

Spis treści

1. Wprowadzenie	9
Krok 1 - Przygotowanie zestawu	10
Krok 2 - How to navigate through the manual	10
Krok 3 - View high resolution images	11
Krok 4 - All the required tools are included	11
Krok 5 - Additional utilities for this guide	12
Krok 6 - Przewodnik po etykietach	12
Krok 7 - Woreczek z częściami zapasowymi	13
Krok 8 - Printed parts - versioning	13
Krok 9 - We are here for you!	14
Krok 10 - Pro tip: inserting the nuts	15
Krok 11 - Ważne: ochrona elektroniki	16
Krok 12 - Poczęstuj się	17
Krok 13 - How to successfully finish the assembly	18
Krok 14 - Przygotuj obszar roboczy	19
Krok 15 - Installing the add-ons and upgrades	20
2. Montaż podstawy	21
Krok 1 - Tools necessary for this chapter	22
Krok 2 - Base assembly: parts preparation	22
Krok 3 - Inserting the zip ties	23
Krok 4 - Base assembly: parts preparation	23
Krok 5 - Installing the motor mounts	24
Krok 6 - Installing the rear motor	24
Krok 7 - Securing the rear motor	25
Krok 8 - Installing the front motor right	25
Krok 9 - Installing the front motor left	26
Krok 10 - Bottom frame: parts preparation	26
Krok 11 - Assembling the bottom profile: front + left	27
Krok 12 - Assembling the bottom profile: left + rear	27
Krok 13 - Assembling the bottom profile: right	28
Krok 14 - Inserting the spacer pins	28
Krok 15 - Anti-vibration feet: parts preparation	29
Krok 16 - Installing the anti-vibration feet	29
Krok 17 - Installing the bottom frame	30
Krok 18 - Mounting the bottom frame: right side	30
Krok 19 - Mounting the bottom frame: rear + left + front	31
Krok 20 - Czas na Haribo	31
Krok 21 - Gotowe	32
3. Montaż tylnej części	33
Krok 1 - Tools necessary for this chapter	34
Krok 2 - PSU assembly: parts preparation	34
Krok 3 - Przygotowanie zasilacza	35
Krok 4 - Informacja o przewodach zasilających	36
Krok 5 - Podłączenie zasilacza	37
Krok 6 - xBuddy: parts preparation I.	37
Krok 7 - xBuddy: parts preparation II.	38
Krok 8 - Applying the thermal pads	38
Krok 9 - Montaż płyty xBuddy	39
Krok 10 - Installing the xBuddy extension	39
Krok 11 - Opaski zaciskowe	40

Krok 12 - Connecting the xBuddy extension board	40
Krok 13 - Inserting grommets: xBuddy box	41
Krok 14 - Wi-Fi: przygotowanie części	41
Krok 15 - Montaż modułu Wi-Fi	42
Krok 16 - Installing the Wi-Fi assembly	42
Krok 17 - Back panel: parts preparation	43
Krok 18 - Installing grommets: back panel top	43
Krok 19 - Installing grommets: sides + bottom	44
Krok 20 - Ustawienie zasilacza	44
Krok 21 - Montaż zasilacza	45
Krok 22 - Aligning the xBuddy box assembly	45
Krok 23 - Mounting the xBuddy box	46
Krok 24 - Power cables cover: parts preparation	46
Krok 25 - Connecting the power cables	47
Krok 26 - Przygotowanie pokrywki przewodów zasilacza	48
Krok 27 - Covering the PSU cables	48
Krok 28 - Chamber fans: parts preparation	49
Krok 29 - Assembling the fan grid	49
Krok 30 - Montaż wentylatorów	50
Krok 31 - Covering the cooling fans	50
Krok 32 - Rear profiles: parts preparation	51
Krok 33 - Installing the rear profiles	51
Krok 34 - Mounting the back panel	52
Krok 35 - Stepper splitter: parts preparation	52
Krok 36 - Guiding the Stepper splitter cable	53
Krok 37 - Connecting the Stepper splitter	53
Krok 38 - Mounting the Stepper Splitter	54
Krok 39 - LCD cable: parts preparation	54
Krok 40 - Guiding the LCD cable	55
Krok 41 - Main FE cable INFO	55
Krok 42 - Connecting the FE cable (no 3.)	56
Krok 43 - Guiding the FE cable (no. 2)	56
Krok 44 - Guiding the FE cable (no. 1)	57
Krok 45 - Guiding the FE cable (no. 4 and 5)	57
Krok 46 - FE cable - xBuddy: parts preparation	58
Krok 47 - Connecting the FE cable: xBuddy	58
Krok 48 - Plugging the xLCD cable	59
Krok 49 - Pokrywa zasilacza: przygotowanie części	59
Krok 50 - Connecting the FE cable: PSU	60
Krok 51 - Czas na Haribo	60
Krok 52 - Gotowe	61
4. Montaż stołu grzewczego	62
Krok 1 - Narzędzia niezbędne w tym rozdziale	63
Krok 2 - Stół grzewczy: przygotowanie części	64
Krok 3 - Montaż przewodów stołu grzewczego (część 1)	64
Krok 4 - Montaż przewodów stołu grzewczego (część 2)	65
Krok 5 - Dolna pokrywa przewodów stołu: przygotowanie części	65
Krok 6 - Montaż pokrywy przewodów	66
Krok 7 - Rama stołu: przygotowanie części	66
Krok 8 - Przygotowanie ramy stołu	67
Krok 9 - Montaż złączy kompensacyjnych	67
Krok 10 - Taśma LED RGB: przygotowanie części	68
Krok 11 - Montaż taśmy LED	68
Krok 12 - Montaż dyfuzora LED	69

Krok 13 - Przykrycie taśmy LED RGB	69
Krok 14 - Ułożenie przewodu LED RGB	70
Krok 15 - Mocowania stołu: przygotowanie części	70
Krok 16 - Montaż mocowań stołu	71
Krok 17 - Przykręcenie mocowań stołu	71
Krok 18 - Mocowania stołu: nakrętki	72
Krok 19 - Montaż tylnego elementu dystansowego	72
Krok 20 - Montaż prawego mocowania stołu	72
Krok 21 - Montaż lewego mocowania stołu	73
Krok 22 - Montaż stołu grzewczego: przygotowanie części	73
Krok 23 - Montaż stołu grzewczego	74
Krok 24 - Przykręcenie stołu grzewczego	74
Krok 25 - Osłona przewodów: przygotowanie części	75
Krok 26 - Organizacja przewodów stołu grzewczego	75
Krok 27 - Montaż pokrywy przewodów stołu grzewczego	76
Krok 28 - Montaż stołu grzewczego: przygotowanie części	76
Krok 29 - Przymocowanie stołu grzewczego	77
Krok 30 - Mounting the heatbed assembly: rear motor	78
Krok 31 - Mounting the heatbed assembly: front motor left	78
Krok 32 - Mounting the heatbed assembly: front motor right	79
Krok 33 - Attaching the heatbed cables I.	79
Krok 34 - Attaching the heatbed cables II.	80
Krok 35 - Securing the heatbed cables: parts preparation	80
Krok 36 - Securing the textile sleeve	81
Krok 37 - Guiding the heatbed assembly cables	81
Krok 38 - Connecting the heatbed power cables	82
Krok 39 - Czas na Haribo	82
Krok 40 - Gotowe	83
5. Montaż CoreXY	84
Krok 1 - Tools necessary for this chapter	85
Krok 2 - Rod holders: parts preparation	85
Krok 3 - Assembling the rod holders	86
Krok 4 - Preparing the front rod holders	86
Krok 5 - Installing the front rod holders	87
Krok 6 - XY carriage: parts preparation	87
Krok 7 - Montaż wózków XY	88
Krok 8 - Assembling the linear holder left	88
Krok 9 - Assembling the linear holder right	89
Krok 10 - Attaching the linear holder assemblies	89
Krok 11 - Info o prętach liniowych	90
Krok 12 - Mounting the smooth rods	90
Krok 13 - Securing the rear rod holders	91
Krok 14 - Securing the front rod holders	91
Krok 15 - Motor mounts: parts preparation	92
Krok 16 - Motor mounts: part preparation	92
Krok 17 - Assembling the XY-motor-mount-right I.	93
Krok 18 - Assembling the XY-motor-mount-right II.	93
Krok 19 - Assembling the XY-motor-mount-left I.	94
Krok 20 - Assembling the XY-motor-mount-left II.	94
Krok 21 - Belt tensioners: parts preparation I.	95
Krok 22 - Belt tensioners: parts preparation II.	95
Krok 23 - Koła pasowe napinaczy: przygotowanie części	96
Krok 24 - Assembling the belt tensioner left I.	96
Krok 25 - Assembling the belt tensioner left II.	97

Krok 26 - Assembling the belt tensioner right	97
Krok 27 - Installing the belt tensioners: parts preparation	98
Krok 28 - Installing the motor mount left	98
Krok 29 - Installing the motor mount right	99
Krok 30 - Montaż lewego napinacza paska	99
Krok 31 - Montaż prawego napinacza paska	100
Krok 32 - Linear rail: parts preparation	100
Krok 33 - Attaching the linear rail	101
Krok 34 - Securing the linear rail	101
Krok 35 - Installing the linear rail: parts preparation	102
Krok 36 - Installing the linear rail assembly	102
Krok 37 - Linear rail: removing the safety pins	103
Krok 38 - Ogranicznik stołu: przygotowanie części	103
Krok 39 - Montaż ogranicznika stołu	103
Krok 40 - Montaż ogranicznika stołu	104
Krok 41 - X&Y motors: parts preparation	104
Krok 42 - Installing the X-axis pulley	105
Krok 43 - Installing the Y-axis pulley	106
Krok 44 - XY belts: parts preparation	107
Krok 45 - Info o paskach XY	107
Krok 46 - Y belt guiding: Y motor pulley	108
Krok 47 - Securing the Y-axis motor	108
Krok 48 - Y belt guiding: Y motor mount	109
Krok 49 - Y belt guiding: belt tensioner	109
Krok 50 - Y belt guiding: X motor mount	110
Krok 51 - Y belt guiding: securing the belt	110
Krok 52 - X belt guiding: X motor pulley	111
Krok 53 - Securing the X-axis motor	111
Krok 54 - Y belt guiding: X motor mount	112
Krok 55 - X belt guiding: belt tensioner	112
Krok 56 - X belt guiding: Y motor mount	113
Krok 57 - X belt guiding: securing the belt	113
Krok 58 - Checking the belt guidance	114
Krok 59 - Bowden guide: parts preparation	114
Krok 60 - Securing the Nextruder holder	115
Krok 61 - Securing the Y motor cable	115
Krok 62 - Securing the X motor cable	116
Krok 63 - Installing the bowden guide	116
Krok 64 - White LED strip: parts preparation	117
Krok 65 - Sticking the White LED strip	117
Krok 66 - Installing the white LED assembly	118
Krok 67 - Door sensor & White LED strip: parts preparation	118
Krok 68 - Inserting the zip ties	119
Krok 69 - Installing the door sensor	119
Krok 70 - Securing the door sensor cable	120
Krok 71 - Guiding the cables: LED and door sensor	120
Krok 72 - Informacja o kamerze Buddy3D	121
Krok 73 - Smooth rods: parts preparation	121
Krok 74 - Installing the CoreXY assembly	122
Krok 75 - Securing the smooth rods	122
Krok 76 - Aligning the linear rail	123
Krok 77 - Guiding the corexy cables	123
Krok 78 - Guiding the cooling fan cables	124
Krok 79 - Montaż ogranicznika stołu	124
Krok 80 - Connecting the cooling fans cables	125

Krok 81 - Connecting the corexy cables	125
Krok 82 - Czas na Haribo	126
Krok 83 - Gotowe	126
6. Montaż Nextrudera	127
Krok 1 - Tool necessary for this chapter	128
Krok 2 - Nextruder idler assembly: parts preparation	128
Krok 3 - Assembling the extruder idler	129
Krok 4 - Assembling the extruder: parts preparation I.	129
Krok 5 - Montaż ekstrudera: przygotowanie części II	130
Krok 6 - Montaż ekstrudera	130
Krok 7 - Montaż przekładni planetarnej	131
Krok 8 - Montaż pierścienia przekładni	132
Krok 9 - Montaż zespołu przekładni	132
Krok 10 - Kontrola montażu przekładni	133
Krok 11 - Assembling the Nextruder idler	133
Krok 12 - Gear lubrication: parts preparation	134
Krok 13 - Smarowanie kół zębatach	134
Krok 14 - Covering the planetary gear	135
Krok 15 - Assembling the Idler-swivel: parts preparation	135
Krok 16 - Montaż odchylanej blokady docisku	136
Krok 17 - Montaż nakrętki docisku	136
Krok 18 - Mounting the Idler-swivel assembly	137
Krok 19 - NTC thermistor: parts preparation	137
Krok 20 - Assembling the NTC thermistor	138
Krok 21 - Mounting the Nextruder: parts preparation	138
Krok 22 - Zabezpieczenie stołu grzewczego	139
Krok 23 - Montaż Nextrudera	139
Krok 24 - Wentylator hotendu: przygotowanie części	140
Krok 25 - Montaż wentylatora hotendu	140
Krok 26 - Organizacja przewodów wentylatora hotendu	141
Krok 27 - LoveBoard: parts preparation I.	141
Krok 28 - LoveBoard: parts preparation II.	142
Krok 29 - Montaż mocowania płytki LoveBoard	142
Krok 30 - Montaż pokrywy głowicy	143
Krok 31 - Montaż płytki LoveBoard	143
Krok 32 - Organizacja głównej wiązki przewodów	144
Krok 33 - Zakrycie płytki LoveBoard	144
Krok 34 - Swingarm: parts preparation I.	145
Krok 35 - Swingarm: parts preparation II.	145
Krok 36 - Organizacja głównej wiązki przewodów	146
Krok 37 - Mounting the main cable	146
Krok 38 - Attaching the LoveBoard assembly	147
Krok 39 - Montaż Swingarm	147
Krok 40 - Attaching the main cable	148
Krok 41 - Inserting the PTFE tube	148
Krok 42 - Securing the PTFE tube	149
Krok 43 - Sprawdzenie ruchu	149
Krok 44 - Print fan: parts preparation	150
Krok 45 - Montaż kanału wentylatora	150
Krok 46 - Installing the print fan assembly	151
Krok 47 - Hotend: przygotowanie części	151
Krok 48 - Montaż hotendu	152
Krok 49 - Connecting the heatsink cables	152
Krok 50 - Connecting the hotend cables	153

Krok 51 - Connecting the print fan cable	153
Krok 52 - Podłączenie silnika ekstrudera	153
Krok 53 - LoveBoard covers: parts preparation	154
Krok 54 - Zakrycie płytki LoveBoard	154
Krok 55 - LoveBoard: kontrola okablowania	155
Krok 56 - Guiding the main cable	155
Krok 57 - Czas na Haribo	156
Krok 58 - Gotowe	156
7. Bodywork & Electronics	157
Krok 1 - Tools necessary for this chapter	158
Krok 2 - Front profiles: parts preparation	158
Krok 3 - Installing the front right profile	159
Krok 4 - Installing the front left profile	159
Krok 5 - Top profiles: parts preparation	160
Krok 6 - Assembling the top profiles I.	160
Krok 7 - Assembling the top profiles II.	161
Krok 8 - Aligning the top profiles	161
Krok 9 - Installing the top profiles	162
Krok 10 - CoreXY fixing screws: parts preparation	162
Krok 11 - Fixing the CoreXY assembly	163
Krok 12 - Side sensor base: parts preparation	163
Krok 13 - Assembling the side sensor base	164
Krok 14 - Test dźwigni	164
Krok 15 - Montaż przełącznika	165
Krok 16 - IR Sensor: parts preparation	165
Krok 17 - Connecting the IR sensor	166
Krok 18 - Installing the IR sensor	166
Krok 19 - Installing the side sensor cover	167
Krok 20 - Side filament sensor: parts preparation	167
Krok 21 - Installing the side filament sensor	168
Krok 22 - Guide the filament sensor cable	168
Krok 23 - Connecting the side filament sensor	169
Krok 24 - NFC Antenna: parts preparation	169
Krok 25 - Applying the adhesive film	170
Krok 26 - Installing the NFC Coil	170
Krok 27 - Connecting the NFC Coil	171
Krok 28 - Kontrola okablowania	171
Krok 29 - Preparing the electronics cover	172
Krok 30 - Installing the electronics cover	172
Krok 31 - Informacja o kamerze Buddy3D	173
Krok 32 - xBuddy cover: parts preparation	173
Krok 33 - Installing the xBuddy cover	174
Krok 34 - Installing the rear cover	174
Krok 35 - Right side: parts preparation	175
Krok 36 - Montaż krążka uchwytu szpuli	175
Krok 37 - Right handle: parts preparation	176
Krok 38 - Montaż tulei zaciskowej	176
Krok 39 - Montaż uchwytu	177
Krok 40 - Fixing the right side	177
Krok 41 - Left side: parts preparation	178
Krok 42 - Installing the left side	178
Krok 43 - Czas na Haribo	179
Krok 44 - Gotowe	179
8. Trim, Door & xLCD	180

Krok 1 - Tools necessary for this chapter	181
Krok 2 - Top cover: parts preparation	181
Krok 3 - Odklejenie folii	182
Krok 4 - Test-fitting the top cover	182
Krok 5 - Assembling the top cover I.	183
Krok 6 - Assembling the top cover II.	183
Krok 7 - Test wentylacji	184
Krok 8 - Installing the top cover	184
Krok 9 - Side covers: parts preparation	185
Krok 10 - Odklejenie folii	185
Krok 11 - Covering the left side	186
Krok 12 - Covering the right side	186
Krok 13 - xLCD: przygotowanie części	187
Krok 14 - Assembling the xLCD I.	187
Krok 15 - Assembling the xLCD II.	188
Krok 16 - Installing the FE Faston connector	188
Krok 17 - Installing the LCD knob	189
Krok 18 - xLCD bezel: parts preparation	189
Krok 19 - Mounting the xLCD I.	190
Krok 20 - Mounting the xLCD II.	190
Krok 21 - Installing the xLCD assembly	191
Krok 22 - Securing the xLCD assembly	191
Krok 23 - Door seal: parts preparation	192
Krok 24 - Attaching the top seal	192
Krok 25 - Attaching the side seals	193
Krok 26 - Magnet holders: parts preparation	193
Krok 27 - Assembling the magnet holders	194
Krok 28 - Installing the magnet holders	194
Krok 29 - Zawiasy: przygotowanie części	195
Krok 30 - Installing the door-hinge-in parts	195
Krok 31 - Installing the door-hinge-out I.	196
Krok 32 - Installing the door-hinge-out II.	196
Krok 33 - Door panel: parts preparation	197
Krok 34 - Door panel: removing the protective film	197
Krok 35 - Installing the door panel	198
Krok 36 - Assembling the door handle	198
Krok 37 - Securing the door handle	199
Krok 38 - Przyklejenie naklejki: przygotowanie	199
Krok 39 - Przyklejenie naklejki	200
Krok 40 - Czas na Haribo	200
Krok 41 - Gotowe	201
9. Calibration & First run	202
Krok 1 - Naciągnięcie paska	203
Krok 2 - Montaż uchwytu szpuli: przygotowanie części	203
Krok 3 - Przymocowanie płyty stołu i uchwytu szpuli	204
Krok 4 - Aktualizacja Firmware	204
Krok 5 - Włączenie drukarki	205
Krok 6 - Konfiguracja drukarki: Intro	205
Krok 7 - Setting up the printer: Network setup	206
Krok 8 - Asystent: Intro	206
Krok 9 - Wizard: Door Sensor Calibration	207
Krok 10 - Asystent: test tensometru	207
Krok 11 - Asystent: osiowanie przekładni	208
Krok 12 - Wizard: Filament Sensor Calibration	208

Krok 13 - Koniec pracy Asystenta	209
Krok 14 - Czas na Haribo	209
Krok 15 - Podręcznik	210
Krok 16 - Baza Wiedzy Prusa	210
Krok 17 - Dołącz do Printables!	211
Lista zmian w instrukcji	212
Krok 1 - Historia wersji	213

1. Wprowadzenie



KROK 1 Przygotowanie zestawu




Witamy w instrukcji montażu i konfiguracji **Prusa CORE One+**. Zapoznaj się dokładnie z poniższymi informacjami, aby mieć pewność, że drukarka jest gotowa do pierwszego wydruku.

Please prepare the kit received from Prusa Research.


No soldering or wire crimping is required.

KROK 2 How to navigate through the manual





- Use the graphical navigation buttons in the bottom right corner or the arrow keys on your keyboard:
- Play backward button / Up arrow key** - Moves to the previous step.
- Left arrow button / Left arrow key** - Moves to the previous image, or to the previous step if it's the first image in the step.
- Next button / Right arrow key** - Moves to the next image, or to the next step if it's the last image in the step.
- Play forward (Next) button / Down arrow key** - Moves to the next step.
- Click on **Contents** to expand the full list of steps in this guide. This allows you to jump to any step regardless of the sequence.
- Click on **Comments** to open the discussion for a specific step and leave your feedback.

KROK 3 View high resolution images



- When you browse the guide on help.prusa3d.com, you can view the original images in high resolution for clarity.
- Just click on the image to open it in high resolution for a detailed view.
- Click on **Fullscreen mode** or press the F key to maximize your screen space and focus entirely on the instructions.

KROK 4 All the required tools are included




● Paczka z narzędziami zawiera:

① Tools can be found in *Electronics & fasteners* package.


- Szczypce spiczaste (1x)
- Philips (PH2) screwdriver (1x)
- Klucz uniwersalny (1x)
- Wrench size 13-16 mm (1x)
- Zestaw kluczy imbusowych
- Zestaw kluczy Torx

KROK 5 Additional utilities for this guide



- ◆ **Some steps in the manual will require commonly available items to help you with assembly (not included in the kit):**
- ◆ Paper towels or a piece of cloth - For wiping preservative oil from the smooth rods and linear rail.
- ◆ Scissors - For cutting a bag with bearings
- ◆ Lubricant (included in the kit) - For lubricating the planetary gear in the Nextruder (print head).

KROK 6 Przewodnik po etykietach



- ◆ All the boxes and bags including parts for the build are labeled.
- ◆ The labels include the list of contents and part count.
- ◆ You can download a **Cheatsheet** with 1:1 fastener drawings from our site prusa.io/core-one-cheatsheet. Print it at 100 %, don't rescale it, otherwise, it won't work.
- i For PRUSA veterans: Fasteners are divided into individual bags according to its type. Not into packages for individual chapters, as it was with previous printers.
- P The instructions will specify the package for each part, with the exception of fasteners, which are always located in the Fasteners package.

KROK 7 Woreczek z częściami zapasowymi




- ◆ Spare fasteners are included in each bag of fasteners. The amount of spare is always included in the total number shown on the bag.
- ◆ Similarly, some parts may include one extra piece in the same bag.

KROK 8 Printed parts - versioning



- ◆ Większość części drukowanych w Prusa CORE One+ jest oznaczonych wersją.
- ◆ **E, F and Gx series** (e.g. E1) - those parts are printed on Prusa Research farm and are distributed with the kit.
- ◆ **R, S and Tx series** (e.g. R1) - those parts are available for download at [printables.com](https://www.printables.com). They are identical to the factory ones.
- ◆ The numbers indicate minor revisions that usually involve small design tweaks. A different label in the manual (e.g., a different version shown in photos) does not affect the assembly – all versions are fully compatible.
- ◆ However, if a specific revision requires a different assembly procedure, we will clearly highlight it in the manual and explain the differences.
- ① In case you have issues while assembling the printer with the certain printed part, please try to find this label and tell it to our support team.

KROK 9 We are here for you!




- Lost in the instructions, missing screw or cracked printed part? **Let us know!**
- You can contact us using the following channels:
 - Using comments under each step.
 - Using our 24/7 live chat here at help.prusa3d.com
 - Writing an email to info@prusa3d.com

KROK 10 Pro tip: inserting the nuts



- 3D printed parts are very precise, however, there still might be a tolerance in the printed part and the same goes for the size of the nut.
- Therefore it might happen, that the nut won't fit easily in or might be falling out. Let's see, how to fix it:
 - **Nut won't fit in:** use a screw with a thread along its entire length (typically: M3x10, M3x18) and screw it from the opposite side of the opening. While tightening the screw, the nut will be pulled in. Remove the screw afterwards.
 - **Nut keeps falling out:** Use a piece of tape to fix the nut temporarily in place, as soon as you insert the screw in, you can remove the tape. *Using glue isn't recommended as it can partly reach into the thread and you won't be able to tighten the screw properly.*
- Every time we recommend using the "screw pulling technique", you will be reminded with Joe's avatar ;)
- ① Parts in the pictures are used as an example.

KROK 11 Ważne: ochrona elektroniki



⚠ WARNING: Make sure to **protect the electronics against electrostatic discharge (ESD)**. Always unpack the electronics right before you need them!

Here are some **tips to prevent damage to the electronics**:

- Keep the electronics inside the ESD bag right until you are asked to install them.
- Always touch the sides of the board only while handling it. Avoid touching the components on the surface.
- Before you touch the electronics use any conductive (metal) structure nearby to neutralize the possible static charge from your hands.
- Be extra cautious in rooms with carpets, which are often a source of electrostatic energy.
- Clothes made of wool or certain synthetic fabrics can easily gather static electricity too. It is safer to wear cotton clothing for the assembly.

KROK 12 Poczęstuj się



- ◆ Składanie drukarki CORE One+ jest nie lada wyzwaniem, dlatego ważne jest, aby nagradzać się po przejściu każdego z ważnych etapów. **Właśnie po to dołączyliśmy paczkę misiów Haribo!**
- ⚠ **The biggest issue from our experience** (MK4S, MK4, MK3S+, MK3S, MK3, MK2S, ...) is inadequate bear consumption. Many of you didn't have enough gummy bears for all chapters, some even ate them all before they started!
- ◆ After years of thorough scientific research, we came to a solution => At the end of each chapter, you will be told a specific amount of bears to consume.
- ◆ Eating an incorrect amount than prescribed in the manual might lead to a sudden boost of energy. Please consult a professional in the closest candy store.
- ⚠ **Hide the Haribo for now!** From our experience, an unattended bag with sweets will suddenly disappear. Confirmed by multiple cases all around the World.

KROK 13 How to successfully finish the assembly

Step 25 Attaching the spacers



- Insert two M3n nuts to the X-carriage-back.
- ① Use the screw pulling technique.
- From the opposite side, insert the M3x10 screw into the X-carriage-back. The screw must protrude from the "front" side of the part.
- Attach the spacer 10 mm on the M3x10 screw and tighten the screw. **Note the cutout of the same shape as the spacer. It must fit perfectly and must not rotate.**




2 comments

⚠ Aby poprawnie zmontować CORE One+ z zestawu, przestrzegaj dokładnie poniższych instrukcji:

- **Always read all the instructions at the current step first**, it will help you to understand what you need to do. Don't cut or trim unless you are told to!!!
- **Don't follow pictures only!** It is not enough, the written instructions are as brief as they could be. **Read them!**
- Read the comments from the other users, they are great sources of ideas. We read them too and based on your feedback improved the manual and the entire assembly.
- **Use a reasonable force**, the printed parts are tough, but not unbreakable. If it doesn't fit, check your approach twice.
- **Eat the gummy bears as instructed!** Disobedience won't be tolerated :D
- **Most importantly: Enjoy the build, and have fun.** Cooperate with your kids, friends or partners.

KROK 14 Przygotuj obszar roboczy



- **Tidy up your desk!** Tidying up decreases the probability of losing small parts.
- **Clear your workspace.** Make sure you have enough room. A nice clear flat workbench will get you the results you are aiming for.
- **Let there be light!** Make sure you are in a well-lit environment. Another lamp or even an extra flashlight will probably come in handy.
- Prepare something to contain the plastic bags and the removed packing materials so you can recycle them afterwards. Make sure there are no important parts being discarded.
- A minimum working space of 1.5×1.5 meters (60×60 inches) is recommended.
- ⚠ **It's highly recommended to place a soft pad on your workbench. Some sheet metal parts have sharp edges that could scratch the surface.**
- ① You can use a piece of cardboard as a protective pad.
- OK, we are ready. Let's start! Go to chapter **2. Frame assembly**

KROK 15 Installing the add-ons and upgrades




- ◆ This information applies to users planning to install upgrades and add-ons, such as Buddy Camera, an advanced filtration system, and MMU3 in the future.
- ① **Before installing any add-ons and upgrades, it is essential to completely assemble and test your printer.** Once the printer is fully functional, follow the separate MMU3 or add-on assembly manuals to modify the printer for installation.

2. Montaż podstawy




KROK 1 Tools necessary for this chapter



● For this chapter, please prepare:

- Klucz 13-16
- Klucz imbusowy 2,5 mm
- Klucz / wkrętak Torx T10


KROK 2 Base assembly: parts preparation



● For the following steps, please prepare:


- Bottom panel (1x) found in the Metal parts 1/3 package
- Zip tie (6x) found in the Electronics & Fasteners package

KROK 3 Inserting the zip ties




- ✿ Turn the bottom panel so that the bends of the plate are facing upwards.
 - ✿ Note the twin holes for the zip ties around the perimeter of the panel.
 - ✿ Insert six zip ties through the holes, placing them along both sides and partially tightening them, engaging only the first few teeth.
- ⚠ **Nie zaciskaj ich jeszcze w pełni, ponieważ później przeprowadzimy przez nie przewody.**
- ℹ Note: The orientation of the zip tie heads (inside or outside the metal sheet) doesn't matter.

KROK 4 Base assembly: parts preparation



- ✿ **For the following steps, please prepare:**
- ✿ Z-axis left motor (2x) *found in the Motor set box.*
- ⚠ **One Z-axis left motor is packed separately in the *Electronics & chamber parts* package.**
- ℹ Na razie pozostaw nakrętki trapezowe w opakowaniach po silnikach.
- ✿ Z-axis right motor (1x) *found in the Motor set box*
- ✿ Z-motor-mount (3x) *found in the Printed parts package*
- ✿ Motor washer (3x) *found in the Electronics & Chamber parts package*
- ✿ Z-rod-mount (2x) *found in the Printed parts package*
- ✿ Śruba M3x8 (24x)

KROK 5 Installing the motor mounts




- 🔴 Spróbuj obrócić pręty gwintowane na każdym silniku Z, aby upewnić się, że nie są zablokowane.
- 🔵 Attach one transparent motor washer pad on each Z motor.
- 🟡 Place one Z-motor-mount on each motor washer. **The protrusions on the part must be facing upwards.**
- ⬛ Align holes with all the parts.
- 🟢 Przykręć części do siebie czterema śrubami M3x8.
- ⬛ Follow the same procedure for all motors.

KROK 6 Installing the rear motor



- 🟡 Turn the bottom panel upside down.
- 🟡 Locate the circle hole in the middle of the panel back side.
- 🔵 Take the **Z motor right** - the motor with the longest cable. Labeled ZR on the cable.
- 🟢 Push the motor threaded rod through the panel and align the holes in the panel with the holes in the motor assembly.
- ⚠️ **The motor cable must point outwards (towards you).**
- 🔵 Push both Z-axis motor left through the bottom panel.
- 🔴 **The motor cables must point to the rear motor side.**
- 📄 **i** In the following instructions, we will refer to the **front** and **rear** sides of the assembly. The **front side has TWO motors**, while the **rear side has ONE motor**. We will remind you along the way, but it's good to keep this in mind :).

KROK 7 Securing the rear motor




- ✦ Begin securing the motors, starting from the rear motor.
- ✦ Insert and fully tighten four M3x8 screws into the **rear motor**.
 - ⚠ Make sure the screws stay straight and do not tilt as you tighten them.
 - ⚠ Do not overtighten the screws, as they thread directly into the plastic part. For a final tightening, use the shorter part of the key as a handle to apply the correct amount of torque.

KROK 8 Installing the front motor right



- ✦ First, insert the rod-mount into the opening next to the front right Z motor.
- ✦ Use the 13-16 wrench to rotate the rod mount 90 degrees, locking it into place.
- ✦ Secure the motor using four M3x8 screws. Tighten them completely.
 - ⚠ Make sure the screws stay straight and do not tilt as you tighten them.

KROK 9 Installing the front motor left




- Let's move to the front left motor (from the front view).
- ⚠ **Ensure, the motor cable still points to the rear side.**
- Insert the rod-mount into the opening next to the front right Z motor.
- Use the 13-16 wrench to rotate the rod mount 90 degrees, locking it into place.
- Secure the motor using four M3x8 screws. Tighten them completely.
- ⚠ **Make sure the screws stay straight and do not tilt as you tighten them.**
- Place the whole assembly aside for a while.

KROK 10 Bottom frame: parts preparation



- **For the following steps, please prepare:**
- ⚠ **Be very careful when handling sharp sheet metal parts to avoid injury or damage.**
- ⚠ **Metal sheet profiles may look identical at first glance, but there are some differences. DOUBLE-CHECK to pick the correct ones.**
- Front profile (1x) **notice the cutouts** - found in the Metal parts 1/3 package
- Rear profile (1x) **with two holes on the flat side** - found in the Metal parts 1/3 package
- Universal profile (2x) **no holes on the flat side** - found in the Metal parts 1/3 package
- Spacer pin (2x) found in the Electronics & Fasteners package
- Śruba M3x4rT (4x)

KROK 11 Assembling the bottom profile: front + left



⚠ Be very careful when handling sharp sheet metal parts to avoid injury or damage.

- 🔵 Place the front profile according to the picture. The cutouts must be facing you.
- 🟢 Place one of the universal profiles on the left side. Orient the part according to the picture. **Use the flange as a guide.**
- ⬛ Attach the two profiles together.
 - ⚠ The flange of the front plate (blue arrow) must be inserted **under** the left universal profile (green arrow), not on top of it.
- 🟡 Align the holes in both parts.
- 🟠 Join both parts together with the M3x4rT screw.

KROK 12 Assembling the bottom profile: left + rear



- 🟡 According to the picture, place the rear profile (with two holes on the flat side) to the universal left profile. Orient the part according to the picture. **Use the flange as a guide.**
- 🟢 Join the rear profile with the universal left profile together.
 - ⚠ Make sure the flange is under the rear profile, not on top.
- 🟡 Align the holes in both parts.
- 🟠 Join both parts together with the M3x4rT screw.

KROK 13 Assembling the bottom profile: right



- Attach the universal right profile between the rear and front profile. **Ensure that:**
 - The **rear** end is **above** the rear profile flange.
 - **Przednia** zakładka jest **pod** przednim profilem.
- Secure the left profile with M3x4rT on both ends.

KROK 14 Inserting the spacer pins



- Insert the spacer pin into the hole in the front profile protrusion.
- Push firmly on the spacer pin so that it fits perfectly into the hole.
- Zrób to samo z drugim kątem.

KROK 15 Anti-vibration feet: parts preparation



● For the following steps, please prepare:

- Anti-vibration foot (4x) found in the *Electronics & Chamber parts package*
- Śruba M3x4rT (8x)

KROK 16 Installing the anti-vibration feet



- Place the bottom frame according to the picture. The front profile must be facing you.




Before applying the anti-vibration feet, **wipe the metal profiles with isopropyl alcohol** and let them dry. This ensures proper adhesion.

- Odklej folię zabezpieczającą ze wszystkich stóp antywibracyjnych.

⚠ Ostrożnie zdejmij **tylko folię ochronną** z każdej nóżki antywibracyjnej. Jeśli wraz z folią zacznie odklejać się taśma klejąca, zatrzymaj się i wznów odklejanie warstwy ochronnej z innego rogu.

- Stick one anti-vibration foot in each corner of the frame. Align it with the outer edge of the flat side of the profile.

KROK 17 Installing the bottom frame




- 🔵 Turn the bottom frame upside down. **The front profile must be facing you.**
- 🟡 Attach the rear side of the bottom panel assembly to the rear side of the bottom frame.
- 🟠 Upewnij się, że przednia część zespołu panelu dolnego (z dwoma silnikami) jest wyrównana z przednim profilem ramy dolnej (z wycięciami).
- 🟣 Place all the motor cables inside the center area of the bottom frame to prevent pinching.
- 🟢 Slowly and carefully lower the bottom panel assembly into the bottom profile.
 - ⬛ Ensure the assembly fits completely **inside the bottom profile.**
 - ⬛ Make sure no part of the bottom panel assembly extends outside the bottom frame
- ⚠️ **Double-check that no cables are pinched.**

KROK 18 Mounting the bottom frame: right side




- ⬛ Focus on the front right corner and right side.
- 🟡 Slightly lift one of the corners of the bottom panel assembly.
- 🟢 Wyrównaj gwintowany otwór w dolnym panelu z otworem w profilu.
- 🟢 Join both parts together with the M3x4rT screw.
- ⬛ Move to the rear corner of the right side.
- 🟣 Align the holes in the base and the profile and secure it with the M3x4rT screw.

KROK 19 Mounting the bottom frame: rear + left + front



- Move to the rear side of the assembly (side with one Z motor).
- Align holes in the base assembly and the profile and secure it with two M3x4rT screws.
- Skoncentruj się na lewej stronie zespołu.
- Align holes in the base assembly and the profile and secure it with two M3x4rT screws.
- Turn the assembly with the front profile facing you (profile with cutouts).
- Align holes in the base assembly with the profile and secure them using two M3x4rT screws.

KROK 20 Czas na Haribo



- It's time to reward yourself!
- Stack your gummy bears in eight rows.
- W każdym rzędzie ułóż taką liczbę żelków, jak na ilustracji.
- ① If you don't get the exact number in the last row, we recommend finding the nearest candy store and buying the missing ones.
- Eat the first row.

KROK 21 Gotowe



- ◆ **Congratulations!** You just assembled the **base assembly**.
- ◆ Set the assembly aside for now and let's move to the next chapter.

3. Montaż tylnej części




KROK 1 Tools necessary for this chapter



- **For this chapter, please prepare:**
- Wkrętak krzyżakowy PH2
- Szczypce spiczaste
- Klucz imbusowy 2,5 mm
- T10 torx key / T10 torx screwdriver

KROK 2 PSU assembly: parts preparation




- **For the following steps, please prepare:**
- Delta PSU 240 W 24 V (1x) *power supply*
- M4x6r screw (2x) *from the Fasteners 3/3 package*
- xBuddy power cables (2x) *found in the Electronics package*
- Power panic cable (1x) *found in the Electronics package*

KROK 3 Przygotowanie zasilacza



- Insert two M4x6r screws into the left side of the PSU. **Do not tighten them completely.** Leave at least a 4 mm (0.16 in) gap between the screw head and the PSU.
- Slightly loosen all four power terminal screws on the PSU. **Do not remove them.** 3-4 turns are enough.

KROK 4 Informacja o przewodach zasilających




- ❗ In the following steps, we will be connecting the power cables one by one. The terminal screws are installed on the PSU already. Loosen them but **don't remove them completely** so they don't get mixed up with the other type of screws used on the xBuddy board side of the cable. Each of the two power cables has two leads. One has a prevailing **red color = positive / +**. One has a prevailing **black color = negative / -**.
- 🔵 Note that the power cables have different connectors on each end. For now, prepare the U-shaped connectors (crimping tube color may vary).
- ⬛ **Note that the polarity of the terminals on the PSU is:**
- 🔴 Dodatni (V+)
 - 🔴 Dodatni (V+)
 - ⬛ Ujemny (V-)
 - ⬛ Ujemny (V-)
- ❗ Czerwony przewód (dodatni) może mieć czarny pasek. Podobnie czarny przewód (ujemny) może mieć czerwony pasek.
- ⚠ **Do not connect any cables yet, wait until you have been prompted.**

KROK 5 Podłączenie zasilacza




- Take the RED wire and slide the fork connector all the way into the first (positive) terminal from the left on the bottom of the PSU. Make sure the steel washer is above the "fork" connector.
- Tighten the terminal screw firmly.
- Use the same procedure to connect the second red wire to the second terminal slot from the left.
- Connect two black wires to the third and fourth terminal slots using the same procedure.
- Plug the power panic cable to the right most connector.
- Put the assembly aside for a while.

KROK 6 xBuddy: parts preparation I.




- **For the following steps, please prepare:**
- CORE One xBuddy box (1x) *found in the Metal parts 3/3 package*
- Grommet 19/16 mm (2x) *found in the Electronics & Fasteners package*
- Thermal pad 40x12x2.2 mm (1x) *found in the Electronics & Fasteners package*
- Thermal pad 12x12x2.2 mm (2x) *found in the Electronics & Fasteners package*
- Opaska zaciskowa (4x)
- Śruba M3x6 (9x)
- **i** Dalszy ciąg listy w kolejnym kroku instrukcji...

KROK 7 xBuddy: parts preparation II.




- xBuddy extension board (1x) found in the Electronics & chamber package
- xBuddy board (1x) found in the Electronics package
- xBuddy extension cable (1x) found in the Electronics & Fasteners package
- Assembly-multi-tool (1x) found in the Printed parts package

KROK 8 Applying the thermal pads



- Peel off the white protective layer from all thermal pads.
 - ⚠ **Always touch the sides of the electronics board while manipulating it. Avoid touching the chips, capacitors and other parts of the electronics.**
- Attach the pads onto the back of the xBuddy board. There are markings that indicate the correct size and positions.
 - ⓘ The surface to which the pads are stuck must be cleaned of grease. This will ensure better adhesion.
- ⚠ **For the protection of the board's electronic components, we strongly recommend placing the xBuddy board on the soft pad. You can use the original xBuddy bubble wrap package.**
- Peel off the blue protective layer from all thermal pads.
 - ⓘ Protip: Jeśli masz trudności z odklejeniem folii, możesz użyć cienkiej strony multitoola montażowego, aby oddzielić krawędź.


KROK 9 Montaż płyty xBuddy



⚠ Always touch the sides of the electronics board while manipulating it. Avoid touching the chips, capacitors and other parts of the electronics.


- ✿ Insert the xBuddy board to the xBuddy box.
 - Make sure the Ethernet connector is properly inserted into the hole in the xBuddy box.
- ✿ **Before fully attaching it completely**, center the holes in the board with the holes (columns) in the xBuddy box
- ✿ Fix the position of the xBuddy board by inserting five M3x6 screws. Do not fully tighten the screws. A few turns are enough for now.
- ⚠ **Put aside your instinct and leave the hole on the bottom right empty.**
- **Całkowicie dokręć wszystkie pięć śrub, jednak zachowaj szczególną ostrożność, aby nie uszkodzić płytki.**

KROK 10 Installing the xBuddy extension




- ✿ Insert the xBuddy extension board to the xBuddy box above the xBuddy board. Notice the part orientation.
- ✿ Before fully attaching it completely, center the holes in the board with the holes (columns) in the xBuddy box.
- ✿ Fix the position of the xBuddy extension board by inserting four M3x6 screws. Tighten them completely.

KROK 11 Opaski zaciskowe



- Take a closer look at the xBuddy box. There are six perforations on the metal case.
- ⚠ Proceed very carefully. Be careful not to damage the connectors or capacitors on the xBuddy board.**
- Attach the hook on the Assembly-multi-tool below the first perforation on the left.
- Push the zip tie through the perforation and into the Assembly-multi-tool. It will guide the zip tie into the electronics box.
- ⚠ Note the correct orientation of the zip tie. The teeth on the zip tie must be on the visible side.**
- Repeat the process at the indicated perforations.
- Pomiń trzecią i szóstą perforację.

KROK 12 Connecting the xBuddy extension board



- Plug the xBuddy extension connector with the free red cable to the xBuddy extension board.
- Leave the red cable free for now.
- Plug the other end of the xBuddy extension cable to the xBuddy board.

KROK 13 Inserting grommets: xBuddy box



- Insert both grommets into both circle holes in the xBuddy box.
- Gently compress the grommet and fit it into the metal sheet, ensuring the groove locks into place

KROK 14 Wi-Fi: przygotowanie części




- For the following steps, please prepare:
- ESP-WiFi (1x) found in the Electronics package
- CORE-One-Wifi-cover (1x) found in the Printed parts package
- Śruba M3x12 (1x)
- Śruba M3x6 (2x)

KROK 15 Montaż modułu Wi-Fi




- ✚ Insert two M3x6 screw to the xBuddy box assembly from the right side. **Do not tighten them completely.** Leave at least a 4 mm (0.16 in) gap.
- ✚ Insert the ESP-WiFi module into the WiFi-cover, positioning it just below the bridge on the left side.
- ✚ On the other side, ensure the connector fits correctly into the hole in the cover.

KROK 16 Installing the Wi-Fi assembly



- ⚠ **Be very careful when handling and connecting the ESP module to avoid bending and damaging the pins.**
- ✚ Take the WiFi cover assembly and connect the ESP module pins to the connector in the xBuddy.
- ✚ Close the WiFi cover carefully, ensuring the pins of the ESP module are properly engaged in the connector on the xBuddy.
- ✚ Secure the cover with the M3x12 screw.
- ⬛ Put the assembly aside for a while.

KROK 17 Back panel: parts preparation



● **For the following steps, please prepare:**


- Back panel (1x) *found in the Metal parts 1/3 package*
- Grommet 19/16 mm (2x) *large one - found in the Electronics & Fasteners package*
- Grommet 13.5/10 mm (2x) *small one - found in the Electronics & Fasteners package*
- Sealing plug 15.5 mm (1x) *found in the Electronics & Fasteners package*
- Śruba M3x4rT (2x)

KROK 18 Installing grommets: back panel top




- Position the back panel as shown in the first image. Use the two oval holes as a reference.
- Insert the sealing plug into the center hole.
 - **The sealing plug is not symmetrical.** Insert the side with the smaller diameter facing downward.
- Insert one small grommet to the left circle hole.
- Insert one small grommet into the oval hole.

KROK 19 Installing grommets: sides + bottom




- Focus on the left top side of the back panel and locate two oval holes.
- Insert one large grommet into the oval hole closest to the corner.
- Move to the right top side of the back panel and insert one large grommet to the oval hole.

KROK 20 Ustawienie zasilacza




- Carefully insert the PSU into the rear panel pocket.
- Align the screws on the PSU to the holes on the left side of the back panel.
- Slide the PSU so that the screws go through the holes.

KROK 21 Montaż zasilacza




- Gently slide the PSU so that the position of the screws moves to the end position of the keyhole-shaped holes.
- Maintain the PSU position and fully tighten both screws.

KROK 22 Aligning the xBuddy box assembly



- Carefully insert the xBuddy box assembly into the rear panel pocket.
- Align the screws on the xBuddy box to the holes on the right side of the back panel.
- Slide the xBuddy box so that the screws go through the holes.

KROK 23 Mounting the xBuddy box




- Gently slide the xBuddy box assembly so that the position of the screws moves to the end position of the keyhole-shaped holes.
- Maintain the xBuddy box position and fully tighten both screws.
- Fix the PSU and xBuddy box assembly to the back panel by tightening two M3x4rT screws.

KROK 24 Power cables cover: parts preparation




- **For the following steps, please prepare:**
- PSU-cable-cover (1x) *found in the Printed parts package*
- Nakrętka kwadratowa M3nS (2x)
- Śruba M3x10rT (2x)
- 6-32 Power Terminal Screw (4x)

KROK 25 Connecting the power cables




- Take one red cable leading from the PSU and connect it to the first left terminal slot on the xBuddy board using the 6/32" terminal screw. Tighten it firmly but gently.
 - ⚠ Note that the "L" shape of the cable connector must always "undercut" the head of the terminal screw.
- Connect the black PSU cable from the same pair as the red one to the second terminal using the 6/32" terminal screw. Tighten the screws firmly.
- Take the second red cable from the PSU and attach it to the red cable leading from the extension board. **Note the detail.** Secure these two cables with the terminal screw in the third terminal slot.
- Guide the xBuddy extension cable carefully between the fuses, ensuring it is positioned securely without pressing against them.
- ⓘ **Note that from early 2025, the fuses are different.** Significantly smaller, white, and embedded in the fuse slot in the xBuddy board, so as not to obstruct the cables.
- Podłącz drugi czarny przewód z zasilacza do xBuddy, **upewniając się, że nie zasłania on gwintowanego otworu.**
- Poprowadź przewód Power Panic do obudowy xBuddy i podłącz go do prawego dolnego gniazda na płycie xBuddy. Zwiń nadmiar przewodu w kilka pętli nad gniazdem.
- Arrange the PSU cables as shown, ensuring that no obstructions are around the threaded holes in the PSU and xBuddy box.

KROK 26 Przygotowanie pokrywki przewodów zasilacza




- Insert one M3nS nut into the hole on each end of the PSU-cable-cover.
- Ensure the holes are aligned.

KROK 27 Covering the PSU cables



- Attach the PSU-cable-cover on the PSU cables.
- Secure the cover with two M3x10rT screws in the outermost holes of the part.


KROK 28 Chamber fans: parts preparation



● For the following steps, please prepare:

- Fan grid (1x) found in the Electronics & Chamber parts package
- Chamber thermistor 260 mm (1x) found in the Electronics & Chamber parts package
- Opaska zaciskowa (1x)
- Cooling fan (2x) found in the Electronics & Chamber parts package
- Śruba M3x30 (4x)

KROK 29 Assembling the fan grid



- Guide the thermistor cable under the grid. Thread it in the direction shown in the picture.



❗ The grid has both sides the same.

- Leave the whole thermistor part sticking out.
- Turn the grid over and push the zip tie through the pair of holes on the grid's protrusion.
- Route the thermistor cable in between the zip tie parts.
- Ostrożnie przymocuj przewód termistora opaską zaciskową. **Nie zaciskaj opaski zbyt mocno, aby nie uszkodzić przewodów.**

⚠ **Upewnij się, że główka opaski jest skierowana w tę samą stronę, co na ilustracji. Musi znajdować się po stronie przewodu.**



- Odstaw zmontowane części na bok.

KROK 30 Montaż wentylatorów




- ✦ Place and orient the back panel according to the picture. The grid cutouts must be facing you.
- ✦ Place both fans to the grid in the back panel.
 - ⚠ The side of the fan without the sticker must be facing up.
 - ✦ Orient the fans so that the cables run from the corners in the centre.
 - ⬛ Let the cables hang freely for now, ensuring they are not pinched during handling.

KROK 31 Covering the cooling fans



- ✦ Place the fan grid assembly on the cooling fans.
 - ⚠ **Make sure that the thermistor is pointing up and its cable runs under the grid.**
- ✦ Align holes in the fans, fan grid and the back panel.
- ✦ Secure the fan assembly to the back panel with four M3x30 screws.
 - ⚠ Do not overtighten the screws to avoid damaging the grid.

KROK 32 Rear profiles: parts preparation



● **For the following steps, please prepare:**

- Rear profile (2x) found in the Metal parts 1/3 package

① Take two of the longer ones.

Note that the other two longer ones differ by having cutouts.

- Nit nylonowy (11x)
- Śruba M3x4rT (4x)
- Wkręt samogwintujący 2,9x6,5sT (1x) znajduje się w pakiecie Electronics and Fasteners

KROK 33 Installing the rear profiles




- Take the bottom assembly and turn it so the rear side (with one motor in the center) faces you.



Focus on the right rear corner—the side with the longest oval opening in the bottom panel.


- Attach the rear profile to the right corner, using the **end without flanges**.
- Align the hole on the rear side and secure it with the M3x4rT screw.
- Secure the corner on the other side with a second M3x4rT screw - each corner will be secured with two M3x4rT screws.
- Postępuj tak samo z drugim profilem tylnym w lewym rogu.

KROK 34 Mounting the back panel



- ◆ Slightly lift the back assembly and gently place it on the base assembly and rear profiles.
- ◆ Insert one nylon rivet through the rear panel and rear profile on the top right side.
- ◆ Push the rivet head with your finger until it is fully seated.
- ◆ Use this procedure for all eleven nylon rivets around the back panel assembly to secure it in place.
- ◆ Insert and tighten the 2.9x6.5 self-tapping screw into the back panel. **Avoid overtightening** to prevent stripping the self-tapped thread.

KROK 35 Stepper splitter: parts preparation




- ◆ **For the following steps, please prepare:**
- ◆ Stepper splitter (1x) *found in the Electronics & Chamber parts package*
- ◆ Stepper splitter cable (1x) *found in the Electronics & Fasteners package*

KROK 36 Guiding the Stepper splitter cable



- ✿ Very carefully turn the assembly on its back (back panel).
- ⬢ **It is recommended to support the rear of the assembly** with a soft, raised pad to prevent it from resting on the protruding Wi-Fi module.
- ⓘ Tip: Use the foam padding from the sheet metal parts package or an empty cardboard box.
- ✿ Guide the Stepper splitter cable through the three zip ties on the left side.
- ⬢ For now, leave the side with the label hanging freely outside.
- ⬢ Poprowadź przewód prawego silnika osi Z przez trzy opaski zaciskowe po lewej stronie.
- ⚠ **Nie zaciskaj jeszcze opasek zaciskowych.**

KROK 37 Connecting the Stepper splitter



- ⬢ **Connect the Z motor cables to the stepper splitter:**


- ✿ Przewód Stepper splitter
- ⬢ Prawy silnik osi Z (Z R)
- ✿ Lewy silnik osi Z (Z L)
- ✿ Lewy silnik osi Z (Z L)

KROK 38 Mounting the Stepper Splitter



- Locate two spacer pins in the bottom frame.
- From the inside of the frame, prepare the Stepper splitter and attach its holes opposite the pins.
 - Check the correct orientation of the part by the logo on the board. **The logo is upside down.**
- Push the aligned Stepper Splitter onto the pins until you feel a click - this secures the Stepper Splitter. Push in the center of the board.
- ❗ It is necessary to apply a significant pressure to seat the part in. Yet, be very careful not to damage the components.

KROK 39 LCD cable: parts preparation




- **For the following steps, please prepare:**
 - xLCD cable (1x) *found in the Electronics & Fasteners package*
 - Main FE cable (1x) *found in the Electronics & Fasteners package*

KROK 40 Guiding the LCD cable




- Guide the Stepper splitter cable through the oval hole to the electronics.
- Take the end of the xLCD cable with the QR code label.
- Push a few centimeters of the xLCD cable (the end with the QR code label) through the oval hole in the bottom panel.
- ❗ The cable must be slightly folded to pass through the hole.
- Guide the xLCD cable through the zip ties on the left side of the frame.
- Poprowadź przewód xLCD przez prostokątny otwór w przednim profilu. Powinien on wystawać na około 6 cm (2,36 cala).
- Pozostaw przewód luźny na tym etapie.

KROK 41 Main FE cable INFO



- Lay out the Main FE cable as shown in the picture, ensuring each connector is positioned accordingly.
- The connectors are numbered in the picture for reference only. This numbering will be used in the following steps to help with proper connections.
- ❗ Note: We will always indicate which connector to use in the following steps. However, it's a good idea to remember this overview for easier assembly.

KROK 42 Connecting the FE cable (no 3.)




- Prepare the connector number 3.
 - ⓘ That's the female faston connector in the middle of the cable.
- Locate the male Faston connector in the bottom right corner.
- Slide the FE cable connector completely onto the Faston connector.

KROK 43 Guiding the FE cable (no. 2)




- Take the FE cable connector number 2.
 - ⓘ The round connector nearby.
- Insert the connector loosely into the hole in the bottom panel.

KROK 44 Guiding the FE cable (no. 1)




- Take the connector number 1 and guide it through the zip ties on the right side of the frame.
- ❗ That is the long part with just one faston connector at the end.
- Push the connector through the rectangular opening in the front profile. Keep protruding approximately 6 cm (2.36 in).
- Leave the cable hang freely for now.
- Tighten all three zip ties. Cut off the excess.

KROK 45 Guiding the FE cable (no. 4 and 5)



- Take the FE cable connectors number 4 and 5.
- Push both connectors through the leftmost hole in the bottom. Leave them free for now.
- Tighten all three zip ties on the left side of the frame. Cut off the excess.
- There's no need to fully tighten the zip ties. However, the cables must still be easy to move for any necessary length adjustment during connection.
- Carefully turn the printer back on its feet. Focus on the back side.

KROK 46 FE cable - xBuddy: parts preparation



● For the following steps, please prepare:

● Podkładka M3w (1x)

● Śruba M3x6 (1x)

KROK 47 Connecting the FE cable: xBuddy




- Take the connector number 4 and connect it to the xBuddy using the M3x6 screw and M3w washer.

⚠ The M3 washer must be between the screw head and the connector.


- Guide the FE cable (number 5) alongside the xBuddy box and pass it through the right-side holes out of the box.
- Guide the Stepper splitter cable alongside the xBuddy box and connect it to the second slot from the right in the top row on the xBuddy board (labeled ZR).

KROK 48 Plugging the xLCD cable




- ◆ Arrange the cables as shown - route all cables along the right side of the xBuddy box.
- ⚠ Make sure all the cables guide through the zip ties in the xBuddy box, not under them.
- ◆ Place the xLCD cable over the other cables and route it upwards.
- ◆ Connect the xLCD to the slot on the right side of the xBuddy. **Note the safety latch on the xLCD cable connector. The latch must fit into the upper side of the connector.**
- ◆ Secure the cable arrangement by tightening the bottom zip tie.
- ⚠ **Nie zaciskaj opasek zbyt mocno, aby nie uszkodzić przewodów.**
- ◆ Ostrożnie odetnij nadmiar opaski zaciskowej. **Uważaj, aby nie przeciąć przewodów!**

KROK 49 Pokrywa zasilacza: przygotowanie części




- ◆ For the following steps, please prepare:
- ◆ CORE-One-PSU-cover (1x) found in the Printed parts package
- ◆ Śruba M3x10 (2x)

KROK 50 Connecting the FE cable: PSU



- ◆ Remove the screw from the PSU board. **Do not discard it!**
- ◆ Ensure the FE connector (number 2) is routed into the PSU compartment.
- ◆ Insert the removed screw through the FE cable connector and screw it back to the PSU board.
- ◆ Note the correct orientation of the connector.
- ◆ Rotate the connector counter-clockwise, positioning it so it doesn't block the threaded hole underneath.
- ◆ Załóż pokrywę zasilacza [CORE-One-PSU-cover] na złącza i przymocuj ją dwiema śrubami M3x10.

KROK 51 Czas na Haribo




- ◆ Time to recharge for the next chapter!
- ◆ Eat the second row.
- ⚠ **No cheating**—eat only the number shown!

KROK 52 Gotowe



- Congratulations! The back assembly is installed.
- Now continue to the next chapter.

4. Montaż stołu grzewczego




KROK 1 Narzędzia niezbędne w tym rozdziale



● **For this chapter, please prepare:**

- Szczypce spiczaste
- Klucz uniwersalny
- Klucz 13-16
- Wkrętak krzyżakowy PH2
- Klucz imbusowy 2,5 mm
- Klucz imbusowy 2 mm
- Klucz / wkrętak Torx T10


KROK 2 Stół grzewczy: przygotowanie części



For the following step please prepare:


- Heatbed MK52 24V (1x) found in the CoreXY parts + Hinges set package
- Heatbed cable red (1x) found in the Electronics & Fasteners package
- Heatbed cable black (1x) found in the Electronics & Fasteners package
- Śruba M3x10rT (2x)
- Nakrętka samokontrująca M3nN (2x)
- Podkładka M3w (2x)

KROK 3 Montaż przewodów stołu grzewczego (część 1)




- IT IS IMPORTANT** to connect the power cable correctly. Before you start the assembly have a look at the pins. The one on the left with "GND" sign must be connected to the **BLACK WIRE**.
- Take both Heatbed cables. Note the label on each cable. For the following steps, prepare the ends of the cables **without the label**.

KROK 4 Montaż przewodów stołu grzewczego (część 2)




- ✿ Place the black wire above the pin with "GND" sign. **Use the end of the cable that is not labeled with QR code.** The QR code must be at the other end.
- ✿ Note the correct position of the cable terminal lug on the detail.
- ✿ Place the M3w washer above the round cable connector.
- ✿ Push the M3x10rT screw through all parts.
- ✿ Hold the screw and carefully turn the heatbed upside down.
- ✿ Załóż nakrętkę M3nN na śrubę M3x10rT i dokręć lekko.
- ✿ Postępując w ten sam sposób, podłącz czerwony przewód do padu oznaczonego "VCC" na stole grzewczym.
- ✿ Ułóż przewody stołu grzewczego lekko do siebie (w kształcie litery „V”). **Następnie mocno dokręć nakrętki od spodu.**

KROK 5 Dolna pokrywa przewodów stołu: przygotowanie części



- ✿ **For the following steps, please prepare:**
- ✿ Bed-cable-cover-bottom [dolna pokrywa przewodów stołu] (1x)
- ✿ Nakrętka M3n (3x)
- ✿ Śruba M3x10rT (1x)

KROK 6 Montaż pokrywy przewodów




- ✿ Insert three M3n nuts into the Bed-cable-cover-bottom part.
- ❗ Pro tip: Use the screw-pulling technique.
- ⬛ Make sure the nuts are fully inserted and held in place.
- 🔵 Insert the Bed-cable-cover-bottom under the heatbed cables. Note the orientation of the part.
- 🟠 Slide the Bed-cable-cover-bottom under the cable joint of the heatbed.
- 🟢 Wyrównaj otwór w stole grzewczym z osłoną i przykręć je śrubą M3x10rT.

KROK 7 Rama stołu: przygotowanie części



- ⬛ **For the following steps, please prepare:**
- ✿ Heatbed carriage (1x) *found in the Metal parts 1/3 package*
- 🟠 Expansion joint (8x) *found in the Electronics package*
- 🟢 Śruba M3x4r (8x)
- 📌 The Fasteners package includes both M3x4r and M3x4rT screws. Make sure you have the correct type prepared.

KROK 8 Przygotowanie ramy stołu




- Place the heatbed carriage in front of you in the same orientation as in the picture.
- Make sure the **rectangular cutout is facing you on the right side**.
- Insert eight M3x4r screws around the heatbed carriage.
- ⚠ **Do not tighten completely, leave a gap of approximately 3 mm (0.12 in).**

KROK 9 Montaż złączy kompensacyjnych



- Attach one expansion joint to any M3x4r screw in the same orientation as shown.
- Note the U-shaped "groove" for the screw inside the expansion joint - point it towards the screw.
- Slide the expansion joint onto the screw.
- Grasp the expansion joint in the rectangular cutout of the universal wrench.
- Position the key with the expansion joint in its correct orientation as shown in the illustration.
- **Utrzymaj pozycję złącza kompensacyjnego i mocno dokręć śrubę M3x4r przez otwór w złączu, używając klucza imbusowego 2,0 mm.**
- ⚠ **Powtórz to samo dla wszystkich pozostałych złączy kompensacyjnych. Zwróć szczególną uwagę na ich prawidłową pozycję!**

KROK 10 Taśma LED RGB: przygotowanie części



■ **For the following steps, please prepare:**


- RGB LED strip 166 mm (1x) *found in the Electronics & Fasteners package*
- ⚠ **Avoid direct contact with the LED and resistors on the LED strip.**
- LED status cover (1x) *found in the Electronics & Chamber parts package*
- LED strip diffuser (1x) *found in the CoreXY parts + Hinges set package*
- Tulejka dystansowa 3,2/6x5 mm (2x) *znajdują się w pakiecie Electronics & Fasteners*
- Śruba M3x10rT (2x)
- Opaska zaciskowa (3x)

KROK 11 Montaż taśmy LED




- Place the heatbed carriage in front of you in the same orientation as in the picture.
- Make sure the **rectangular cutout is far from you and on the right side.**
- Carefully peel off the protective (paper) layer from the RGB LED strip.
- ⚠ **After removing the protective layer, the RGB LED strip is adhesive.**
- Stick the RGB LED strip evenly to the front of the heatbed carriage, approximately 3 mm (0.12 in) from the folded edge.
Align the middle LED with the screw on the carriage.
- **Przewód taśmy LED RGB musi być skierowany w prawo.**
- Po przyklejeniu lekko dociśnij obszary taśmy bez komponentów elektronicznych.
Nie dotykaj diod LED i rezystorów!

KROK 12 Montaż dyfuzora LED




- Place the LED strip diffuser over the RGB LED strip. Note the orientation of the part - according to the beveled edges.
- Place two spacers 3.2/6x5 mm on the holes in the edges of the LED assembly.

KROK 13 Przykrycie taśmy LED RGB




- From both sides of the LED status cover, peel off the protective layers.
- Note that one side of the cover is matte.
- Druga strona pokrywy jest błyszcząca.
- Attach the LED strip cover to the assembly, **matte side up**.
- Secure all parts together by inserting and tightening two M3x10rT screws. **Do not overtighten the screws**, as it may crack the cover.

KROK 14 Ułożenie przewodu LED RGB




- ✦ Thread the three zip ties along the **RIGHT SIDE** of the heatbed carriage. Make sure the zip tie heads are facing outward.
- ✦ Guide the RGB LED strip cable through all zip ties.
- ✦ Następnie zaciśnij wszystkie trzy opaski zaciskowe i odetnij ich nadmiar.

KROK 15 Mocowania stołu: przygotowanie części



- ⬢ **For the following steps, please prepare:**
- ✦ CORE-One-bed-mount-left (1x) *found in the Printed parts package*
- ✦ CORE-One-bed-mount-right (1x) *found in the Printed parts package*
- ✦ CORE-One-bed-spacer-rear (1x) *found in the Printed parts package*
- ✦ LM8UU bearing (2x) *found in the Electronics package*
- ⓘ Łożyska w zestawie są zapakowane w niebieskie torebki.
- ✦ Śruba M3x10 (6x)
- ✦ Nakrętka M3n (2x)
- ✦ Nakrętka M3n (10x)

KROK 16 Montaż mocowań stołu



- Place the CORE-One-bed-mount-left onto the bearing, ensuring the correct orientation.
- Press the part onto the bearing, applying more force to ensure it moves all the way down. You will feel a click, indicating that the plastic part and bearing are correctly seated.
- ⚠ The bearing must be fully enclosed within the part and must not protrude.
- Follow the same procedure with CORE-One-bed-mount-right.

KROK 17 Przykręcenie mocowań stołu



- Insert one M3n nut into the CORE-One-bed-mount-left.
- Position the CORE-One-bed-mount-left according to the picture:
 - Position the bearing so that two ball rows face the bottom of the part, not just one.
- Keep the bearing in the position and secure it by inserting and tightening one M3x10 screw.
- ⚠ Ensure that the top surface of the bearing is flush with the top surface of the plastic part.
- Zrób to samo z prawym mocowaniem [CORE-One-bed-mount-right].

KROK 18 Mocowania stołu: nakrętki



- Insert four M3nN nuts into both bed mounts.
- Make sure they are inserted completely inside.

KROK 19 Montaż tylnego elementu dystansowego



- Insert two M3nN nuts into the CORE-One-bed-spacer-rear.
- Insert the nuts down as much as possible.

KROK 20 Montaż prawego mocowania stołu




- Turn the heatbed carriage piece with the "forks" facing you and with the **expansion joints facing up**.
- Take the CORE-One-bed-mount-**right** part and slide it **under the right fork** - with the bearing on the right.
- Fix it with two M3x10 screws.

KROK 21 Montaż lewego mocowania stołu




- Take the One-bed-mount-**left** part and slide it **under** the **left** fork - with the bearing on the left.
- Fix it with two M3x10 screws.

KROK 22 Montaż stołu grzewczego: przygotowanie części




- For the following steps, please prepare:
- M3x12bT countersunk screw (1x)
- i** Note: The package may label this screw as M3x12cT.
- Spacer 6x3.1x8 mm (1x) *found in the Nextruder assembly package*
- M3x4bT countersunk screw (8x)

KROK 23 Montaż stołu grzewczego




- Place the spacer onto the heatbed carriage on the side with the expansion joints and align it with the hole in the center.
- Put the heatbed on the heatbed carriage and secure it by the M3x12bT. **Do not fully tighten the screw yet.**
 - Make sure the heatbed thermistor cable (the thinnest pair) is routed alongside the heatbed power cables. Do not route it around or across any expansion joints.
- ⚠ **Ensure the correct orientation of the part. Use the heatbed cables as a guide.**
- Insert the M3x4bT screws into the remaining holes in the heatbed. **Do not fully tighten the screws yet.**

KROK 24 Przykręcenie stołu grzewczego



- ⚠ **IMPORTANT:** The heatbed must be tightened in a specific order. Repeat the sequence multiple times, ensuring the final tightening after at least two rounds.
- After all screws are in place, tighten them in the following sequence:
 - Śruba centralna
 - First four screws (edges)
 - Last four screws (corners)
- ⚠ **Dokręć śruby mocno, ale z wyczuciem.**


KROK 25 Osłona przewodów: przygotowanie części



■ For the following steps, please prepare:


- CORE-One-bed-cable-cover-top (1x) found in the Printed parts package
- Śruba M3x10 (2x)
- Owijka tekstylna 520 x 8 mm (1x) znajduje się w pakiecie Electronics & Chamber parts

KROK 26 Organizacja przewodów stołu grzewczego



- Pull the RGB LED strip cable from the bottom through the rectangular cutout to the top.
- Guide the heatbed thermistor cable under the RGB LED cable, and insert the heatbed thermistor cable into the cable channel in the cable cover.
- Route the RGB LED strip cable through the cable channel.
- Guide the heatbed power cables through the cable channel.

KROK 27 Montaż pokrywy przewodów stołu grzewczego



- ◆ Thread approximately 5 cm (2 in) of the textile sleeve onto the heatbed cable bundle and slide the textile sleeve 1 cm (0.39 in) into the cable channel.
- ◆ Attach the CORE-One-bed-cable-cover-top on the heatbed cables.
- ◆ Make sure the textile sleeve is still in place - inside the cable cover. **Do not pull on the textile sleeve.**
- ◆ Secure the top cover with two M3x10 screws.
- ◆ Wrap the rest of the textile sleeve around the cable bundle.

KROK 28 Montaż stołu grzewczego: przygotowanie części




◆ For the following steps, please prepare:

◆ Nakrętka trapezowa (3x)

ⓘ Two trapezoidal nuts are included in the motors set package, and one nut can be found in the Electronics & Chamber parts package.


◆ Śruba M3x18 (6x)

KROK 29 Przymocowanie stołu grzewczego



- Take the back and base assembly and orient the front side towards you.
- Place the CORE-One-bed-spacer-rear onto the rear motor screw heads, making sure it stays in place.
 - ⚠ Note the orientation of the part and holes as shown. The holes must be parallel to the motor screw heads.
- Very carefully thread the heatbed assembly onto the threaded rods of the Z motors, then gently lay it down onto the base.
 - ⚠ Keep in mind that there is a spacer on the rear motor. Avoid the spacer by the heatbed cable.
- Przewody stołu grzewczego muszą przebiegać **pod stołem** oraz **za tylnym silnikiem**.

KROK 30 Mounting the heatbed assembly: rear motor



- ❖ Ensure the heatbed assembly is seated correctly—all threaded rods pass through the correct holes.
- ❖ Double-check that the heatbed cable bundle (textile sleeve) runs properly—it **must go under the heatbed assembly** and **behind the threaded rod** of the rear motor.
- ❖ Manually thread the trapezoidal nut onto the rear Z motor. Screw the nut all the way down until it seats into the heatbed carriage.
 - ⚠ Ensure the correct orientation of the part. **The protruding section must face downwards.**
- ❖ Align the holes in the trapezoidal nut, carriage and bed-spacer-rear.
 - i Nie ma znaczenia, które otwory wykorzystasz w nakrętce trapezowej.
 - i Wskazówka: Możesz przełożyć klucz imbusowy 1,5 mm przez otwory we wszystkich częściach, aby je wyrównać.
- ❖ Przykręć nakrętkę trapezową, ramę stołu grzewczego i tylny element dystansowy dwoma śrubami M3x18.

KROK 31 Mounting the heatbed assembly: front motor left




- ❖ Manually thread the trapezoidal nut onto the **left** Z motor. Screw the nut all the way down until it seats into the plastic part.
 - ⚠ Ensure the correct orientation of the part. **The protruding section must face downwards.**
- ❖ Align the holes in the trapezoidal nut with those in the plastic part. Either pair of holes can be used.
- ❖ Secure all the part together with two M3x18 screws.

KROK 32 Mounting the heatbed assembly: front motor right




- Manually thread the trapezoidal nut onto the **right** Z motor. Screw the nut all the way down until it seats into the plastic part.
- ⚠ Ensure the correct orientation of the part. **The protruding section must face downwards.**
- Align the holes in the trapezoidal nut with those in the plastic part. Either pair of holes can be used.
- Secure all the part together with two M3x18 screws.

KROK 33 Attaching the heatbed cables I.




- Locate the grommet hole at the top right of the rear assembly and push the heatbed cables through in the following order:
 - Guide the RGB LED strip cable through the hole first.
 - Route the thermistor cable through the hole.
 - Finally, insert both power cables of the hole.

KROK 34 Attaching the heatbed cables II.




- Push the heatbed cables and the textile sleeve through the grommet hole.
- ⬛ No more than 1 cm (0.39 in) of the textile sleeve should protrude from the back side.

KROK 35 Securing the heatbed cables: parts preparation




- ⬛ **For the following steps, please prepare:**
- Opaska zaciskowa (1x)
- Power terminal screw 6-32 (2x)

KROK 36 Securing the textile sleeve




- Guide the zip tie through the two holes under the heatbed cables and make a loop around the heatbed cable bundle (textile sleeve) on the inside.
- Tighten the zip tie firmly and cut off the excess.

KROK 37 Guiding the heatbed assembly cables




- Route the RGB LED strip cable through the left hole in the xBuddy box and connect it to the xBuddy Extension board labeled 'RGBW LED.'
- Connect it to the first slot from the right on the xBuddy extension board.
- Guide the heatbed power cables along with the thermistor through the left hole. Leave the cables hanging freely for now.

KROK 38 Connecting the heatbed power cables



- Ensure that none of the heatbed cables run over the zip ties—they must be guided underneath.
- Using the 6/32" terminal screw connect the **black** power cable to the **left** terminal slot on the xBuddy board. Tighten firmly.
- Using the 6/32" terminal screw to connect the **red** power cable to the **right** terminal slot. Tighten firmly.
- Plug the heatbed thermistor connector to the slot next to the power terminals.

KROK 39 Czas na Haribo




- Time for another quick energy boost!
- Eat the third row.
 - With one extra treat. You deserve it!

KROK 40 Gotowe



- ◆ Congratulations! You have just assembled and installed the heatbed.
- ◆ Let's go to the next chapter.

5. Montaż CoreXY




KROK 1 Tools necessary for this chapter




- **For this chapter, please prepare:**
- Szczypce spiczaste
- Klucz imbusowy 2 mm
- Klucz imbusowy 2,5 mm
- T10 torx key / T10 torxy screwdriver

KROK 2 Rod holders: parts preparation




- **For the following steps, please prepare:**
- Rod holder left (1x) *found in the CORE XY parts + hinges + HB set package*
- Rod holder right (1x) *found in the CORE XY parts + hinges + HB set package*
- Rod holder rear (2x) *found in the CORE XY parts + hinges + HB set package*
- Śruba M3x10 (6x)
- Śruba M3x6 (4x)
- CoreXY plate (1x) *found in the Metal parts 1/3 package*

KROK 3 Assembling the rod holders




- Insert two M3x10 screws into the Rod holder left and two into the Rod holder right.
- **Do not tighten them completely**, a few turns are enough for now.
- Insert one M3x10 screw into each Rod holder rear. Insert from the **side with the screw head hole**.
- **Do not tighten them completely**, a few turns are enough for now.

KROK 4 Preparing the front rod holders



- Place the CoreXY plate as shown - the **bent parts of the plate must point upwards**.
- Divide the Rod holder left and the Rod holder right into the sides of the front:
 - ⚠ **Ensure you are preparing the correct part for the correct side. Use the chamfers on both parts as a reference for alignment.**
 - Lewy uchwyt pręta
 - Prawy uchwyt pręta

KROK 5 Installing the front rod holders




- 🟢 Place the Rod holder left to the left front corner on the corresponding threaded holes.
- 🟠 Secure it with two M3x6 screws.
- 🟡 Place the Rod holder right to the right front corner on the corresponding threaded holes.
- 🟣 Secure it with two M3x6 screws.

KROK 6 XY carriage: parts preparation




- ⬛ **For the following steps, please prepare:**
- 🟡 Linear holder left (1x) *found in the Metal parts 1/3 package*
 - 🔴 Linear holder right (1x) *found in the Metal parts 1/3 package*
 - 🟢 XY-carriage (2x) *found in the Printed parts package*
 - 🟣 LM10LUU linear bearing (2x) *found in the CORE XY parts + hinges + HB set package*
 - 🔵 GT2-20 Idler pulley (4x) *found in the Electronics & Fasteners package*
 - 🟠 M3x8rT black screw (8x)
 - 🟡 Śruba M3x18 (10x)

KROK 7 Montaż wózków XY




- ◆ Take one of the XY-carriage and orient it as shown. Use the beveled side as a guide.
- ◆ Insert the GT2-20 Idler pulley into the XY-carriage.
- ◆ Push one M3x18 screw through the pulley and tighten it completely down.
- ◆ Turn the part upside down.
- ◆ Insert another GT2-20 Idler pulley into the XY-carriage.
- ◆ Secure it with the M3x18 screw. Tighten it completely down.
- ◆ Repeat the same procedure with the second XY-carriage.

KROK 8 Assembling the linear holder left




- ◆ Prepare the Linear holder **left** and position it as in the picture.
- ◆ Attach one of the XY-carriages to the Linear holder.
- ◆ Przykręć go do uchwyty liniowego trzema śrubami M3x18.
- ◆ Turn the Linear holder upside down.
- ◆ From the XY-carriage side, attach the LM10LUU linear bearing to the holder and secure it with four M3x8rT screws.

KROK 9 Assembling the linear holder right




- Prepare the Linear holder **right** and position it as in the picture.
- Attach one of the XY-carriages to the Linear holder.
- Przykręć go do uchwyty liniowego trzema śrubami M3x18.
- Turn the Linear holder upside down.
- From the XY-carriage side, attach the LM10LUU linear bearing to the holder and secure it with four M3x8rT screws.

KROK 10 Attaching the linear holder assemblies



- Position the CoreXY plate as shown in the picture, ensuring the front rod holders are facing up.
- Slightly lift the CoreXY plate and from the plate's inner side loosely attach the Linear holder of the assemblies.
- **Lewy uchwyt liniowy**
- **Prawy uchwyt liniowy**
- ① The linear holders are now only loosely seated.

KROK 11 Info o prętach liniowych



- There are two different types of smooth rods in the package. Compare carefully with the picture and prepare the correct ones required.

i Smooth rods are included in the Rods box.

Smooth rod 330 x 8 mm (2x)

Smooth rod 325 x 10 mm (2x) **required for the following steps**

- For the following steps, please prepare:**


Śruba M3x6 (4x)

KROK 12 Mounting the smooth rods




- Slide both rear rod holders onto both 10mm smooth rods.
- Line up the ends of the rods with the holders.
- Push both 10mm smooth rods through the LM10LUU bearing to the front rod holders.
- Make sure the screws on the rear rod holders are pointing out of the frame.
- Line up the front end of the 10mm smooth rods with the front rod holders.

KROK 13 Securing the rear rod holders




- Line up the left rear rod holder with the threaded holes in the plate.
- Fix it with two M3x6 screws.
- Firmly tighten the screw in the rod holder.
- Line up the right rear rod holder with the threaded holes in the plate.
- Fix it with two M3x6 screws.
- Firmly tighten the screw in the rod holder.

KROK 14 Securing the front rod holders



- Skup się na przednim lewym uchwycie (teraz po prawej stronie) i zamocuj pręt, dokręcając śrubę.
- ⚠ **Do not tighten the bottom screw.**
- Skup się na przednim prawym uchwycie (teraz po lewej stronie) i zamocuj pręt, dokręcając śrubę.
- ⚠ **Do not tighten the bottom screw.**


KROK 15 Motor mounts: parts preparation



■ **For the following steps, please prepare:**

- XY-motor-mount-left (1x) *found in the Printed parts package*
 - XY-motor-mount-right (1x) *found in the Printed parts package*
 - Assembly-multi-tool (1x) *you already used*
 - Śruba M3x30 (2x)
 - Śruba M3x18 (2x)
 - Spacer 3.2/6x2 (2x) *found in the Electronics & Fasteners package*
 - Nakrętka kwadratowa M3nS (1x)
- ❗ The list continues in the next step...

KROK 16 Motor mounts: part preparation




- GT2-20 Idler pulley (6x) *found in the Electronics & Fasteners package*

KROK 17 Assembling the XY-motor-mount-right I.



- ✿ Umieść jedno koło pasowe w dolnej pozycji multitoola montażowego.
- ✿ Insert the spacer 3.2 on the pulley.
- ✿ Umieść drugie koło pasowe w multitoole montażowym.
- ✿ Insert the whole assembly into the XY-motor-mount-right.
 - ⬛ Position the part according to the picture. Note the beveled corner.
- ✿ Align holes in both parts and secure it with the M3x30 screw.
 - 🔧 Plastikowa część nie ma gwintu, więc śruba natnie go podczas dokręcania. Spodziewany jest niewielki opór.
- ✿ Wyciągnij multitool.

KROK 18 Assembling the XY-motor-mount-right II.



- ✿ Insert another pulley into the XY-motor-mount-right.
- ✿ Secure it with M3x18 screw.
 - ⓘ Plastikowa część nie ma gwintu, więc śruba natnie go podczas dokręcania. Spodziewany jest niewielki opór.
- ✿ Insert the M3nS nut into the XY-motor-mount-right.


KROK 19 Assembling the XY-motor-mount-left I.

- ✿ Umieść jedno koło pasowe w dolnej pozycji multitoola montażowego.
- ✿ Insert the spacer 3.2 on the pulley.
- ✿ Umieść drugie koło pasowe w multitoole montażowym.
- ✿ Insert the whole assembly into the XY-motor-mount-left.
 - ⬛ Position the part according to the picture. Note the bevel next to the screw hole.
- ✿ Align holes in both parts and secure it with the M3x30 screw.
 - ⓘ Plastikowa część nie ma gwintu, więc śruba natnie go podczas dokręcania. Spodziewany jest niewielki opór.
- ✿ Wyciągnij multitool.

KROK 20 Assembling the XY-motor-mount-left II.

- ✿ Insert another pulley into the part.
- ✿ Secure it with M3x18 screw. **Do not overtighten the screw.**
 - ⓘ Plastikowa część nie ma gwintu, więc śruba natnie go podczas dokręcania. Spodziewany jest niewielki opór.

KROK 21 Belt tensioners: parts preparation I.



For the following steps, please prepare:

GT2-20 Idler pulley (2x) *found in the Electronics package*

Śruba M3x30 (2x)


Śruba M3x18 (2x)

Śruba M3x12 (1x)

Nakrętka kwadratowa M3nS (2x)

i The list continues in the next step...

KROK 22 Belt tensioners: parts preparation II.




For the following steps, please prepare:

Belt-tensioner-left (1x) *found in the Printed parts package*

Belt-tensioner-right (1x) *found in the Printed parts package*

Belt-tensioner-pulley (2x) *found in the Printed parts package*

KROK 23 Koła pasowe napinaczy: przygotowanie części



- ✦ Insert one M3nS nut into each Belt-tensioner-pulley.
- ✦ Upewnij się, że nakrętki są prawidłowo osadzone w częściach. Wszystkie otwory **muszą być wyrównane**.
- ✦ Utrzymaj obie części w tej pozycji.

KROK 24 Assembling the belt tensioner left I.



- ✦ Nałóż niewielką ilość smaru Prusa na końcówki obu śrub M3x30.
- ✦ Rozprowadź smar równomiernie na całym gwincie.
- ⓘ Wskazówka: rozprowadź smar za pomocą końcówki opaski zaciskowej.
- ✦ Slide the Belt-tensioner-**left** onto the Belt-tensioner-pulley.
- ✦ **Ensure the parts are oriented correctly**, as shown.
- ✦ Wsuń śrubę M3x30 przez napinacz paska - lewy [Belt-tensioner-left] do uchwytu kółka napinającego [Belt-tensioner-pulley]. **Nie dokręcaj do końca!** Wystarczą 3-4 obroty.

KROK 25 Assembling the belt tensioner left II.




- Insert the GT2-20 Idler pulley into the Belt-tensioner-pulley.
- Secure it with the M3x18 screw.
 - i Plastikowa część nie ma gwintu, więc śruba natnie go podczas dokręcania. Spodziewany jest niewielki opór.
- Insert the M3x12 screw into the Belt-tensioner-left. Tighten slightly—five turns are enough. It must not protrude through the other side.
 - i Note: This screw, referred to as the tensioning screw, will later be used to adjust the door sensor.

KROK 26 Assembling the belt tensioner right



- Slide the Belt-tensioner-**right** onto the Belt-tensioner-pulley.
 - **Ensure the parts are oriented correctly**, as shown.
- Wsuń śrubę M3x30 przez napinacz paska - prawy [Belt-tensioner-right] do uchwyty kółka napinającego [Belt-tensioner-pulley]. **Nie dokręcaj do końca!** Wystarczą 3-4 obroty.
- Insert the GT2-20 Idler pulley pulley into the Belt-tensioner-pulley-right.
- Secure it with the M3x18 screw.
 - i Plastikowa część nie ma gwintu, więc śruba natnie go podczas dokręcania. Spodziewany jest niewielki opór.


KROK 27 Installing the belt tensioners: parts preparation



● For the following steps, please prepare:


- Śruba M3x30 (5x)
- Śruba M3x18 (1x)
- Śruba M3x6 (2x)
- Belt tensioner left assembly (1x) *you assembled earlier*
- Belt tensioner right assembly (1x) *you assembled earlier*

KROK 28 Installing the motor mount left




- Locate the corner of the CoreXY plate with the Faston connector on it. It is on the underside of the assembly.
- Position the motor-mount-**left** on the CoreXY plate as shown in the picture.
- Note the rectangular protrusion on the motor-mount-left and the rectangular cutout on the CoreXY plate.
- Wsuń lewe mocowanie silnika [motor-mount-left] pod płytę CoreXY, upewniając się, że prostokątny występ pasuje do wycięcia.
- Align the holes in both parts and secure them with an M3x6 screw in the designated hole

KROK 29 Installing the motor mount right




- ◆ Position the motor-mount-**right** on the CoreXY plate as shown in the picture.
- ◆ Zwróć uwagę na prostokątny występ na prawym mocowaniu silnika [motor-mount-right] i prostokątne wycięcie na płycie CoreXY.
- ◆ Wsuń prawe mocowanie silnika [motor-mount-right] pod płytę CoreXY, upewniając się, że prostokątny występ pasuje do wycięcia.
- ◆ Align the holes in both parts and secure them with an M3x6 screw in the designated hole

KROK 30 Montaż lewego napinacza paska




- ◆ Turn the CoreXY assembly upside down so that the bent parts face downward. Focus on the front left corner on the assembly.
- ◆ Place the belt-tensioner-**left** assembly in the front left corner of the CoreXY plate. Align it with the front and inner side edges.
- ◆ Line up the holes in both parts.
- ◆ Secure the part with two M3x30 screws.
- ◆ Insert and tighten one M3x18 screw.

KROK 31 Montaż prawego napinacza paska




- Place the belt-tensioner-**right** assembly in the front right corner. Align it with the front and inner side edges.
- Line up the holes in both parts.
- Secure the part with three M3x30 screws.

KROK 32 Linear rail: parts preparation



- For the following steps, please prepare:
 - Śruba M3x6 (6x)
 - Linear rail beam (1x) *found in the Metal parts 3/3 package*
 - Linear rail (1x) *found in the Electronics & Chamber parts package*
- ⚠ **Under no circumstances remove the green anti-ejection safety pins.** Wait for the prompt in the instructions.
- Piece of cloth or a paper towels to wipe the preservative lubricant from the linear guide.


KROK 33 Attaching the linear rail



⚠ Under no circumstances remove the green anti-ejection safety pins. Wait for the prompt in the instructions.

- ✎ Immediately after removing the linear guide from the package, wipe off the preservative lubricant with a paper towel.
- 🔵 Place the linear rail on the linear rail beam and line up the holes in both parts.
- 🟠 Insert and slightly tighten two M3x6 screws into the third holes from both ends.
- 🟢 Move the linear carriage approximately to the center of the rail.

KROK 34 Securing the linear rail



⚠ Do not move the linear carriage in any way in this step.

- 🔵 Relocate the safety pins from each end to the fourth holes from the ends of the linear rail.
- ⬛ Gently squeeze the safety pin with needle-nose pliers and pull it out.
- 🔵 Insert two M3x6 screws into the fifth holes from the ends of the rail. **Tighten just slightly.**
- 🟠 Insert two M3x6 screws into the first holes in the rail. **Tighten just slightly.**

⚠ Do not remove the safety pins from the rail.

KROK 35 Installing the linear rail: parts preparation



For the following steps, please prepare:

Śruba M3x8rT (6x)

i There are both M3x8rT and M3x8 screws in the kit. Make sure you have prepared the correct ones.

Linear rail assembly (1x) *you assembled earlier*

! Do not remove the safety pins.

KROK 36 Installing the linear rail assembly




Position the assembly with the motor mounts facing you.

Move both linear holders approximately to the center of the Y-axis.

Attach the linear rail assembly to the holders from the front side of the assembly.


Secure it with three M3x8rT screws from the back side on both the left and right sides.

KROK 37 Linear rail: removing the safety pins



- ◆ Gently squeeze both safety pins with needle-nose pliers and pull them out of the linear rail.
- i You can discard the safety pins as they are no longer needed.

KROK 38 Ogranicznik stołu: przygotowanie części



- ◆ **For the following steps, please prepare:**
- ◆ Bed-stop-rear (1x) *found in the Printed parts package*
- ◆ Nakrętka kwadratowa M3nS (3x)
- ◆ Śruba M3x8rT (3x)

KROK 39 Montaż ogranicznika stołu




- ◆ Insert two M3nS nuts into the bed-stop from one side.
- ◆ Insert one M3nS nut into the bed-stop from the other side.

KROK 40 Montaż ogranicznika stołu



- Position the CoreXY assembly as shown, ensuring the motor mounts face upwards.
- Focus on the triangle protrusion on the metal part.
- Insert the bed-stop-rear **under** the protrusion at the back of the CoreXY plate.
- Align all three holes in both parts.
- Secure both parts together with three M3x8T screws.
- i** The upper screw is screwed into plastic with no pre-cut thread. It cuts the thread as it's tightened. Slight resistance is expected.

KROK 41 X&Y motors: parts preparation



- For the following steps, please prepare:**
- Y-axis motor (1x) *found in the Motors package*
- X-axis motor (1x) *found in the Motors package*
- i** Note that the motors are marked as X and Y-axes in order to distinguish between them. We will continue to follow this marking.
- Pulley T16-2GT (2x) *found in the Electronics package*
- Assembly-multi-tool (1x) *you already used*

KROK 42 Installing the X-axis pulley



- ⬢ Prepare the **X-axis** motor.
- ⬢ Note the flat part on the motor shaft.
- ⚠ Slide the Pulley on, **note the CORRECT orientation.**
- ⬢ Rotate the motor shaft with the flat part facing you.
- ⬢ Using the fork on the Assembly-multi-tool set a gap between the pulley and the motor.
- ⬢ Push the pulley on the tool and firmly tighten the screw against the flat part on the shaft.
- ⬢ Rotate the pulley and firmly tighten the second grub screw.
- ⚠ **Sprawdź dokładnie orientację kółka pasowego. Strona z ząbkami musi znajdować się bliżej silnika.**

KROK 43 Installing the Y-axis pulley

- Prepare the **Y-axis** motor.
- Note the flat part on the motor shaft. Rotate the motor shaft with the flat part facing you.
- ⚠ **Wsuń koło pasowe zębate na wałek, zwracając uwagę na **WŁAŚCIWY** kierunek. Orientacja koła pasowego osi Y jest INNA niż osi X. Upewnij się, że zęby koła pasowego są oddalone od silnika. Użyj szerszego haka multitoola montażowego.**
- Wykorzystaj hak na multiitoolu montażowym i ustaw grubszą część między kołem pasowym, a silnikiem.
- ⚠ **Nie próbuj zaczepiać go wokół wałka.** Po prostu oprzyj przyrząd o silnik i upewnij się, że końcówka haka wsuwa się między niego, a koło pasowe.
- Push the pulley on the tool and firmly tighten the screw against the flat part on the shaft.
- Rotate the pulley and firmly tighten the second grub screw.
- ⚠ **Sprawdź dokładnie orientację koła pasowego. Zęby muszą być skierowane w stronę przeciwną do silnika.**

KROK 44 XY belts: parts preparation



■ **For the following steps, please prepare:**

- X-axis motor assembly (1x) *you assembled earlier*
- Y-axis motor assembly (1x) *you assembled earlier*
- Nexttruder holder (1x) *found in the CORE XY parts + hinges + HB set package*
- XY belt (2x) *found in the CORE XY parts + hinges + HB set package*
- Śruba M3x35 (8x)

KROK 45 Info o paskach XY




❗ The next steps cover belt installation and guiding on the core XY assembly. Before starting, refer to the illustration for an overview and better understanding of each belt's path.

- X-axis belt - at the **top position**
- Y-axis belt - at the **bottom position**


■ Let's guide the belts step by step...

KROK 46 Y belt guiding: Y motor pulley




- From the back of the CoreXY, focus on the motor-mount on the **left** side.
- Create a loop anywhere on the belt so the **belt teeth are pointing inside** the loop.
- Push this loop through the space between the lower pulleys inside the motor mount.
- Push through enough to make the loop follow the top round hole of the motor-mount as closely as possible.
- Insert the **Y** motor into the motor holder, the pulley must be in the middle of the belt loop.
- Insert the Y motor pulley into the motor mount, ensuring the pulley is centered within the belt loop.
Fully attach the motor to the motor-mount with the motor cable facing you.
- Pull lightly on the belt loop to encircle the pulley.

KROK 47 Securing the Y-axis motor



- Firmly grasp the Y-axis motor assembly and position the CoreXY assembly vertically. **Do not drop the motor!**
- ⚠ Be careful not to pull the entire belt out of the motor.
- Keep holding the motor with one hand. With the other hand, secure the motor using four M3x35 screws on the underside of the frame. **Tighten firmly.**
- Place the CoreXY assembly back into the horizontal position.

KROK 48 Y belt guiding: Y motor mount




- 🟡 Guide the left end of the belt around the lower left pulley.
- 🟣 Push the belt through the part and guide it to the front of the CoreXY plate.
- ⚠️ **Don't pull too long so you don't pull the whole belt out.** Remember that the other end is loose. The whole process would then have to be repeated.

KROK 49 Y belt guiding: belt tensioner




- 🟡 Poprowadź pasek wokół napinacza.
- 🟣 Push the belt around the front pulley in the linear assembly.
- 🟢 Prepare the Nextruder holder in the same orientation as in the picture. Note the holes for securing the belts.
- 🔵 Push the end of the belt through the middle hole into the left hole in the bottom row - leave 4-5 teeth sticking out.
- 📄 The belt is secured on this end. You can leave it free for now.

KROK 50 Y belt guiding: X motor mount




- Back to the other end of the Y belt.
- Take the other end of the belt and guide it around the lower pulley in the X motor mount.
- Push it through the motor mount to the front.
- Route the belt around the lower right pulley in the linear rail holder.

KROK 51 Y belt guiding: securing the belt




- Push the end of the belt through the middle hole to the right hole in the bottom row of the Nextruder holder - leave 4-5 teeth sticking out.
- ⓘ If it is difficult to reach the Nextruder holder with the belt, try loosening the belt tensioner screw on the front of the assembly.
- 📌 Don't forget to adjust it back after securing the belt.

KROK 52 X belt guiding: X motor pulley



- From the back of the CoreXY, focus on the motor-mount on the **right** side.
- Create a loop anywhere on the second belt so the belt teeth are pointing inside the loop.
- Push this loop through the space between the upper pulleys inside the motor mount.
- Push through enough to make the loop follow the top round hole of the motor-mount as closely as possible.
- Insert the **X** motor pulley into the motor mount, ensuring the pulley is centered within the belt loop.
- Ensure the motor cable is facing you (rear).
- Pull lightly on the belt loop to encircle the pulley.

KROK 53 Securing the X-axis motor



- Mocno chwyć zespół silnika osi X i ustaw zespół CoreXY pionowo. **Nie upuść silnika!**
- ⚠ Be careful not to pull the entire belt out of the motor.
- Keep holding the motor with one hand. With the other hand, secure the motor using four M3x35 screws on the underside of the frame. **Tighten firmly.**
- Place the CoreXY assembly back into the horizontal position.

KROK 54 Y belt guiding: X motor mount




- Guide the right end of the belt around the upper right pulley.
- Push the belt through the part and guide it to the front of the CoreXY plate.
- ⚠ **Don't pull too long so you don't pull the whole belt out.** Remember that the other end is loose. The whole process would then have to be repeated.

KROK 55 X belt guiding: belt tensioner




- Poprowadź pasek wokół napinacza.
- Push the belt around the front upper pulley in the linear assembly.
- Route the end of the belt through the middle hole into the right hole - leave 4-5 teeth sticking out.
- ⓘ The belt is secured on this end. You can leave it free for now.

KROK 56 X belt guiding: Y motor mount



- Back to the other end of the X belt.
- Take the other end of the belt and guide it around the upper pulley in the Y motor mount.
- Push the belt through the motor mount.
- Route the belt around the upper front pulley in the linear rail holder.

KROK 57 X belt guiding: securing the belt





- Push the end of the belt through the middle hole to the left hole in the upper row of the Nexttruder holder - leave 4-5 teeth sticking out.

KROK 58 Checking the belt guidance



Przed przejściem do następnego etapu sprawdź prowadzenie paska zgodnie z ilustracją.


KROK 59 Bowden guide: parts preparation



Do kolejnych etapów przygotuj:

-  Bowden-guide (1x) *found in the Printed parts package*
-  Śruba M3x10 (5x)
-  Nakrętka kwadratowa M3nS (1x)
-  Opaska zaciskowa (2x)


KROK 60 Securing the Nextruder holder



- Przymocuj mocowanie Nextrudera do zespołu prowadnicy liniowej i przykręć go czterema śrubami M3x10.


CAUTION: Ensure no belt obstructs the screw. Avoid screwing through the belt!

KROK 61 Securing the Y motor cable




- Przełóż opaskę zaciskową przez mocowanie prawego silnika [motor-mount-right].
- Route the Y motor cable through the cable channel in the motor-mount-right and over the zip tie.
- Secure the cable with a zip tie and trim the excess.

KROK 62 Securing the X motor cable



- ✚ Przełóż opaskę zaciskową przez mocowanie lewego silnika [motor-mount-left].
- ✚ Route the X motor cable through the cable guide in the motor-mount-left and over the zip tie.
- ✚ Secure the cable with a zip tie and trim the excess.

KROK 63 Installing the bowden guide



- ✚ Umieść nakrętkę kwadratową M3nS w prawym mocowaniu silnika [motor-mount-right].
- ✚ Attach the bowden-guide to the motor-mount-right.
- ⚠ Note the correct orientation of the part.
- ✚ Fix the bowden-guide in place using the M3x10 screw.

KROK 64 White LED strip: parts preparation



Do kolejnych etapów przygotuj:

White LED strip (1x) *found in the Electronics & Fasteners package*

CoreXY strut (1x) *found in the Metal parts 1/3 package*

i The part is inserted in a foam cutout and may not be immediately visible at first glance.

Śruba M3x4rT (2x)

KROK 65 Sticking the White LED strip



Ostrożnie odklej warstwę ochronną (papierową) z taśmy White LED.


! After removing the protective layer, the LED strip is adhesive.

Position the White LED strip near the CoreXY strut to check alignment, but **do not attach it yet**.

! Note the rectangular cutout on the strut, orient the strip cable to the same side.

Stick the White LED strip evenly to the strut - on the side with the rectangular cutout.

After sticking, press lightly on the blank areas of the strip to ensure adhesion. **Do not touch LEDs and resistors!**

KROK 66 Installing the white LED assembly

- Weź zespół białej taśmy LED i przymocuj go do przedniej części zespołu CoreXY. Wyrównaj otwory w obu częściach.
- **The white LED strip cable must point to the left.**
- Attach the LED assembly to the CoreXY plate and secure it with two M3x4rT screws.

KROK 67 Door sensor & White LED strip: parts preparation

- **Do kolejnych etapów przygotuj:**
- Door sensor (1x) *found in Electronics and fasteners package*
- M2.5x10 screw (1x) *silver*
- Opaska zaciskowa (4x)

KROK 68 Inserting the zip ties




- ❖ Odwróć zespół CoreXY do góry nogami i oprzyj go na silnikach.
- ❖ Position it with the white LED strip cable facing toward you.
- ❖ Thread three zip ties through the CoreXY plate, ensuring the zip tie heads point inward. **Make sure that the zip ties do not catch the belts from the other side.**
- ❖ Partially tighten the zip ties—just enough to catch the first few teeth.
- ⚠ **Do not fully secure them yet, as we will route cables through them later.**
- ❖ Flip the assembly back with the motors facing upwards.

KROK 69 Installing the door sensor



- ❖ Umieść czujnik drzwi na lewym napinaczu paska. Dźwignia czujnika musi być skierowana do przodu.
- ❖ Secure the door sensor with the M2.5x10 screw.
- ❖ Tighten the bolt fully and then loosen 1/4 turn. The sensor must be allowed to move.
- ❖ From the rear of the belt tensioner, tighten the M3x12 screw so that it touches the door sensor.

KROK 70 Securing the door sensor cable




- ◆ Przełóż opaskę zaciskową przez otwór w lewym napinaczu paska.
- ◆ Guide the door sensor cable through the zip tie.
- ◆ Tighten the zip tie to secure the door sensor cable. Cut off the excess.

KROK 71 Guiding the cables: LED and door sensor



- ◆ Przygotuj kartonowe pudełko. Możesz użyć dowolnego pudełka z zestawu. *Pudełko użyte na ilustracji służy wyłącznie do celów poglądowych.*
- ◆ Flip the CoreXY assembly upside down, positioning the smooth rods on top.
- ◆ Slightly lift and support the front side of the CoreXY assembly with the cardboard box.
- ⚠ **Be careful not to damage the door sensor.**
- ◆ Route the white LED strip cable and the door sensor cable through the zip ties.
- ◆ Tighten all the zip ties to secure the cables. Cut off the excess zip ties.
- ⓘ **If you plan on adding the Buddy camera, do not tighten the zip ties all the way.** As you will be adding another USB-C cable to the zip ties soon.
- ◆ **Cables must be slightly taut and straight.** Excess slack or bends may cause collisions with the Y-axis and lead to damage.

KROK 72 Informacja o kamerze Buddy3D



- Ma zastosowanie, jeśli chcesz w przyszłości używać kamery Buddy3D. **Pomiń ten krok, jeśli nie planujesz instalacji kamery Buddy3D.**



⚠ Disclaimer: Typically, the printer must be fully assembled and tested before any add-ons can be installed. Choosing to install the Buddy3D Camera USB cable now will save you time later on.



For detailed information on cable placement, refer to the separate guide **Buddy3D Camera for CORE One Installation**


- The above-mentioned guide on how to install the Buddy3D Camera shows the printer in a further stage of assembly.
- For now, use the guide to make sure that the cable is installed correctly and tighten the zipties.
- i** We will let you know later on when to return to the guide and finish the Buddy camera installation.

KROK 73 Smooth rods: parts preparation




- Do kolejnych etapów przygotuj:**
 - Smooth rod 330 x 8 mm (2x) *found in the Rods box*
 - Śruba M3x8rT (1x)

KROK 74 Installing the CoreXY assembly




- ❖ Ostrożnie przełóż oba gładkie pręty przez łożyska zespołu stołu grzewczego do mocowań prętów w podstawie.
 - ⚠ **It is a requirement to insert the smooth rod in the axis with the bearing very slowly to prevent the balls from shooting out of the bearing.**
- ❖ Temporarily hang the cables from the cooling fans over the rear panel. **There must be a space between the cables and the back panel pocket.**
- ❖ Exercise extreme caution when placing the assembly on the smooth rods and back panel assembly.
 - ⚠ **Ensure that no cables are pinched.**
 - ❖ Ensure both smooth rods are properly seated in the rod holders.
 - ❖ The threaded rod of the rear Z motor must pass through the bed-stop-rear part.
- ⚠ **WARNING: When handling the printer, DO NOT lift it by the CoreXY assembly. Always lift it by the base of the entire assembly.**

KROK 75 Securing the smooth rods




- ⚠ Upewnij się, że oba gładkie pręty są prawidłowo osadzone w uchwytach.
 - ❖ Firmly tighten the right M3x10 screw to secure the smooth rod.
 - ❖ Firmly tighten the left M3x10 screw to secure the smooth rod.

KROK 76 Aligning the linear rail




- ✦ Przesuń wózek liniowy na środek prowadnicy.
- ⚠ **Firmly tighten all screws in the order shown in the picture.**
- ✦ Push the linear rail down while tightening.

KROK 77 Guiding the corexy cables




- ✦ Od tyłu drukarki przełóż złącze PE przez owalny otwór.
- ✦ Locate the FE cable connector (number 5) in the rear left corner - under the CoreXY assembly.
- ✦ Plug the FE connector onto the Faston on the underside of the CoreXY plate.
- ✦ On the same side, push the X motor cable through the oval hole in the back panel.
- ✦ Push the White LED strip and Door sensor cables through the oval hole in the back panel.

KROK 78 Guiding the cooling fan cables





- ◆ Przełóż przewody wentylatorów chłodzących i termistora przez owalny otwór w tylnym panelu.
- ◆ On the right back corner, locate the Y motor cable and push it through the upper oval hole in the back panel.

KROK 79 Montaż ogranicznika stołu





- ◆ Z tyłu zlokalizuj owalny otwór na śrubę pod wentylatorami chłodzącymi.
- ◆ The oval hole must be flush with the hole in the bed-stop part on the opposite side.
- ◆ To compensate, slightly raise the rear of the CoreXY assembly - just a few millimeters.
- ◆ After aligning the holes, secure them with an M3x8rT screw.

KROK 80 Connecting the cooling fans cables




- Poprowadź przewody wentylatorów chłodzących przez lewy otwór w obudowie xBuddy i podłącz je do czwartego i piątego gniazda na płycie rozszerzeń xBuddy extension, oznaczonych jako FAN 1 i FAN 2.
- ❗ The connection order does not matter, both cables are the same.
- Guide the chamber thermistor cable together with the cooling fan cables.
- Connect it to the second slot from the left on the xBuddy extension board labeled TEMP.

KROK 81 Connecting the corexy cables



- Poprowadź przewód silnika osi X przez otwór po prawej stronie obudowy xBuddy. Podłącz go do drugiego gniazda od lewej na płycie xBuddy.
- Guide the door sensor cable through the right hole in the xBuddy box. Connect it to the lower slot on the left side of the xBuddy board.
- Guide the white LED strip cable through the right hole in the xBuddy box. Connect it to the second slot from the right on the xBuddy extension board.
- Guide the Y motor cable through the left hole in the xBuddy box. Connect it to the second slot from the left on the xBuddy board.

KROK 82 Czas na Haribo




- Myslę, że znów nadszedł czas na przekąskę.
- You deserve to eat the whole bag, but keep... Eat just the fourth row.

KROK 83 Gotowe




- Congratulations! You have just assembled and installed the CoreXY assembly.
- Let's go to the next chapter.

6. Montaż Nextrudera



KROK 1 Tool necessary for this chapter



● **For this chapter, please prepare:**

- Klucz uniwersalny
- Klucz imbusowy 1,5 mm
- Klucz imbusowy 2,5 mm
- Klucz Torx T6
- T10 torx key / T10 torx screwdriver

KROK 2 Nextruder idler assembly: parts preparation



● **For the following steps, please prepare:**

- Idler-lever-a (1x) *found in the Electronics package*
- Idler-lever-b (1x) *found in the Electronics package*
- Bearing 693 2RS (2x) *found in the Electronics package*
- Sworzeń 2,9x8,5 (2x) *znajdują się w pakiecie Electronics*
- Śruba M3x6 (1x)
- Tubular spacer 13.2x3.8x0.35 (1x) *found in the Electronics package*

KROK 3 Assembling the extruder idler




- Place both bearings into the Idler-lever-a.
- Insert the pin 2.9x8.5 into each bearing 693 2RS, as seen in the picture.
- Close it up with the Idler-lever-b part and secure it with the M3x6 screw. **Do not overtighten the screw.** Both bearings must be able to rotate without significant resistance.
- From the same side, push the tubular spacer into the assembly. The "bottom" of the tubular spacer must be flush with the bottom part of the Idler assembly.

KROK 4 Assembling the extruder: parts preparation I.



- **For the following steps, please prepare:**
- PG-assembly (1x) *found in the Electronics package*
- Heatsink assembly (1x) *found in the Electronics package*
- Main-plate (1x) *found in the Electronics package*
- PG-ring [pierścień przekładni] (1x) *znajduje się w pakiecie Electronics*
- PG-assembly-adapter (1x) *found in the Electronics package*
- ① The list continues in the next step...

KROK 5 Montaż ekstrudera: przygotowanie części II




- ◆ Extruder motor (1x) *found in the Motors package*
- ◆ Spacer 5x10x0.1 mm (1x) *found in the Electronics package*
- ◆ Socket set screw M3x25 (1x) *found in the Electronics & Fasteners package*

KROK 6 Montaż ekstrudera



- ◆ Place the 5x10x0.1 spacer over the shaft on the extruder motor.
 - ◆ Place the heatsink on the extruder motor. Note the orientation of both parts.
 - ◆ The motor cable must be facing "up".
 - ◆ The heatsink cables must be on the right side.
 - ◆ Umieść przekładkę [main-plate] na radiatorze. Zwróć uwagę na orientację części. Użyj wycięcia jako odniesienia.
- ⚠ **Before proceeding to the next step, make sure that the 5x10x0.1 spacer is placed on the extruder motor.**


KROK 7 Montaż przekładni planetarnej



❗ **The following instructions need to be done correctly and carefully.** Achieve better understanding and successful assembly by watching the video alongside the guide: prusa.io/PG-assembly

- After watching the video, follow the steps in this guide.
- Attach the PG-assembly-adapter on the PG-assembly. Note the pockets for the gears in the adapter.


KROK 8 Montaż pierścienia przekładni



⚠ Do not assemble the gearbox without the PG-assembly-adapter. This tool is intended to ensure that the gears are correctly fit together.

- ➡ Slide the PG-ring onto the adapter.
- ➡ Note there is a chamfer on one side of the PG-ring teeth. This side must be facing down (to the PG-assembly).
- ➡ Grasp the entire assembly in one hand so that it can be rotated with the PG-ring.
- ➡ Drugą ręką nasuń pierścień przekładni [PG-ring] na zespół [PG-assembly] ruchem kołyskowym (przesuwając pierścień przekładni [PG-ring] kilkukrotnie w lewo i w prawo). Wystarczy ćwierć obrotu.
- ➡ Stop when the surfaces of the gears are approximately flush with the surface of the PG ring.

KROK 9 Montaż zespołu przekładni



⚠ Proceed very carefully in this step.


- ➡ Maintain the position of the PG-assembly and attach it on to extruder motor shaft.
- ➡ Very gently and freely rotate with the whole PG assembly (PG-assembly-adapter, PG-assembly and PG-ring) until it drops down so that there is no gap between the assembly and the main-plate. **Do not push on the assembly.**
- ➡ Zdejmij adapter montażowy [PG-assembly-adapter].

KROK 10 Kontrola montażu przekładni



- Attach the PG-assembly-adapter back on the PG-assembly again to verify that all parts are properly seated.
- Rotate with the PG-assembly-adapter. **The PG assembly must be easy to rotate without having to exert much force.**
- Remove the PG-adapter. You will no longer need it during assembly. We recommend keeping it for maintenance.
- Ensure that the PG-assembly is not sticking out above the PG-ring. It should be positioned lower than the level of the PG-ring's surface or at the same level as the ring.
- Upewnij się, że szczelina między pierścieniem przekładni [PG-ring] a przekładką główną [Main-plate] jest minimalna. Jeśli zauważasz większą szczelinę, zdemontuj zespół przekładni i ustaw go ponownie.

KROK 11 Assembling the Nextruder idler



- Insert the idler assembly between the PG-ring and the extruder motor. There is a cutout for the spacer in the main-plate. Line up the idler spacer with the hole in the PG-ring.
- Secure both parts with the socket set screw 3x25. **Do not overtighten the screw! The screw protrudes from the PG-ring after tightening.**

KROK 12 Gear lubrication: parts preparation



For the following steps, please prepare:

- Front Case (1x) *found in the Printed parts package*
- i** Logo na przedniej pokrywie przekładni Nextrudera pozostanie jako **PRUSA CORE ONE**.
- Śruba M3x25 (3x)
- Smar (1x) *znajduje się w pakiecie Electronics & Fasteners*
- Several paper towels to wipe grease from your hands.

KROK 13 Smarowanie kół zębanych




- Remove the cap from the lube. Use the spike on the opposite side of the cap to pierce a hole in the lube tube opening.
- Squeeze a small amount of lubricant onto the tip of the zip tie, then spread it over the gears.
- Apply a small amount of Prusa Lubricant **all around** the PG-ring and PG-assembly teeth.
- Close the lubricant; it is no longer needed for the assembly.

KROK 14 Covering the planetary gear



- Using the paper towel, wipe off the lubricant residue from the face surface of the PG-ring.
- Place the front case onto the gearbox and secure it with three M3x25 screws. **Do not tighten them completely** at this moment.
- i The screws on the front case will be completely tightened during the self-test in the final chapter.

KROK 15 Assembling the Idler-swivel: parts preparation



- **For the following steps, please prepare:**
- Idler-swivel (2x) *found in the Electronics package*
- Idler-nut (1x) *found in the Electronics package*
- Śruba M3x30 (2x)
- Śruba M3x20rT (2x)
- Nakrętka samokontrująca M3nN (2x)
- Spring 15x5 (2x) *found in the Electronics package*
- Spacer 6x3.1x8 (1x) *found in the Electronics package*

KROK 16 Montaż odchylanej blokady docisku




- Push the M3x20rT screw all the way through one of the idler-swivel.
- Slide the spacer onto the screw.
- Place the second idler-swivel from the opposite side on the screw.
- From the other side, attach the M3nN nut onto the screw. Hold the nut using the universal wrench and tighten the screw. **Tighten just lightly!** The spacer must rotate freely.

KROK 17 Montaż nakrętki docisku



- Insert the Idler-nut into the Idler-swivel assembly. Make sure that both parts are oriented correctly according to the picture.
- Secure both parts together by inserting the M3x20rT screw from the same side, like the first screw.
- Secure the screw with M3nN nut. **Do not overtighten the nut.** It must be possible to move with the Idler-swivel on the Idler-nut.

KROK 18 Mounting the Idler-swivel assembly




- Attach the spring 15x5 on both M3x30 screws.
- Push the two screws with the springs through the holes in the protrusion on the heatsink. There are no threads inside.
- Attach the Idler-swivel assembly on the screws. See the correct orientation of the Idler-nut. The side with version marking must be visible. See the picture.
- Tighten both screws. **Stop tightening as soon as the screw tips reach the front face of the idler nut.**

KROK 19 NTC thermistor: parts preparation




- **For the following steps, please prepare:**
- NTC thermistor 90 mm (1x) *found in the Electronics package*
- M3x4T grub screw (1x)

KROK 20 Assembling the NTC thermistor



- On the **extruder motor side**, insert the NTC thermistor into the hole in the heatsink.
- Secure it with the M3x4T grub screw. Screw it all the way in. **Tighten gently, but firmly** using two fingers and the short side of the T6 Torx key. Applying more force may cause permanent damage to the thread.

KROK 21 Mounting the Nextruder: parts preparation




- **For the following steps, please prepare:**
- Nextruder spacer (3x) *found in the Electronics & Fasteners package*
- Śruba M3x10 (3x)
- Cardboard box (1x) *used as temporary heatbed protection*
- i Wskazówka: możesz użyć dowolnego kartonu z zestawu.

KROK 22 Zabezpieczenie stołu grzewczego



- Place an empty cardboard box on the heatbed, ensuring it covers as much of the surface as possible.
- i** This will protect the heatbed from falling parts.

KROK 23 Montaż Nextrudera



- Screw three Nextruder spacers to the Nextruder holder. Tighten the spacers firmly.
- Place the Nextruder assembly on the spacers.
- Align the holes in the Nextruder with the spacers and secure it with three M3x10 screws. **Do not overtighten the screws.**
- Ensure the NTC cable is pointing to the left.


KROK 24 Wentylator hotendu: przygotowanie części



For the following steps, please prepare:


- Hotend fan (1x) *found in the Electronics package*
- Hotend-cable-clip (1x) *found in the Printed parts package*
- Śruba M3x4rT (2x)
- Śruba M3x18 (2x)

KROK 25 Montaż wentylatora hotendu



- Attach the hotend fan onto the heatsink with two M3x18 screws on the left side. **Tighten the screw gently, but firmly, otherwise the plastic housing may crack.**
- ⚠ There is a sticker on the hotend fan, the sticker must be on the rear side of the fan - not visible.
- The cable must be pointing towards the lower-left corner.

KROK 26 Organizacja przewodów wentylatora hotendu




- ✦ Take the Hotend-cable-clip in the same position as shown and guide the **heatsink fan cable** together with the **NTC thermistor cable** through the right cable hook.
- ✦ Attach the Hotend-cable-clip to the Nextruder holder.
- ✦ Secure it using two M3x4rT screws.

KROK 27 LoveBoard: parts preparation I.




- ✦ **For the following steps, please prepare:**
 - ✦ Printhead-cover (1x) *found in the Printed parts package*
 - ✦ Loveboard-mount (1x) *found in the Printed parts package*
 - ✦ Main cable (1x) *found in the Electronics & Fasteners package*
- ⓘ Uwaga: Kolory przewodów mogą się różnić w zależności od partii. Nie ma to wpływu na procedurę.
- ✦ Śruba M3x10 (4x)
- ✦ Śruba M3x8rT (1x)
- ✦ Nakrętka kwadratowa M3nS (5x)
- ⓘ The list continues in the next step...

KROK 28 LoveBoard: parts preparation II.




- ◆ For the following steps, please prepare:
- ◆ LoveBoard (1x) found in the Electronics package

KROK 29 Montaż mocowania płytki LoveBoard




- ◆ Locate the U-shaped cable channel on the Loveboard-mount and insert an M3nS nut into the nearby hole.
- ◆ Use a 2.5mm Allen key to push the nut all the way in.
- ◆ On the opposite side of the part, insert an M3nS nut and push it into place.

KROK 30 Montaż pokrywy głowicy




- 🟢 From the back of the printhead-cover, insert two M3nS nuts into the part.
- 🟡 From the other side of the printhead-cover, insert one M3nS nut into the part.

KROK 31 Montaż płytki LoveBoard



- 🟡 Place the LoveBoard to the Loveboard-mount. Note the correct orientation - the connectors must be facing downwards.
- 🟢 Align the holes with both parts and secure the board with the M3x8rT screw. **Do not overtighten it**, it might damage the part.
- 🟢 Take the end of the extruder main cable without the white label.
- 🟡 Turn the Loveboard-mount upside down and connect the Main cable to the LoveBoard.

KROK 32 Organizacja głównej wiązki przewodów




- ✚ Twist the main cable half a turn.
- ✚ Fold the main cable over the LoveBoard to its opposite side.
- ⬛ Turn the LoveBoard assembly upside down.
- ✚ Guide the main cable over the LoveBoard through the cable channel in the Loveboard-mount.
- ✚ Końcówka owijki tekstylnej musi być zrównana z krawędzią plastikowego elementu.

KROK 33 Zakrycie płytki LoveBoard



- ✚ Insert two M3x10 screws into the Loveboard-holder.
 - ⚠ Ensure you insert the screws from the correct side. Use the LoveBoard logo on the board as a reference.
- ✚ Cover the LoveBoard with the Printhead-cover.
 - ⚠ **Avoid pinching any wires in the main cable.**
- ✚ Przykręć części do siebie dwoma śrubami M3x10.
- ✚ Check that there is no large gap or pinched textile sleeve between the parts.

KROK 34 Swingarm: parts preparation I.



● **For the following steps, please prepare:**

- Śruba M3x8T (2x)
- Śruba M3x10 (1x)
- Fitting M5-4 (1x) *found in the Electronics & Fasteners package*
- Rurka PTFE 710x4x2,5 (1x) *znajduje się w pakiecie CoreXY parts + Hinges set*
- Swingarm assembly (1x) *found in the Metal parts 3/3 package*
- Cable tie (5x) *found in the Electronics & Fasteners package*
- ① Packed in a stack and must be separated.
- ① The list continues in the next step...


KROK 35 Swingarm: parts preparation II.



● **For the following steps, please prepare:**


- Bowden-bend (1x) *found in the Printed parts package*
- Main-cable-clip (1x) *found in the Printed parts package*

KROK 36 Organizacja głównej wiązki przewodów




- Carefully open the Main-cable-clip. Be careful not to crack the part.
- Insert the main cable into the Main-cable-clip.
- Ustaw klips ok. 5-15 cm (2-6") od końca owijki i zamknij go.
- Połóż zespół płytki LoveBoard na pudełku na stole grzewczym.
- Wprowadź główną wiązkę przewodów za zespół CoreXY w prawym tylnym rogu.

KROK 37 Mounting the main cable




- In the right corner of the printer on the Y motor assembly, locate the hole in the plastic part and align it with the main-cable-clip.
- Fix the main-cable-clip with the cable to the hole using the M3x10 screw.

KROK 38 Attaching the LoveBoard assembly



- ◆ From the back of the Nextruder, attach the LoveBoard assembly to the Nextruder.
- ◆ Align the hole in the Loveboard-mount with the threaded hole in the top of the heatsink (Nextruder).
- ◆ Insert and tighten the fitting M5-4 to the heatsink. Use the universal wrench.
- ◆ Z tyłu Nextrudera dokręć dwie śruby M3x10, aby przymocować zespół płytki Loveboard.

KROK 39 Montaż Swingarm




- ◆ Attach the swingarm assembly to the pair of threaded holes on the back panel near the top right corner.
- ◆ Secure it with two M3x8rT screws.
- ⚠ Do not overtighten the screws, as this may strip the threads.

KROK 40 Attaching the main cable



- 🟠 Notice the cutouts on the swingarm.
- 🟢 Position the main cable at the first cutout on the swingarm.
- 🔵 Place one cable tie behind the first cutout on the swingarm, ensuring the correct orientation of the zip strip.
- 🟡 Przełóż opaskę przez oczko, owijając ją wokół Swingarm i wiązki.
- ⬛ Zaciśnij opaskę tak mocno, jak to możliwe.
- 🟡 Wrap the cable tie around.

KROK 41 Inserting the PTFE tube



- 🟢 Push one end of the PTFE tube through the bowden-bend and keep protruding at least 1 cm (0.39 in) of the tube.
- 🔵 Insert the PTFE tube into the fitting M5-4 on the Nextruder. Push it all the way down.
- 🟠 Slide bowden-bend down to cover the fitting M5-4.

KROK 42 Securing the PTFE tube




- Route the PTFE tube in parallel with the main cable, ensuring the PTFE tube stays above the main cable.
- Secure the PTFE tube and main-cable to the swingarm using two cable ties to the remaining cutouts.
- ⚠ Do not pass the PTFE tube through the first cable tie on the swingarm.
- Przepchnij wolny koniec rurki PTFE przez prowadnicę Bowdena [Bowden-guide] i płytę CoreXY w dół. Pozostaw koniec swobodnie zwisający.
- Złącz rurkę PTFE i wiązkę za pomocą pozostałych dwóch opasek kablowych, pozostawiając między nimi odstęp 10 cm (3,94 cala).

KROK 43 Sprawdzenie ruchu



- Manually move the XY axes to their end positions several times and ensure that:
 - The main cable is not too tight and does not pull the Nextruder backward.
 - Wiązka przewodów nie jest uformowana w zbyt duży łuk.
 - Jeśli wiązka jest zbyt napięta lub tworzy zbyt duży łuk, lekko poluzuj śrubę na klipsie [main-cable-clip] i wyciągnij przewód w górę lub w dół o kilka milimetrów. Następnie dokręć śrubę i przetestuj ponownie.

KROK 44 Print fan: parts preparation



For the following steps, please prepare:

- Print fan (1x) found in the Electronics package
- Fan-shroud (1x) found in the Printed parts package
- Śruba M3x25 (1x)
- Śruba M3x10 (2x)
- Nakrętka kwadratowa M3nS (3x)


KROK 45 Montaż kanału wentylatora



- Insert two M3nS nuts from one side into the fan-shroud.
- From the other side, insert one M3nS nut into the fan-shroud.
- Insert the print fan into the fan-shroud as shown. See the correct orientation of the parts.
- Przymocuj wszystkie części jedną śrubą M3x25.

⚠ Nie dokręcaj śrub zbyt mocno, aby nie uszkodzić obudowy wentylatora.

KROK 46 Installing the print fan assembly




- Attach the print fan assembly to the back of the Nextruder.
- Align the holes in the Nextruder bracket with the holes in the fan-shroud.
- Secure the fan-shroud to the Nextruder holder using two M3x10 screws.

KROK 47 Hotend: przygotowanie części




- For the following steps, please prepare:
- Thumb screw (2x) found in the Electronics package
- Prusa Hotend assembly (1x) found in the Electronics package

KROK 48 Montaż hotendu




- ✿ Route the heatsink fan cable above the first threaded hole in the heatsink.
 - ✿ Insert two thumb screws into the heatsink. **Do not tighten them completely.** Two turns are enough for now.
 - ✿ Look closely at the underside of the heatsink and find the hole for the hotend assembly.
 - ✿ Włóż rurkę hotendu (prowadnicę dyszy) do otworu i wsuń całość do radiatora.
 - ✿ Skieruj przewody w lewo zgodnie z ilustracją.
 - ✿ Push the hotend assembly all the way into the heatsink. There should be approximately a 2 mm (0.08 in) gap between the heatsink and the brass part of the nozzle.
 - ✿ While pushing the hotend assembly in, **firmly tighten both thumb screws.**
- ⚠ **Avoid pinching any cable between the screws and the heatsink!**

KROK 49 Connecting the heatsink cables




- ✿ Plug the NTC thermistor cable into the connector above the main cable on the LoveBoard.
- ✿ Podłącz złącze wentylatora hotendu do dolnego gniazda w lewym rzędzie płytki LoveBoard.

KROK 50 Connecting the hotend cables




- ◆ Guide the hotend thermistor through the cable-clip on the Nextruder and connect it to the LoveBoard.
- ◆ Guide the hotend heater through the cable-clip on the Nextruder and connect it to the LoveBoard.

KROK 51 Connecting the print fan cable




- ◆ Guide the print fan cable through the channel in the plastic cover.
- ◆ Create a loop with the print fan cable in the cable area and plug it into the middle connector in the LoveBoard.

KROK 52 Podłączenie silnika ekstrudera



- ◆ Plug the Nextruder motor (labeled E) to the top-facing connector.
- ◆ Plug the loadcell cable (lower cable) to the upper connector on the right side of the Nextruder.
- ◆ Plug the filament sensor (upper cable) to the lower connector.


KROK 53 LoveBoard covers: parts preparation



● **For the following steps, please prepare:**

- Printhead-cover-right-lever [boczna pokrywa z ramieniem] (1x)
- Print-head-cover-right (1x) *found in the Printed parts package*
- Śruba M3x10 (1x)
- Śruba M3x6 (2x)

KROK 54 Zakrycie płytki LoveBoard




- Załóż prawą pokrywę głowicy z ramieniem [Printhead-cover-right-lever] na Nextruder z prawej strony.

⚠ **Do not pinch the cables!**

- Secure the cover with two M3x6 screws.
- Dociśnij przewody do płytki LoveBoard tak bardzo, jak to możliwe, aby nie wystawały i nie przeszkadzały w montażu pokrywy.
- Załóż lewą pokrywę głowicy [Printhead-cover-left] na Nextruder z lewej strony.
- **Note the protrusion on the underside of the cover - the protrusion must fit into the counterpart on the Nextruder.**
- Secure the cover with one M3x10 screw.

KROK 55 LoveBoard: kontrola okablowania




 **Before covering the electronics, check the connection of all cables.**

 Click on the picture to open it in the high-resolution preview.

 Guide the main-cable through the upper hole on the right side of the back panel assembly.

 Pozostaw koniec wiązki luźny na tym etapie.

KROK 56 Guiding the main cable



 Rotate the printer so that the backside faces you.


 Poprowadź główną wiązkę przez otwór po lewej stronie do obudowy xBuddy.

 Plug the main-cable to the slot on the right side of the xBuddy board.

 Jeśli złącze nie sięga gniazda lub wiązka jest zbyt napięta, wróć do kroku **Organizacja głównej wiązki przewodów** i wyciągnij wiązkę lekko w dół z klipsa [main-cable-clip].


 Zamocuj przewody opaskami zaciskowymi, które wcześniej zostały przewleczone przez otwory w obudowie xBuddy. Ostrożnie odetnij nadmiar, **zwracając szczególną uwagę na przewody.**

KROK 57 Czas na Haribo



- ⬢ Power up and push forward!
- ⬢ Eat the fifth row.
- ⬢ Jeszcze Ci mało?

KROK 58 Gotowe




- ⬢ Congratulations! You just successfully assembled the Nextruder.
- ⬢ Let's move to the next chapter.

7. Bodywork & Electronics




KROK 1 Tools necessary for this chapter



For the following steps, please prepare:

- Klucz imbusowy 2,5 mm
- Klucz imbusowy 1,5 mm
- Klucz Torx T10
- Szczypce spiczaste
- Obcinaczki boczne (opcjonalnie)


KROK 2 Front profiles: parts preparation



For the following steps, please prepare:


- Front Left Profile (1x) *found in the Metal parts 1/3 package*
 - ① The one with the two circular openings on top.
- Front Right Profile (1x) *found in the Metal parts 1/3 package*
 - ① The one with one circular opening on top.
- Śruba M3x4rT (8x)

KROK 3 Installing the front right profile




- Attach the Front Right Profile to the printer.
 - ❗ Ensure you are using the correct profile—it should have **one large round opening** for the belt tensioning screw.
- Align the profile so that the calibration screw opening and the smaller bolt opening line up with the thread.
- Secure the profile to the CoreXY assembly using two M3x4rT screw
- Fix the profile at the bottom using the two M3x4rT screws.

KROK 4 Installing the front left profile



- Attach the Front Left Profile to the printer.
 - ❗ Ensure you are using the correct profile—it should have **two large round openings** for the door sensor and the belt tensioning screw.
- Align the profile so that the openings match. **Be careful not to bend the door sensor lever!**
- Secure the profile to the CoreXY assembly using two M3x4rT screw
- Fix the profile at the bottom using the two M3x4rT screws.

KROK 5 Top profiles: parts preparation



- Top Profile (4x) *found in the Metal parts 1/3 package*
- Note that one of the profiles has two openings in the middle—this one belongs at the back.
- Śruba M3x4rT (8x)
- M3x4 screw (4x) *with the different head type*
- Nit nylonowy (3x)

KROK 6 Assembling the top profiles I.




- ⚠ Be very careful when handling sharp sheet metal parts to avoid injury or damage.
- According to the picture, place the top profile with two holes on the flat side.
- Orient the part according to the picture. **Use the flange as a guide.**
- Place any other of the top profiles on the left side. Orient the part according to the picture. **Use the flange as a guide.**
- Attach the two profiles together.
 - ⚠ The flange of the front plate (blue arrow) must be inserted **under** the left universal profile (green arrow), not on top of it.
- Align the holes in both parts and join both parts together with the M3x4 screw.
- Using the same procedure, join the other two profiles to form a corner, securing them with an M3x4 screw.

KROK 7 Assembling the top profiles II.



- Attach the corner profile assembly to the first one, aligning the holes on the flanges with the holes in the profiles.
- ⚠ Ensure the flanges are positioned **underneath** the profiles.
- Join the both profile assemblies using two M3x4 screws.

KROK 8 Aligning the top profiles



- Find the profile with **two openings in the middle**—this part should be positioned at the **rear of the printer**.
- Add the top profile assembly onto the printer, making sure the two openings are facing the back.
 - The protruding part of the rear profile must be positioned behind the back sheet metal plate.
 - On the sides and front, the profiles must sit on top of the tabs with threaded openings.

KROK 9 Installing the top profiles



- Once all the top profiles are properly aligned, fix them in place using the remaining 8 M3x4rT screws in the corners.
- Attach the back panel to the top profile with three nylon rivets.

KROK 10 CoreXY fixing screws: parts preparation



- For the following steps, please prepare:
- Śruba M3x4rT (4x)

KROK 11 Fixing the CoreXY assembly



- Align the CoreXY assembly so the threaded holes match the screw openings in the rear profiles. You may need to push the assembly upward to align the holes.
- Fix the CoreXY assembly using the four M3x4rT screws in the marked openings.

KROK 12 Side sensor base: parts preparation



- **For the following steps, please prepare:**
- Filament-sensor-body [korpus czujnika filamentu] (1x)
- Filament-sensor-lever [dźwignia czujnika filamentu] (1x)
- Filament-sensor-switch [przełącznik czujnika filamentu] (1x)
- Śruba M3x10 (1x)
- 10x6x2mm magnet (2x) *found in the Electronics & Fasteners package*
- 7mm Ferromagnetic Ball (1x) *found in the Electronics & Fasteners package*
- Podkładka M3w (1x)

KROK 13 Assembling the side sensor base



- Insert one of the magnets into the dedicated opening in the Lever.
- Insert the ball into the corresponding opening on the inside of the sensor base.
- Insert the lever with the magnet into the Base.

i The part with the magnet should be positioned next to the ball.

Note that the ball will be attracted to the magnet—ensure it stays securely in place.

- Przymocuj dźwignię śrubą M3x10 z podkładką M3w. Na razie dokręć ją tylko o kilka obrotów - tylko na tyle, aby utrzymać ją na miejscu.

! **Nie dokręcaj śruby do końca.** W przeciwnym razie dźwignia nie będzie się poruszać, a czujnik nie będzie działać!

KROK 14 Test dźwigni



- Verify the lever is able to move freely.
- Jeśli dźwignia nie porusza się z luzem lub nie można jej w ogóle poruszyć, poluzuj śrubę o ćwierć obrotu i sprawdź ponownie.


! Śruba **nie może być całkowicie dokręcona**, aby dźwignia mogła się swobodnie poruszać.

KROK 15 Montaż przełącznika



- Wsuń drugi magnes 10x6x2 do przełącznika [filament-sensor-switch].
- Umieść przełącznik czujnika filamentu [filament-sensor-switch] w korpusie [filament-sensor-switch].
- Przesuń przełącznik do lewej pozycji, tak aby magnesy znalazły się naprzeciwko siebie.
- Upewnij się, że **magnesy się odpychają** - elementy powinny się samoczynnie odsuwać.
- **Jeśli się przyciągają:** wyjmij magnes z przełącznika i odwróć go. Następnie sprawdź ponownie.
- ⓘ *Pro tip: Użyj jednego z cienkich kluczy imbusowych lub Torx, aby wyjąć magnes z przełącznika.*

KROK 16 IR Sensor: parts preparation



- **For the following steps, please prepare:**
- Side Filament Sensor Cable (1x) *found in the Electronics & Fasteners package*
- IR Filament Sensor (1x) *found in the Electronics & Chamber parts package*
- Side Filament Sensor Cover (1x) *found in the Printed package*
- Śruba M2x8 (1x)
- Śruba M3x10 (2x)
- Nakrętka kwadratowa M3nS (2x)

KROK 17 Connecting the IR sensor




- Plug the cable into the IR filament sensor.
- ⚠ Ensure the connector is oriented correctly before plugging it in!
- On CORE One, the brown cable must connect to the +5V pin.
- The white cable connects to the GND pin.

KROK 18 Installing the IR sensor



- First, insert the cable into the groove. The black connector should be approximately in the middle of the sensor base.
- Insert the IR sensor itself into the dedicated groove.
- The lever must fit into the optical gate part of the sensor.
- Make sure neither the connector nor the cables touch the lever, as this could prevent the sensor from functioning correctly.
- Using the 1.5mm Allen key, fix the sensor in place with the M2x8 screw.

KROK 19 Installing the side sensor cover



- ✚ Insert the two M3nS nuts into the designated openings. Use a 1.5mm Allen key to **push them all the way in**.
 - ✚ Look from the side to ensure the threads in the nuts align with the openings.
 - ✚ Add the cover part onto the assembly.
 - ✚ Fix the cover in place using two M3x10 screws on the sides.
- ⚠ **Nie dokręcaj śruby na środku! W przeciwnym razie czujnik przestanie działać.**

KROK 20 Side filament sensor: parts preparation



- ✚ **For the following steps, please prepare:**
- ✚ Side Filament Sensor Assembly (1x) *you assembled earlier*
- ✚ Collet (1x) *found in the Electronics & Fasteners package*
- ✚ Opaska zaciskowa (3x)

KROK 21 Installing the side filament sensor




- 🟠 Install one zip-tie into the marked openings. We will use it to attach a cable underneath the metal profile.
 - 🟡 Włóż tuleję zaciskową do wskazanego otworu na zespole czujnika.
 - 🟢 Attach the sensor assembly onto the PTFE tube in the printer.
- ⚠️ **Make sure to push the tube all the way in!**

KROK 22 Guide the filament sensor cable




- 🟠 Move the sensor assembly up, roughly to the middle of the printer's frame, to align the cable properly.
- 🟢 Once in position, secure the cable underneath the metal profile using a zip-tie. Tighten the zip-tie lightly, allowing for cable adjustments if needed later. Cut off the excess zip-tie.
- 🟡 Guide the sensor cable through the dedicated opening to the back of the printer.
- 🟠 Z tyłu drukarki poprowadź przewód do obudowy xBuddy. Pozostaw go na razie luźno.

KROK 23 Connecting the side filament sensor



- Connect the Side Filament Sensor cable into the connector labeled FILAMENT on top of the xBuddy extension board.
- i You can use needle-nose pliers to assist you, but be careful not to damage the cables.
- Use two zip-ties to clamp the cable bundle together in the marked area.
 - Secure the cables in the **highest possible position** to ensure they clear the two openings on the sheet metal below.
- ⚠ Do not over-tighten the zip ties or strain the cables too much!

KROK 24 NFC Antenna: parts preparation



- For the following steps, please prepare:
- El-box-cover (1x) found in the Printed parts package
- Śruba M3x10 (2x)
- NFCcoil (1x) found in the Electronics & Chamber parts package
- Adhesive film 32 x 25 mm (1x) found in the Electronics & Chamber parts package
- NFC coil cable (1x) found in the Electronics & Chamber parts package

KROK 25 Applying the adhesive film




- ✦ Peel off the yellow protective film from the adhesive tape.
- ✦ Apply the film to the flat side of the NFC coil, ensuring it adheres properly.
- ✦ Peel of the remaining protective layer from the NFC coil.

KROK 26 Installing the NFC Coil




- ✦ Stick the NFC coil onto the inner side of the EI-box cover, approximately as shown in the picture.
- ⓘ The small round connector should be positioned closer to the edge of the cover.
- ✦ Connect the cable to the board by aligning the connectors and pressing lightly until you feel a click, ensuring a secure connection.
- ⚠ Be careful when connecting the NFC coil cable. Misalignment or excessive pressure can cause irreversible damage.

KROK 27 Connecting the NFC Coil



- 🟢 Locate the small round connector labeled NFC on the bottom left side of the xBuddy board.
- 🟡 Connect the NFC coil cable to the board by aligning the connectors and pressing lightly until you feel a click.

KROK 28 Kontrola okablowania



- 🟡 Use the pictures as a reference to verify your electronics connections.
- ⚠️ Make sure that all connectors are fully inserted and PSU cables properly tightened. Otherwise, there is a risk of damage to the printer!

KROK 29 Preparing the electronics cover



- Push two M3x10 screws through the EI-box-cover.

KROK 30 Installing the electronics cover




- Ensure the threaded holes on the bottom of the xBuddy box are not obstructed by cables.
- If so, rearrange the cables to allow clear access.
- Align the cover with the opening in the xBuddy box and fix it in place by tightening the screws.
- Route the NFC cable through the space between the Ethernet connector and the PSU power cables.
- ⚠ Avoid running it through the Ethernet connector or the power cables. The cable may be damaged when covering the xBuddy box.**

KROK 31 Informacja o kamerze Buddy3D




- i** Dla użytkowników planujących montaż kamery Buddy3D w przyszłości:
- Jeśli planujesz używać kamery Buddy3D, przewód USB jest już poprowadzony.
 - Szczegółowe informacje na temat montażu i podłączenia kamery Buddy3D znajdziesz w tym przewodniku: **Montaż kamery Buddy3D w CORE One**

KROK 32 xBuddy cover: parts preparation



- **For the following steps, please prepare:**
- Sheet metal back cover (1x) *found in the Metal parts 2/3 package*
 - xBuddy cover (1x) *found in the Metal parts 3/3 package*
 - Śruba M3x4rT (8x)

KROK 33 Installing the xBuddy cover




- 🟢 Ułóż przewody wewnątrz obudowy xBuddy tak, jak na ilustracji.
- 🟡 Carefully cover the xBuddy box by first sliding the bent part of the cover into the box.
- ⚠️ **Avoid pinching the cables. Double-check the NFC coil cable position.**
- 🔵 Secure the xBuddy box cover using the six M3x4rT screws.

KROK 34 Installing the rear cover



- 🔵 Align the rear sheet metal cover so that the cables can run through the "tray".
- 🔴 Place the rear sheet metal cover into the recess. Push it toward the printer, then move it upward to engage it.
- 🟡 There are four tabs that should engage into the printer's chassis.
- 🟢 Secure the rear cover in place using two M3x4rT screws from inside the printer.

KROK 35 Right side: parts preparation



For the following steps, please prepare:

Right side sheet metal (1x) found in the Metal parts 2/3 package

⚠ The correct **right-side** piece can be easily identified by the screw openings in the middle.


Śruba M3x8rT (4x) znajdują się w pakiecie Electronics & Fasteners

Puck-universal [krążek uniwersalny] (1x)

Dowolne kartonowe pudełko

📌 Wskazówka: dobrze sprawdza się pudełko po Prusamencie.

KROK 36 Montaż krążka uchwytu szpuli



Połóż krążek na pudełku tak, aby otwory na śruby były skierowane do góry.


Ostrożnie połóż prawy panel na krążku, ustawiając go na środku.

Wyrównaj otwory w krążku z otworami w prawym panelu.

Przykręć krążek czterema śrubami M3x8rT.

ⓘ Śruby mogą stawiać opór podczas dokręcania, ponieważ same wycinają gwint w otworze.


KROK 37 Right handle: parts preparation



For the following steps, prepare:

- Side Handle (1x) *found in the Printed parts package*
- Śruba M3x8rT (2x)
- Collet (1x) *found in the Electronics & Fasteners package*
- PTFE Tube 4 x 2.5 x 45 mm (1x) *found in the CoreXY parts + Hinges set package (together with hinges parts)*
- Nit nylonowy (11x)

KROK 38 Montaż tulei zaciskowej




- Insert the collet into the handle.
- Push it all the way in.

KROK 39 Montaż uchwytu




- ✿ Place the right-side metal sheet assembly on the right side of the printer. Ensure the U-shaped cutouts are facing upwards.
- ✿ Attach the right handle to the right metal sheet.
- ✿ Push one M3x8rT screw through the rear hole in the handle and the metal sheet.
- ✿ Attach the side filament sensor assembly on the screw.
- ⚠ **Do not pull the side sensor assembly too far; bring the right side metal sheet as close as possible.**
- ✿ Tighten the screw just slightly—the nut must remain free to move.
- ✿ Align the side filament sensor with the front screw hole in the metal sheet and the handle.

KROK 40 Fixing the right side



- ✿ Using the second M3x8rT screw, secure the right handle and the side filament sensor to the right metal sheet.
- ✿ Secure the side sheet metal to the printer using the 11 Nylon rivets.
- ✿ Insert the short PTFE tube 4 x 2.5 x 45 into the collet. Push it all the way in.
- ⓘ Part of the PTFE tube will remain protruding from the handle.

KROK 41 Left side: parts preparation



For the following steps, prepare:


- Left side sheet metal (1x) *found in the Metal parts 2/3 package*
- Side Handle (1x) *found in the Printed parts package*
- Śruba M3x5rT (2x)
- Nit nylonowy (11x)

KROK 42 Installing the left side



- Align the handle with the threaded openings in the sheet metal.
- Attach the handle using the two M3x5rT screws.
- Secure the side sheet metal to the printer using 11 nylon rivets.

KROK 43 Czas na Haribo



- Well done—fuel up for the next challenge!
- Eat the sixth row.
- So close! But **hands off those last gummies!**

KROK 44 Gotowe




- Congratulations! You've successfully assembled the entire body.
- Let's move to the next chapter.

8. Trim, Door & xLCD



KROK 1 Tools necessary for this chapter



● **For the following steps, prepare:**

- Klucz imbusowy 2,5 mm
- Klucz Torx T10
- Szczypce spiczaste


KROK 2 Top cover: parts preparation



● **For the following steps, prepare:**


- Top cover (1x) *found in the Plexi set package*
- Vent cover (1x) *found in the Plexi set package*
- Nakrętka samokontrująca M3nN (3x)
- Insulating insert (3x) *found in the Electronics & Fasteners package*
- ⓘ Ta część może mieć kolor szary lub czarny. Jednak kształt jest identyczny i nie ma to wpływu na procedurę.
- Śruba M3x12rT (3x)
- Nit nylonowy (4x)
- Upg-vent-block [zasuwa górnej kratki wentylacyjnej]

KROK 3 Odklejenie folii



- First, remove the protection foil from both the plastic sheets.
- Flip the parts around and remove the protective foil from the other sides.


KROK 4 Test-fitting the top cover




- Lay down the top cover onto the printer.
- The part with the vent openings should be oriented towards the front of the printer.
- If oriented correctly, the cover will align with the recess, and the bolt heads in the corners will fit into the cutouts.

i If the bolt openings don't align, flip the cover.

Spoiler alert: The cover isn't symmetrical!

KROK 5 Assembling the top cover I.

- 🟠 Nałóż podkładki na wszystkie trzy śruby M3x12rT.
- 🔵 Make sure the flanged part of the insert is oriented toward the screw head.
- 🟢 Insert the screws with the inserts through the three slot openings in the vent.

KROK 6 Assembling the top cover II.

- 🟡 Align the vent cover with the screw ends on the bottom.
- 🟣 Ręcznie dokręć prawą nakrętkę M3nN na śrubie M3x12rT, aby zamocować pokrywę.
- 🟠 Przyłóż zasuwę górnej kratki wentylacyjnej [Upg-vent-block] do kratki. Upewnij się, że jest prawidłowo ustawiona.
- 🟢 Przymocuj zasuwę górnej kratki wentylacyjnej [Upg-vent-block] nakrętkami M3nN. Przytrzymaj nakrętki szczypcami spiczastymi podczas dokręcania śrub.

⚠️ The screw must be tight enough just to remove the slack. It must remain loose, or the ventilation cover won't open and close properly.

KROK 7 Test wentylacji



- Try moving one of the three screws with your hand.
- ⓘ The vent openings must open and close smoothly without effort.
- ⚠ If movement is difficult, loosen the screw that is restricting it.

KROK 8 Installing the top cover



- Dopasuj pokrywę do wgłębienia na drukarce, upewniając się, że otwór wentylacyjny jest skierowany do przodu.
- Secure the cover to the frame using four nylon rivets in the marked openings.
- ⓘ There are eight openings, but four rivets should be sufficient.


KROK 9 Side covers: parts preparation



● For the following steps, prepare:

- Side Cover (2x) found in the Plexi set package
- Nit nylonowy (10x)

KROK 10 Odklejenie folii



- Remove the protective foil from both the side covers.
- Remove the protective foil from the other sides of both the side covers.

KROK 11 Covering the left side



- ✦ Align the cover with the recess on the left side of the printer.
- ✦ The protruding screws on the printer must align with the larger openings in the cover.
- ✦ Secure the cover to the frame using five nylon rivets in the marked openings.

KROK 12 Covering the right side



- ✦ Align the other cover with the recess on the right side of the printer.
- ✦ Secure the cover to the frame using five nylon rivets in the marked openings.

KROK 13 xLCD: przygotowanie części



- For the following steps, prepare:
- xLCD (1x) found in the Electronics package
 - xLCD Front Cover (1x) found in the Printed parts package
 - xLCD Display-mount (1x) found in the Printed parts package
 - Knob (1x) found in the Printed parts package
 - Wkręt 3x8sT (4x)
 - Faston connector (1x) found in the Electronics package

KROK 14 Assembling the xLCD I.



- Zalecamy ustawienie przedniej pokrywy ekranem do dołu na krawędzi kartonu lub biurka, aby pozostawić miejsce na pokrętło enkodera.
- Remove the protective foil from the xLCD.
- Insert the xLCD into the front cover.


KROK 15 Assembling the xLCD II.



- Cover the assembly with the rear part.
 - Jeśli masz starszą, wydrukowaną wersję tylnej pokrywy, musi ona zahaczać o sam xLCD w rogu. W najnowszej wersji tylną część można po prostu położyć.
- Fix the parts together using **JUST THREE** 3x8sT screws in the marked openings.

⚠ Nie wkręcaj jeszcze wkręta w czwarty otwór w pobliżu podłużnego otworu na złącze xLCD, widocznego przez wycięcie. Pozostaw go pustym.


KROK 16 Installing the FE Faston connector



- Let's move on to the fourth screw opening—this is where we will attach the grounding faston connector.
- Using needle-nose pliers, carefully maneuver the grounding faston connector over the screw opening, ensuring the holes line up.
- Secure the connector in place using one 3x8sT screw, making sure it stays lined up as indicated.


⚠ To prevent damaging some of the surrounding electronic components, be careful and make sure the connector doesn't spin, while tightening it.

KROK 17 Installing the LCD knob



- There is a flat part on the encoder shaft. Rotate the encoder so that the flat part is facing up.
- There is a small gate scar on the injection-molded knob, which can serve as an orientation mark.
- Attach the knob onto the shaft, making sure the mark on the knob is facing up.

KROK 18 xLCD bezel: parts preparation




- **For the following steps, prepare:**
- xLCD (1x) *found in the Electronics package*
- Nakrętka kwadratowa M3nS (2x)
- Śruba M3x6 (2x)
- Bezel (1x) *found in the Metal parts 2/3 package*

KROK 19 Mounting the xLCD I.




- Insert the two M3nS nuts into the dedicated openings on the back of the xLCD assembly,
- Push the nuts all the way in until the threads line up with the screw openings.
- Attach two M3x6 screws into the openings. Do not screw them all the way in.
- Leave a gap under the screw heads.

KROK 20 Mounting the xLCD II.




- Hook up the xLCD assembly onto the Bezel.
- Insert the screw heads into the keyhole openings.
- Slide the xLCD assembly so that the screw heads engage into the narrower parts of the keyholes.
- If assembled correctly, the LCD should be pointing up...
- ...While the bent lip on the Bezel is on top.
- Push the screws all the way into the narrow part of the keyhole on both sides. Then, tighten the screws.

KROK 21 Installing the xLCD assembly




- ✶ Put the xLCD assembly in front of the printer, as pictured.
- ✷ Pull the appropriate cables out from the front of the printer to make connecting them easier.
- ✶ There is a small red tab on the main connector. This tab must be oriented towards the triangle symbol on the PCB.
- ✶ Connect the main connector into the xLCD.
- ✶ Connect the grounding faston connector.

KROK 22 Securing the xLCD assembly



- ✶ Gently lift the xLCD assembly into the upward position.
⚠ Proceed carefully to ensure none of the cables get pinched or disconnected.
- ✷ Hook the tiny tab on the left side of the bezel behind the left vertical profile of the printer.
- ✶ Gently lift the bottom part of the xLCD assembly to allow for smoother tab engagement and extra wiggle room.
 - ✶ Hook the tab on the right side into the printer's right profile.


KROK 23 Door seal: parts preparation



For the following steps, prepare:

- Side door seal, a longer one (2x) found in the *Electronics & Fasteners* package
- Top door seal, a shorter one (1x) found in the *Electronics & Fasteners* package
- i The color of the protective layer may vary.

KROK 24 Attaching the top seal




- Take the **SHORTER** seal.
- Peel off the start of the protective foil. No need to remove it entirely yet.
 - i No need to remove it entirely yet. For easier installation, you can peel it off gradually as you go.
- Start applying the seal along the top edge of the printer's frame.
 - Begin offset from the corner by a distance equal to the seal thickness.
- Apply the seal along the top edge, leaving the end offset from the corner, just like on the other side.

KROK 25 Attaching the side seals



- ✦ Apply the longer door seal, starting from the end of the seal on top.
- ✦ Work your way from the top down.
- ✎ With needle-nose pliers, trim the excess.
- ✦ Using the same technique, apply the remaining long seal along the left edge of the printer's frame.

KROK 26 Magnet holders: parts preparation



- ✦ **For the following steps, prepare:**
- ✦ Śruba M3x5rT (2x)
- ✦ Nakrętka kwadratowa M3nS (2x)
- ✦ 20x6x2 Magnet (2x) *found in the Electronics & Fasteners package*
- ⚠ **Keep the magnets apart at a sufficient distance. They can break each other!**
- ✦ Magnet Holder (2x) *found in the Printed parts package*

KROK 27 Assembling the magnet holders



- ✚ Insert the M3nS nuts into the corresponding openings in the magnet holders.
- ✚ Push the nuts all the way in, until the thread aligns with the screw opening.
- ✚ Insert the magnets into the corresponding pockets in the holders. Push them all the way in.
- ⓘ The orientation of the magnets does not matter.


KROK 28 Installing the magnet holders



- ✚ From the inside of the printer, insert the magnet holder assembly into the corresponding bottom opening in the right-side metal profile.
- ⚠ Ensure the protruding rectangular pocket fits into the cutout.
- ✚ Secure the assembly in place using the M3x5rT screw.
- ✚ Using the same technique, install the other magnet holder into the top opening on the right side.


KROK 29 Zawiasy: przygotowanie części**For the following steps, prepare:**

- Door-hinge-in (2x) found in the CoreXY + Hinges set package
- Door-hinge-out (2x) found in the CoreXY + Hinges set package
- Hinge Pin 2 x 40 mm (2x) found in the Electronics & Fasteners package
- Śruba M3x5rT (2x)

KROK 30 Installing the door-hinge-in parts


- From the inside of the printer, insert the door-hinge-in into the bottom rectangular opening in the left-side profile. The protruding part should pass through to the front.
- Fix the door-hinge-in in place using the M3x5rT screw.
- Using the same technique, install the other door-hinge-in into the opening on top.

KROK 31 Installing the door-hinge-out I.



- ✦ Align the door-hinge-out with the door-hinge-in.
- ✦ The chamfered end of the hinge pin should be inserted first to make assembly easier.
- ✦ Insert the pin from the top of the door-hinge-out, guiding it through the door-hinge-in until it is fully inserted.
- ❗ Use the tip of needle-nose pliers to press the pin in securely.

KROK 32 Installing the door-hinge-out II.




- ✦ Using the same technique, install the bottom door-hinge-out to complete the hinge assembly.
- ✦ Look into the grooves on the door-hinge-out parts and verify that the pins are fully inserted.

No part of the pin should be visible above the bottom surface in the groove.

- ✦ Open up both the hinges.

KROK 33 Door panel: parts preparation




● **For the following steps, prepare:**

- Door (1x) found in the Plexi set package

❗ Panel drzwi jest fabrycznie oznaczony jako **CORE ONE**. Nie martw się, **jest to zamierzone!** Naklejkę + nakleimy na końcu.

- Door handle (1x) found in the Metal parts 2/3 package
- Śruba M3x5rT (4x)

KROK 34 Door panel: removing the protective film



- **The door panel has protective film on both sides.** One covers the entire surface, the other just the center area.

- Peel off the film covering the entire door; it's lightly transparent.

- You can remove the center protective film (white) now or after mounting the panel to protect the surface during handling.

❗ This protective film does not interfere with the installation of the hinges or handle.

KROK 35 Installing the door panel



- Align the door with the hinges. The cutouts on the door should fit into the grooves on top and bottom of the leaves.
- Make sure the door is oriented so that the signs on the door are pointing outward.
- Slide the door all the way into both the hinges.
- Fix the door to the hinges using four M3x5rT screws. Start with the top one. Then, do the bottom.


KROK 36 Assembling the door handle



- Let's move onto the handle. Remove the protective foil from both the adhesive strips on the inside.
- The part with the adhesive strip will go onto the back of the door. But do not attach the handle yet!

⚠ Wait for the upcoming step! We have to align the handle first!

KROK 37 Securing the door handle



- ✦ Align the handle so that the front chamfered part is flat to the door. The top of the handle must be flush with the door.
- ✦ While pushing the handle against the door to keep it aligned, slowly rotate it counterclockwise until the adhesive strips bond to the door.
- ✦ Push the door and handle together firmly in the adhesive strip areas to ensure a secure attachment.

KROK 38 Przyklejenie naklejki: przygotowanie



- ✦ Do kolejnego etapu przygotuj:
 - ✦ Naklejka na drzwi CORE One+
 - ❗ Naklejka na drzwi CORE One+ znajduje się w pudełku CORE One+ Upgrade

KROK 39 Przyklejenie naklejki



- Odklej folię ochronną z naklejki.
- Wyrównaj naklejkę z **napisem ONE** na przednich drzwiczkach drukarki i dociśnij ostrożnie, ale zdecydowanie.
- Ostrożnie zdejmij folię transferową, upewniając się, że symbol + nie odkleja się.

KROK 40 Czas na Haribo




- Hard work deserves sweet results!
- Eat the seventh row.
- ⚠ But don't eat the rest yet.

KROK 41 Gotowe



- Gratulacje! Mamy za sobą pomyślny montaż drukarki Prusa CORE One+.
- Let's move to the final chapter.

9. Calibration & First run



KROK 1 Naciągnięcie paska



i This chapter will guide you through calibrating and preparing the printer for its first run.

● Calibrate the belt tension. See the following article for more info:

● **Adjusting belt tension (CORE One)**

! Nie zapomnij wrócić tutaj po wyregulowaniu pasków.

KROK 2 Montaż uchwyty szpuli: przygotowanie części



● Do kolejnego etapu przygotuj:

● O-ring

● Spoolholder-static [uchwyt szpuli - element stały]

i Element stały uchwyty szpuli [Spoolholder-static] i o-ring znajdują się w tym samym woreczku.

KROK 3 Przymocowanie płyty stołu i uchwytu szpuli



⚠ Make sure there is nothing on the heatbed. The heatbed must be clean. Any dirt can damage the surface of both the heatbed and the print sheet.

➡ **Attach the sheet by first aligning the rear cutout with the locking pins on the back of the heated bed.** Hold the sheet by the front two corners and slowly lay it down onto the heated bed - **watch your fingers!**


⬛ Keep the **print sheet** clean for optimum performance.

⬛ Przyczyną nr 1 odklejania się wydruków od arkusza jest zatłuszczona powierzchnia. **Użyj IPA (alkoholu izopropylowego), aby ją odtłuścić**, jeśli wcześniej zdarzyło Ci się dotknąć powierzchni.

➡ Załóż o-ring na element stały uchwytu.

➡ Wciśnij stały element uchwytu na krążek [Puck-universal] i zablokuj, przekręcając w prawo.

KROK 4 Aktualizacja Firmware



i Wszystkie drukarki wysyłamy z pamięcią USB z najnowszym firmware. Zalecamy jednak sprawdzenie i ewentualną aktualizację oprogramowania co kilka tygodni.

⬛ Visit the **help.prusa3d.com** page.

➡ Przejdź do strony Prusa CORE One+.

➡ Pobierz najnowszą wersję firmware.


⬛ Zapisz plik z firmware (.bbf) w pamięci USB.

KROK 5 Włączenie drukarki



- ✿ Insert the USB drive included in your kit into your printer.
 - ❗ The included USB drive contains the latest firmware file.
- ✿ Connect the power cable and plug the printer into a wall outlet.
- ✿ Włącz drukarkę za pomocą przełącznika znajdującego się z tyłu.
- ❗ Drukarka automatycznie sprawdzi czy w pamięci USB znajduje się nowa wersja firmware.
 - ✿ If the "New firmware available" screen appears, hit **FLASH** by pressing the rotary knob to upgrade to the latest firmware.
 - ✿ If no such message appears, the printer is running the latest firmware already. Proceed to the next step.

KROK 6 Konfiguracja drukarki: Intro



- ✿ The printer displays on the screen a prompt to select your language. Use the control knob or touchscreen to set your preference.
- ✿ After selecting your language, the printer will display the welcome screen. Hit **OK** to continue through the setup process.
- ✿ Na następnym ekranie zobaczysz opcje wyboru modelu drukarki - CORE ONE+. Naciśnij **Gotowe**, aby kontynuować.

KROK 7 Setting up the printer: Network setup



- ◆ The Network Setup screen will ask you to connect to a Wi-Fi network using our official Prusa mobile app.
 - ❗ Read more on prusa.io/app.
- ◆ If you select **No**, the printer will show alternative ways to connect to Wi-Fi. This step is optional and can be done later.
 - ❗ Możesz pominąć ten etap i skonfigurować połączenie sieciowe później.

KROK 8 Asystent: Intro



- ❗ The printer will prompt you to run self-tests and calibrations for all important components. The entire process takes a few minutes, with some parts requiring direct user interaction.
 - ◆ Hit **YES** to begin the self-test and follow the instructions on screen.
- ⚠ During the self-test, **keep the door closed until you are prompted**. Opening the door will interrupt the process.
 - ◆ **Podczas Selftestu wewnątrz drukarki poruszają się GORĄCE części.**
 - ◆ Drukarka rozpocznie testy wszystkich wentylatorów. **Ostrzegamy - przez chwilę będzie dość głośno!**

KROK 9 Wizard: Door Sensor Calibration




- ✿ The first part that requires your interaction is the door sensor calibration. To begin, hit **Calibrate** and follow the on-screen instructions.
- ✿ You'll be prompted to gradually tighten the sensor tension screw from its default loose position - usually in half-turn steps, possibly several times during calibration.
- ✿ After each adjustment, observe the door sensor switch emerging from the front profile hole.
- ✿ Powtarzaj procedurę, aż czujnik drzwi zostanie prawidłowo wyregulowany, czyli aktywuje się w momencie otwarcia drzwi na szerokość wystarczającą do wsunięcia palców dłoni. Następnie naciśnij **Kontynuuj**.
- ❗ Gdy czujnik zostanie prawidłowo skalibrowany, w obszarze czujnika drzwi podczas otwierania i zamykania drzwi powinno być słyszalne kliknięcie.

KROK 10 Asystent: test tensometru



- ✿ The next step of the wizard will prompt you to touch the nozzle to test and calibrate the Loadcell. During this procedure, the **parts of the printer are not heated up** so that you can touch them. Hit **Continue**.
- ❗ Loadcell calibration requires the door to be open, as you must interact directly inside the printer.
- ✿ Do not touch the nozzle yet, wait until prompted by the **Tap nozzle NOW** message.
- ✿ Dotknij dyszy z dołu. Jeśli czujnik tensometryczny nie wykryje wystarczająco silnego dotyku, zostanie wyświetlony monit o powtórzenie tego etapu. Jeśli natomiast test się powiedzie, zobaczysz **Test tensometru OK**.
- ✿ Zamknij drzwiczki, aby pozwolić drukarce na kontynuowanie pracy.

KROK 11 Asystent: osiowanie przekładni




- ✿ Once you get to the Gearbox Alignment part, select **Continue** and follow the on-screen instructions.
- 🟠 Make sure the idler lock (swivel) is unlocked from the idler door.
- 🟢 Loosen the three screws on the front of the gearbox by 1.5 turns.
- 📄 **i** Drukarka wykona automatyczne osiowanie przekładni. Proces ten nie jest widoczny z zewnątrz.
- ⬛ Po wyświetleniu monitu dokręć trzy śruby w sposób wskazany na ekranie.

KROK 12 Wizard: Filament Sensor Calibration




- 🟠 Przesuń przełącznik kilka razy, aby go przetestować, a następnie **ustaw w pozycji włączonej**.
- ✿ During the filament sensor calibration, you will need to use a short piece of filament. Prepare the filament and select **Continue**.
- 📄 **i** There should be no filament inside the extruder before the calibration process starts.
- 🟡 Umieść szpulę filamentu w uchwycie po prawej stronie drukarki.
- 🟡 Po wyświetleniu monitu wsuń filament w rurkę PTFE znajdującą się pod prawym uchwytem.
- ⬛ Remove the filament after the calibration finishes.

KROK 13 Koniec pracy Asystenta



- ◆ Congratulations! The Wizard is complete. Now it's time to test some prints.

KROK 14 Czas na Haribo



- ◆ Victory tastes like gummy bears!
- ◆ Enjoy the rest. You've earned this.

KROK 15 Podręcznik



- Read the **3D Printing Handbook** dedicated to your printer and follow the instructions to set up the printer and prepare it for your first print.




The latest version is always available at help.prusa3d.com.



Read the Disclaimer and Safety instructions chapters.

KROK 16 Baza Wiedzy Prusa




If you encounter any problems at all, don't forget you can always check out our knowledge base at help.prusa3d.com



We're adding new topics every day!

KROK 17 Dołącz do Printables!



- 🟢 Don't forget to join the biggest Prusa community! Download the latest models in STL or G-code tailored for your printer. Register at [Printables.com](https://www.printables.com)
- 🟣 Looking for inspiration on new projects? Check our blog for weekly updates.
- 🟡 If you need help with the build, check out our forum with a great community :-)
- 📍 Do wszystkich usług firmy Prusa wystarczy jedno konto.

Lista zmian w instrukcji



KROK 1 Historia wersji



- **Wersje instrukcji montażu Prusa CORE One+:**
- 11/2025 - Wersja początkowa 1.00

[illegible]

[illegible]

Notes:

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across the entire width of the page, providing a guide for handwriting or typing. The background is a clean, off-white color.

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across the entire width of the page, providing a guide for writing. The background is a clean, off-white color. There are no margins, text, or other markings present.