

Indice

1. Introduzione	7
Passo 1 - Introduzione	8
Passo 2 - Informazioni generali	8
Passo 3 - Come navigare nel manuale	9
Passo 4 - Guida alle etichette	9
Passo 5 - ATTENZIONE: Manipolazione del lubrificante	10
Passo 6 - Siamo qui per te!	10
Passo 7 - Preparare la stampante	11
Passo 8 - Attrezzi necessari I.	11
Passo 9 - Attrezzi necessari II.	12
2. Aggiornamento della testina	13
Passo 1 - Liberare lo strumento	14
Passo 2 - Scollegare lo strumento	14
Passo 3 - Scoperchiare i cavi del Nextruder	15
Passo 4 - Rimuovere le coperture dwarf	15
Passo 5 - Info: Versione scheda Dwarf	16
Passo 6 - Liberare il Tool changer	16
Passo 7 - Rimuovere la ventola di stampa	17
Passo 8 - Rimuovere la ventola del dissipatore	17
Passo 9 - Rimuovere l'hotend	18
Passo 10 - Rimuovere l'ugello Prusa Nozzle	18
Passo 11 - Installazione dell'ugello Prusa Nozzle: preparazione dei componenti	19
Passo 12 - Installazione dell'ugello Prusa Nozzle	19
Passo 13 - Inserire l'hotend	20
Passo 14 - Nuova piastra dell'estrusore: preparazione dei componenti	20
Passo 15 - Montaggio della piastra dell'estrusore	21
Passo 16 - Installazione della piastra dell'estrusore	21
Passo 17 - Ventola di stampa: preparazione dei componenti	22
Passo 18 - Montaggio della ventola di stampa	22
Passo 19 - Montaggio della copertura della ventola	23
Passo 20 - Installazione della ventola di stampa	23
Passo 21 - Fissare l'hotend	24
Passo 22 - Installazione della ventola del dissipatore	24
Passo 23 - Rimozione della vecchia copertura della ventola dell'hotend	25
Passo 24 - Nuova copertura ventola hotend: preparazione dei componenti	25
Passo 25 - Installazione della nuova copertura ventola hotend	25
Passo 26 - Installazione del Tool changer	26
Passo 27 - Rimozione della vecchia piastra principale	26
Passo 28 - Nuova piastra principale: preparazione dei componenti	27
Passo 29 - Installazione della nuova piastra principale	27
Passo 30 - Assemblare l'anello PG-ring	28
Passo 31 - Assemblare il gruppo PG-assembly	28
Passo 32 - Controllo del gruppo PG-assembly	29
Passo 33 - Coprire l'ingranaggio planetario	29
Passo 34 - Nuova copertura Dwarf: preparazione dei componenti	30
Passo 35 - Montaggio della nuova base per la copertura Dwarf	30
Passo 36 - Coprire la scheda Dwarf	31
Passo 37 - Copertura dei cavi Dwarf	31
Passo 38 - Rimozione del vecchio connettore della copertura dwarf.	32


Passo 39 - Nuovo gruppo cavo principale: preparazione dei componenti	32
Passo 40 - Montare la nuova copertura connettore dwarf	33
Passo 41 - Rimuovere la vecchia cable-clip-click	33
Passo 42 - Installare la nuova cable-clip-click	34
Passo 43 - Collegare lo strumento	34
Passo 44 - Scoprire il retro	35
Passo 45 - Rimozione del gruppo dock degli strumenti I.	35
Passo 46 - Rimozione del gruppo dock degli strumenti II.	36
Passo 47 - Smontaggio del gruppo del dock degli strumenti	36
Passo 48 - Smontaggio della piastra del dock	37
Passo 49 - Nuovo gruppo Dock strumenti: preparazione dei componenti	37
Passo 50 - Montaggio della nuova piastra del dock	37
Passo 51 - Montaggio del nuovo dock-cable-router	38
Passo 52 - Montaggio del nuovo gruppo Tool Dock	38
Passo 53 - Installazione del gruppo tool dock I.	39
Passo 54 - Installing the new tool dock assembly II.	39
Passo 55 - Come montare lo strumento	40
Passo 56 - È fatta	40
3. Aggiornamento piano riscaldato	41
Passo 1 - Scopercchiare il controller del piano riscaldato	42
Passo 2 - Rimuovere la scheda del piano modulare	42
Passo 3 - Rimuovere il supporto bed-controller-mount-rear	43
Passo 4 - Sganciare i cavi	43
Passo 5 - Nuovi supporti per il controller del piano: preparazione dei componenti	44
Passo 6 - Assemblare i supporti bed-controller-mount I.	44
Passo 7 - Assemblare i supporti bed-controller-mount II.	45
Passo 8 - Come fissare il bed-controller-mount-rear	45
Passo 9 - Montaggio della scheda XL-CAN	46
Passo 10 - Collegamento dei cavi XL-CAN	46
Passo 11 - Modular bed controller fan: parts preparation	47
Passo 12 - Installazione della ventola del controller del piano	47
Passo 13 - Copertura del controller del piano modulare	48
Passo 14 - Gruppo raschietto ugello: preparazione dei componenti	48
Passo 15 - Assemblare il raschietto dell'ugello	49
Passo 16 - Montaggio del gruppo del raschietto	49
Passo 17 - Come montare il raschietto in silicone	50
Passo 18 - Offset sensor: parts preparation	50
Passo 19 - Collegamento del cavo del sensore di offset	51
Passo 20 - Frame-holder-cnc: preparazione dei componenti	51
Passo 21 - Rimozione delle viti	52
Passo 22 - Montaggio del supporto frame-holder-cnc	52
Passo 23 - Montaggio del sensore di offset	53
Passo 24 - È fatta	53
4. Printed parts and back cover upgrade	54
Passo 1 - Preparazione stampante	55
Passo 2 - Rilascio delle cinghie	55
Passo 3 - ATTENZIONE: Manipolazione del lubrificante	56
Passo 4 - Rimozione copertura X-carriage	56
Passo 5 - Rimozione del morsetto delle cinghie	57
Passo 6 - Rimozione cinghie	57
Passo 7 - Rimozione delle lamiere laterali	58
Passo 8 - Rimozione delle parti anteriori del CoreXY	58
Passo 9 - Smontaggio del gruppo anteriore sinistro del CoreXY	59

Passo 10 - Smontaggio del gruppo anteriore destro del CoreXY	59
Passo 11 - Nuovo gruppo tenditore CoreXY: preparazione dei componenti	60
Passo 12 - Montaggio del nuovo tenditore CoreXY	60
Passo 13 - Nuovo CoreXY anteriore sinistro: preparazione dei componenti	61
Passo 14 - Montaggio della nuova parte anteriore sinistra del CoreXY	61
Passo 15 - Installazione del CoreXY anteriore sinistro	62
Passo 16 - Nuovo CoreXY anteriore destro: preparazione dei componenti	62
Passo 17 - Montaggio della nuova parte anteriore destra del CoreXY	63
Passo 18 - Installazione del CoreXY anteriore destro	63
Passo 19 - Scoprire l'elettronica I.	64
Passo 20 - Smontare la copertura	64
Passo 21 - Scoprire l'elettronica II.	65
Passo 22 - Scoprire l'elettronica III.	65
Passo 23 - Scoprire l'elettronica IV.	66
Passo 24 - Liberare i cavi: lato sinistro	66
Passo 25 - Rimozione della barra LED	67
Passo 26 - Rimozione del gruppo posteriore destro del CoreXY	67
Passo 27 - Smontare il CoreXY sul retro a destra	68
Passo 28 - Rimozione dei distanziatori	68
Passo 29 - New CoreXY back right bottom: parts preparation	69
Passo 30 - Assemblare il CoreXY posteriore inferiore destro	69
Passo 31 - Nuovo CoreXY posteriore destro superiore: preparazione dei componenti	70
Passo 32 - Assemblare il CoreXY posteriore superiore destro	70
Passo 33 - Assemblare il CoreXY posteriore destro	71
Passo 34 - Installazione CoreXY sul retro a destra	71
Passo 35 - Smontaggio della puleggia del motore XY	72
Passo 36 - Nuova puleggia del motore: preparazione dei componenti	72
Passo 37 - Assemblare la nuova puleggia del motore	73
Passo 38 - Installazione del nuovo motore	73
Passo 39 - Installazione della barra LED	74
Passo 40 - Fissare i cavi	74
Passo 41 - Liberare i cavi: lato destro	75
Passo 42 - Rimozione della barra LED	75
Passo 43 - Rimozione del gruppo posteriore sinistro del CoreXY	76
Passo 44 - Smontaggio del CoreXY posteriore sinistro	76
Passo 45 - Rimozione dei distanziatori	77
Passo 46 - New CoreXY back left bottom: parts preparation	77
Passo 47 - Montaggio della parte posteriore sinistra in basso del CoreXY	78
Passo 48 - New CoreXY back left top: parts preparation	78
Passo 49 - Montaggio della parte posteriore sinistra in alto del CoreXY	79
Passo 50 - Montaggio della parte posteriore sinistra del CoreXY	79
Passo 51 - Installazione del CoreXY posteriore sinistro	80
Passo 52 - Smontaggio della puleggia del motore XY	80
Passo 53 - Nuova puleggia del motore: preparazione dei componenti	81
Passo 54 - Assemblare la nuova puleggia del motore	81
Passo 55 - Installazione del nuovo motore	82
Passo 56 - Installazione della barra LED	82
Passo 57 - Fissare i cavi	83
Passo 58 - Side metal covers: parts preparation	83
Passo 59 - Installing the side metal covers	84
Passo 60 - Rimozione delle clip della copertura posteriore superiore	84
Passo 61 - New upper back cover clips: parts preparation	85

Passo 62 - Installing the new upper back cover clips	85
Passo 63 - Copertura posteriore: preparazione dei componenti	86
Passo 64 - Fissaggio della copertura posteriore I.	86
Passo 65 - Fissaggio della copertura posteriore II.	87
Passo 66 - Nuova copertura dell'elettronica: preparazione dei componenti	87
Passo 67 - Montare la nuova copertura	88
Passo 68 - Ventilatore XL Buddy: preparazione dei componenti	88
Passo 69 - Installazione del ventilatore XL Buddy	89
Passo 70 - Dissipatore XL Buddy: preparazione dei componenti	89
Passo 71 - Installazione del dissipatore	90
Passo 72 - Collegamento del ventilatore XL Buddy	90
Passo 73 - Come collegare la scheda XL Buddy	91
Passo 74 - Coprire l'elettronica	91
Passo 75 - Nuove coperture dei cavi dell'alimentatore: preparazione dei componenti	92
Passo 76 - Sostituzione delle coperture dei cavi dell'alimentatore	92
Passo 77 - Removing the old bed energy chain mount	93
Passo 78 - New bed energy chain mount: parts preparation	93
Passo 79 - Installing the new bed energy chain mount	94
Passo 80 - Rimozione della copertura anteriore del telaio	94
Passo 81 - Nuova copertura anteriore del telaio: preparazione dei componenti	95
Passo 82 - Installing the new right frame front cover	95
Passo 83 - Installing the new left frame front cover	96
Passo 84 - Nuova Clip della copertura: preparazione dei componenti	96
Passo 85 - Rimuovere la clip della copertura	97
Passo 86 - Installazione della nuova clip di fissaggio della copertura	97
Passo 87 - Sostituzione delle clip della copertura I.	98
Passo 88 - Sostituzione delle clip della copertura II.	98
Passo 89 - Regolazione del piano riscaldato	99
Passo 90 - Sostituzione delle clip della copertura III.	99
Passo 91 - Rimozione dell'alloggiamento del cuscinetto dell'asse Z	100
Passo 92 - Nuovo alloggiamento del cuscinetto dell'asse Z: preparazione dei componenti	100
Passo 93 - Installing the new Z axis bearing housing I.	101
Passo 94 - Installing the new Z axis bearing housing II.	101
Passo 95 - Rimozione del supporto della catena portacavi dal telaio	102
Passo 96 - Nuovo supporto per catena portacavi: preparazione dei componenti	102
Passo 97 - Installazione del nuovo supporto per la catena portacavi	103
Passo 98 - È fatta	103
5. Aggiornamento delle cinghie e del porta bobina	104
Passo 1 - Fissaggio della cinghia: informazioni importanti	105
Passo 2 - Fissaggio della cinghia: preparazione dei componenti	105
Passo 3 - Fissaggio della cinghia inferiore: lato anteriore destro	106
Passo 4 - Fissaggio della cinghia inferiore: lato posteriore destro	106
Passo 5 - Fissaggio della cinghia inferiore: lato posteriore sinistro	107
Passo 6 - Fissaggio della cinghia inferiore: preparazione puleggia motore	107
Passo 7 - Fissaggio della cinghia inferiore: fissaggio puleggia motore	108
Passo 8 - Fissaggio della cinghia inferiore: lato sinistro	108
Passo 9 - Fissaggio della cinghia inferiore: morsetto della cinghia	109
Passo 10 - Fissaggio della cinghia inferiore: fissaggio del morsetto della cinghia	110
Passo 11 - Fissaggio della cinghia superiore: lato anteriore sinistro	111

Passo 12 - Fissaggio della cinghia superiore: lato posteriore sinistro	111
Passo 13 - Fissaggio della cinghia superiore: lato posteriore destro	112
Passo 14 - Fissaggio della cinghia superiore: fissaggio puleggia motore	112
Passo 15 - Fissaggio della cinghia superiore: lato destro	113
Passo 16 - Fissaggio della cinghia superiore: morsetto della cinghia	113
Passo 17 - Fissaggio della cinghia inferiore: fissaggio del morsetto della cinghia	114
Passo 18 - Tensionamento della cinghia	114
Passo 19 - Tensione della cinghia: video	115
Passo 20 - Copertura del carrello X: preparazione dei componenti	115
Passo 21 - Attaccare la copertura carrello X	115
Passo 22 - Copertura Core XY: preparazione dei componenti	116
Passo 23 - Attaccare la copertura CoreXY	116
Passo 24 - Fissaggio della copertura CoreXY	117
Passo 25 - Rimuovere il porta bobina	117
Passo 26 - Nuovo porta bobina: preparazione dei componenti	118
Passo 27 - Installare il disco del supporto bobina	118
Passo 28 - Assemblare il porta bobina	118
Passo 29 - È fatta	119
6. Completamento	120
Passo 1 - Prima di iniziare con il Multi-Tool	121
Passo 2 - Calibrazione dell'altezza della guarnizione dell'ugello	121
Passo 3 - Calibrazione dell'altezza della guarnizione dell'ugello	122
Passo 4 - Preparare la stampante	122
Passo 5 - Aggiornamento Firmware	123
Passo 6 - Configurazione guidata: Configurazione della rete e di Prusa Connect	123
Passo 7 - Configurazione guidata: Test di calibrazione	124
Passo 8 - Configurazione guidata: Calibrazione della posizione del Dock	125
Passo 9 - Configurazione guidata: Rimuovere i perni del dock	125
Passo 10 - Configurazione guidata: Allenta le viti	126
Passo 11 - Configurazione guidata: Blocca lo strumento	126
Passo 12 - Configurazione guidata: Stringi la vite superiore	127
Passo 13 - Configurazione guidata: Stringi la vite inferiore	127
Passo 14 - Configurazione guidata: Installa i perni del dock	128
Passo 15 - Configurazione guidata: Dock calibrato correttamente	128
Passo 16 - Configurazione guidata: Test della cella di carico	129
Passo 17 - Wizard - Calibrazione dei sensori del filamento	129
Passo 18 - Wizard - Calibrazione dei sensori del filamento	130
Passo 19 - Configurazione guidata: Phase stepping	131
Passo 20 - È fatta	131
Passo 21 - Calzino Nextruder Prusa (Opzionale)	132
Passo 22 - Manutenzione regolare della stampante	132
Passo 23 - Una veloce guida per le prime stampe	133
Passo 24 - Modelli 3D stampabili	133
Passo 25 - Dacci il tuo feedback	134
Passo 26 - Nozioni base Prusa	134
Passo 27 - Unisciti a Printables!	135
Registro modifiche del manuale	136
Passo 1 - Storico versioni	137

1. Introduzione





PASSO 1 Introduzione




- This guide will take you through the **upgrading your Original Prusa XL to XL+.**
- **Do not discard any parts unless instructed to do so.**
- This also applies to the fasteners; you will reuse some of them later again.

PASSO 2 Informazioni generali



- **Per il montaggio prepara una superficie di lavoro pulita con uno spazio di almeno 1,5 m x 1,5 m (59" x 59").**
 - Si consiglia di posizionare una luce intensa sopra il banco di lavoro. Alcune parti della stampante sono buie e una luce insufficiente potrebbe rendere più difficile l'assemblaggio.
- ⚠ In some of the pictures throughout this guide, the toolheads **have been removed** to provide a clearer view of the assembly. Don't worry if your printer currently has them installed! Whenever the toolheads are important for a specific step, they will be **clearly visible** in the illustrations.

PASSO 3 Come navigare nel manuale





- Usa i pulsanti grafici di navigazione nell'angolo in basso a destra o i tasti freccia della tastiera:
 - **Pulsante successivo / Tasto freccia destra** - Passa all'immagine successiva o alla fase successiva se si tratta dell'ultima immagine della fase.
 - **Pulsante freccia sinistra / Tasto freccia sinistra** - Passa all'immagine precedente o alla fase precedente se si tratta della prima immagine della fase.
 - **Pulsante Play indietro / Tasto freccia su** - Vai al passo precedente.
 - **Pulsante Play Avanti / Tasto freccia giù** - Vai al passo successivo.
- Clicca su **Contenuti** per espandere l'elenco completo dei passi di questa guida. Questo ti permette di saltare a qualsiasi passo, indipendentemente dalla sequenza.
- Clicca su **Commenti** per aprire la discussione su un passo specifico e lasciare il tuo feedback.

PASSO 4 Guida alle etichette



- i Tutte le scatole e le buste che contengono i pezzi necessari per il montaggio sono etichettate.
- La busta Fasteners include un ricambio extra di ogni parte contenuta nella busta. La quantità di ricambi è riportata sull'etichetta. Questo numero è incluso nel numero totale di ogni tipo di pezzo.



PASSO 5 ATTENZIONE: Manipolazione del lubrificante



⚠ ATTENZIONE: evita il contatto diretto sulla pelle con il lubrificante utilizzato per le guide lineari di questa stampante. In caso di contatto, lavati immediatamente le mani. Soprattutto prima di mangiare, bere o toccarsi il viso.


- Il lubrificante si accumula nei cuscinetti della stampante, soprattutto nei canali delle guide lineari.

PASSO 6 Siamo qui per te!



- Ti sei perso nelle istruzioni, ti manca una vite o hai una parte stampata rotta? **Faccelo sapere!**
- Puoi contattarci utilizzando i seguenti canali:
 - I commenti sotto ogni passo.
 - La nostra live chat 24 ore su 24, 7 giorni su 7 su shop.prusa3d.com
 - Scrivendo una mail a info@prusa3d.com


PASSO 7 Preparare la stampante



Prima di iniziare:

- Perform an **Auto Home**. Go to **Menu -> Control -> AutoHome**.
 - ⓘ This will move the heatbed to the top position, providing easier access to its underside.
- Unload all filaments from the printer. No filament must remain loaded in any print head.
- Remove all filament spools from the spool holders.
- Make sure all tools are parked in their docks. Go to **Menu -> Control -> Pick/Park tool -> Park Current Tool** and repeat for each tool if necessary.
- ⚠ Before proceeding, **make sure the printer has cooled down to room temperature**. Go to **Menu -> Preheat -> COOLDOWN** and wait approximately 10 minutes for the temperature to stabilize.
- Turn off and unplug the printer.

PASSO 8 Attrezzi necessari I.



Per questa guida prepara:

- Chiave a brugola da 2.0mm
- Chiave a brugola da 2.5mm
- Chiave a brugola da 3.0mm
- Chiave a brugola da 4.0mm
- Chiave Torx T8
- Chiave Torx T10

- ⓘ You can also use a T10 screwdriver, which is included in the package.

PASSO 9 Attrezzi necessari II.



- **Per questa guida prepara:**
- Pinza a becchi lunghi
 - Cacciavite Torx T10
 - Chiave universale
 - Chiave 13-16
 - Side cutters *for cutting zip ties*

2. Aggiornamento della testina



PASSO 1 Liberare lo strumento




- Turn the printer so that the front side is facing you.
- It is highly recommended to place a soft protective layer (e.g., bubble wrap) on the heatbed.
 - Then place an empty cardboard box on top of it.
- Pull the first tool (from the left) out to the left to release it.
- Place the released tool on the cardboard box.

PASSO 2 Scollegare lo strumento



- Release, but do not remove two screws securing the flexible plate. 2-3 turns are enough.
- Unhook the flexible plate from the screws.
- Push the black collet on the fitting in to unlock the PTFE tube.
- Pull off the PTFE tube from the fitting.
- Loosen the two screws securing the main cable connector cover.
- Unplug the main cable from the Nextruder.
- ⚠ **Warning: The connector has a safety latch that must be pressed to release the cable.**
- Remove the Nextruder from the box and place it on the workbench. Repeat the same procedure for the remaining tools.


PASSO 3 Scopercchiare i cavi del Nextruder



i The following steps describe the upgrade process for one tool only. **Repeat the same procedure for all remaining tools.** It is recommended to **fully complete one tool before continuing with the next.**

-  Togli la vite che fissa la copertura Dwarf-cover-door.
-  Remove the Dwarf-cover-door and discard it. It will no longer be needed.
-  Carefully cut the zip tie securing the Nextruder cables. **Avoid cutting the cables.**
-  Disconnect the three cables in the right row of connectors.
-  Disconnect the heatsink fan cable and hotend thermistor cable from the left row of connectors.

PASSO 4 Rimuovere le coperture dwarf



-  Togli le due viti che fissano la copertura Dwarf-cover-back.
-  Slide the Dwarf-cover-base (the top part) out of the Nextruder.
-  Slide the Dwarf-cover-back down and remove it from the Nextruder.

PASSO 5 Info: Versione scheda Dwarf




- **Check the Dwarf board version. Some versions require replacement.**
- The board version is printed on the back of the board.
 - ❗ Typically versions 08|2024-12|cMC, etc. **The first two digits (08)** represent the board version.
- **Dwarf board versions 07 and earlier are not compatible** with the XL+ upgrade.
 - If this version is installed, replace the Dwarf board using the dedicated guide [How to replace a Dwarf board \(XL multi-tool\)](#).
 - ❗ Follow only the steps required for the board replacement. The Nextruder has already been partially disassembled.
 - After replacing the Dwarf board, return to this guide and continue from this step.

PASSO 6 Liberare il Tool changer




- Unscrew the M3x30 screw attaching the Tool changer to the heatsink fan.
- From the opposite side of the Nextruder, remove two screws securing the Tool changer.
- Disconnect the tool changer cable from the Tool changer.
 - ⚠ **Warning: The connector has a safety latch that must be pressed to release the cable.**

PASSO 7 Rimuovere la ventola di stampa



- ◆ Unscrew two screws securing the fan-shroud and remove it from the Nextruder.
- ◆ Remove the screw securing the print fan, then move the print fan aside.
- ⓘ The print fan will be fully removed in the following steps. Removing now would result in damaging the print fan cable.

PASSO 8 Rimuovere la ventola del dissipatore




- ◆ Loosen the screw securing the heatsink fan.
- ◆ Remove the heatsink fan from the Nextruder.
- ◆ Release two screws holding the extruder plate (metal sheet).
- ◆ Rimuovi l'estrusore.
- ⓘ This part will no longer be needed.

PASSO 9 Rimuovere l'hotend



- From the heatsink side, loosen the set screw securing the hotend. **Do not remove it completely**; 2-3 turns are sufficient.
- Carefully slide the hotend assembly out of the heatsink.
- If a silicone sock is installed on the hotend, remove it.

PASSO 10 Rimuovere l'ugello Prusa Nozzle




- Using the wrench 13-16 grasp the heaterblock.
- Using the 7mm cutout in the universal wrench, grasp the nozzle and loosen it.
- Manually release and remove the Prusa Nozzle from the hotend assembly.

PASSO 11 Installazione dell'ugello Prusa Nozzle: preparazione dei componenti




- Per i seguenti passi prepara:
- Nuovo ugello Prusa Nozzle CHT (1x)

PASSO 12 Installazione dell'ugello Prusa Nozzle




- Insert the nozzle all the way into the heaterblock until the nozzle touches the heaterblock surface.
- Grasp the heaterblock with the wrench 13-16.
- Using the 7mm cutout in the universal wrench, tighten the nozzle against the heaterblock. Do not use any extra force!
- ⓘ The specified torque value is 1.5 Nm (13.3 lb-in).
- Reinstall the silicone sock on the hotend.

PASSO 13 Inserire l'hotend



- Fully insert the hotend assembly into the heatsink.
- Lightly tighten the set screw to secure the hotend.
⚠ Do not fully tighten the set screw. The hotend must still be able to rotate. It will be completely tightened later.
- Plug the hotend thermistor to the connector labeled HE HT.
- Plug the hotend heater to the black connector on the right.

PASSO 14 Nuova piastra dell'estrusore: preparazione dei componenti




- Per i seguenti passi prepara:
- Nuova piastra estrusore (1x)
- M3x6 spacer (3x) *make sure you are using the new part, **not the old one***
- Vite M3x4rT (3x)

PASSO 15 Montaggio della piastra dell'estrusore



- ✚ Insert three M3x4rT countersunk screws into the extruder plate.
- ✚ From the opposite side, screw three M3x6 spacers onto the screws. Tighten them using a T10 screwdriver and a universal wrench.

PASSO 16 Installazione della piastra dell'estrusore



- ✚ Route the tool changer cable under the heatsink.
- ✚ From the underside of the heatsink, place the assembled extruder plate with the spacers facing the heatsink.
- ⬛ Align the part with the holes. Make sure the orientation is correct by checking the two-holes side tab.
- ✚ Fissalo con due viti M3x10.

PASSO 17 Ventola di stampa: preparazione dei componenti



● Per i seguenti passi prepara:

- Ventola di stampa (1x)
- Nuovo fan-case (1x)
- Nuova copertura della ventola (1x)
- Vite M3x14 (3x)
- Vite M3x8rt (1x)
- Dado M3nS (1x)
- Fascetta (1x)

PASSO 18 Montaggio della ventola di stampa




- Insert the print fan into the xls-fan-case.
- Guide the print fan cable through the cutout in the case.
- Route the cable in the cable channel.
- Inserisci un dado M3nS nel supporto xls-fan-case.

PASSO 19 Montaggio della copertura della ventola



- Align the **tab on the case** with the **slot on the fan-shroud**.
- Hook the fan-shroud onto the tab on the case.
- Chiudi la copertura della ventola.
- Fissalo con una vite M3x8rT.

PASSO 20 Installazione della ventola di stampa




- Turn the Nextruder so the rear side is facing up and align it with the print fan assembly.
- Warning: Ensure the fan-shroud fits correctly onto the hotend. If needed, rotate the hotend to achieve proper alignment.
- When inserting, make sure the cut-out aligns with the Nextruder sheet metal.
- Fissa i componenti con tre viti M3x14.

PASSO 21 Fissare l'hotend




- ✦ Finally adjust the hotend orientation so it matches the shape of the fan-shroud.
- ✦ Keep the hotend in the same orientation and **push it fully in**.
- ⚠ **The brass collar of the nozzle core must be barely visible.**
- ✦ Secure it by fully tightening the set screw.
- ✦ Connect the print fan cable to the second connector in the left row on the Dwarf board.

PASSO 22 Installazione della ventola del dissipatore




- ✦ Place the heatsink fan on the extruder plate so the cable is in the upper right corner.
- ✦ Make sure the fan is positioned so the cable is coming from the upper right corner.
- ✦ Secure it with one M3x20rT screw in the upper left corner.
- ✦ Plug the heatsink fan into the remaining free connector in the right row on the Dwarf board.
- ✦ Using a zip-tie, bundle the cables together and cut off the excess plastic.

PASSO 23 Rimozione della vecchia copertura della ventola dell'hotend



- Rimuovi le due viti M3x8bT.
📌 Make sure to keep the screws close for the next step.
- Togli la vecchia protezione della ventola dell'hotend.

PASSO 24 Nuova copertura ventola hotend: preparazione dei componenti




- Per i seguenti passi prepara:
- Nuovo scudo per la ventola dell'hotend (1x)
- Vite M3x8bT (2x)
- Viti M3x8rT (2x)
- Vite M3x30 (1x)

PASSO 25 Installazione della nuova copertura ventola hotend




- Align the holes of the hotend fan shield with the holes on the Tool changer.
- Fissalo con due viti M3x8bT.

PASSO 26 Installazione del Tool changer



- Plug the Tool changer cable to the Tool changer.
- Place the Tool changer on the Nextruder.
- Fissalo con la vite M3x30.
- From the opposite side of the Nextruder, secure the Tool changer using two M3x8rT screws.

PASSO 27 Rimozione della vecchia piastra principale




- Remove the three M3x25 screws and the Extruder front case.
- Carefully lift up the G assembly out of the old main plate.
- Rimuovi la vecchia piastra principale.
- ⚠ **Locate the metal washer that should be between the gearbox and the motor. It might be stuck to the PG assembly.**
- Riposiziona la rondella/spessore sull'albero del motore, nel caso in cui si sia staccata dall'albero.

PASSO 28 Nuova piastra principale: preparazione dei componenti




- Per i seguenti passi prepara:
- PG-assembly-adapter (1x)
- Nuova piastra principale main-plate (1x)

PASSO 29 Installazione della nuova piastra principale



- Posiziona la piastra principale sul dissipatore. Prendi nota dell'orientamento del componente. Usa il ritaglio come guida.
- Monta l'adattatore PG-assembly-adapter sul gruppo PG. Nota le tasche per gli ingranaggi nell'adattatore.
- Achieve better understanding and successful assembly by watching the video alongside the guide: prusa.io/PG-assembly.


PASSO 30 Assemblare l'anello PG-ring



⚠ Non assemblare il riduttore senza l'adattatore PG-assembly-adapter. Questo strumento serve a garantire che gli ingranaggi vengano montati correttamente.

- Fai scorrere l'anello PG-ring sull'adattatore.
- Note there is a chamfer on one side of the PG-ring teeth. This side must be facing down (to the PG-assembly).
- Grasp the entire assembly in one hand so that it can be rotated with the PG-ring.
- With the other hand, slide the PG-ring onto the PG assembly in a wobbling motion (move the PG-ring left and right repeatedly) - a quarter turn is enough.
- Stop when the surfaces of the gears are approximately flush with the surface of the PG ring.


PASSO 31 Assemblare il gruppo PG-assembly



⚠ Procedi con molta attenzione in questa fase.


- Maintain the position of the PG-assembly and attach it on to extruder motor shaft.
- Very gently and freely wiggle with the whole PG assembly (PG-assembly-adapter, PG-assembly and PG-ring) until it drops down so that there is no gap between the assembly and the main-plate. Do not push on the assembly.
- Rimuovi il PG-assembly-adapter.

PASSO 32 Controllo del gruppo PG-assembly



- Ricollega nuovamente l'adattatore PG-assembly-adapter sul gruppo PG-assembly per verificare che tutte le parti siano posizionate correttamente.
- Rotate with the PG-assembly-adapter. **The PG assembly must be easy to rotate without having to exert much force.**
- Rimuovi l'adattatore PG. Non ti servirà più durante l'assemblaggio. Ti consigliamo di conservarlo per la manutenzione.
- Ensure that the PG-assembly is not sticking out above the PG-ring. It should be positioned lower than the level of the PG-ring's surface or at the same level as the ring.
- Ensure that the gap between the PG-ring and the Main-plate is minimal. If a significant gap is observed, disassemble the planetary gear assembly and reposition it.

PASSO 33 Coprire l'ingranaggio planetario



- Posiziona la copertura frontale sul riduttore e fissala con tre viti M3x25. **Non stringerle a fondo** in questo momento.
- ① The screws on the front case will be completely tightened during the self-test in the final chapter.

PASSO 34 Nuova copertura Dwarf: preparazione dei componenti



Per i seguenti passi prepara:

- Nuovo dwarf-cover-base (1x)
- Nuovo dwarf-cover-back (1x)
- Nuovo dwarf-cover-door (1x)
- Vite M3x8bT (2x)
- Vite M3x16 (1x)
- Dado M3nS (4x)
- Dado M3nN (1x)

PASSO 35 Montaggio della nuova base per la copertura Dwarf




- Insert two M3nS nuts into the designated openings.
- Insert the other two M3nS nuts into these designated openings.
- Insert the M3nN nut into the dwarf cover base side.
- i** Ti consigliamo di usare la tecnica di tiro della vite dal lato opposto.

PASSO 36 Coprire la scheda Dwarf




-  In the correct orientation, slide the dwarf-cover-base onto the Dwarf board. Insert it into the rails.
-  Place the dwarf-cover-back onto the Dwarf board, slide it upward, and align the holes.
-  Fissalo con due viti M3x6rT.

PASSO 37 Copertura dei cavi Dwarf



-  Before closing the electronics cover, ensure all cables are correctly connected and not protruding from the compartment.
-  Attach the dwarf-cover-door to the Nextruder and ensure it sits flush all around.
-  Secure it with an M3x16 screw. **Do not overtighten it;** the cover must remain easy to open.

PASSO 38 Rimozione del vecchio connettore della copertura dwarf.



- Remove the M3x10 screw from the top of the dwarf cover connector.
- Remove the dwarf cover connector by pulling the sides of it apart.

PASSO 39 Nuovo gruppo cavo principale: preparazione dei componenti



■ Per i seguenti passi prepara:


- Nuovo cable-clip-click (5x)
- Nuova copertura connettore dwarf
- Vite M3x10 (3x)
- Dado M3nN (1x)

PASSO 40 Montare la nuova copertura connettore dwarf




- Insert the M3nN nut into the hexagonal opening of the dwarf connector
- Insert the main cable into the Dwarf cover connector.
⚠ Pay attention to the **orientation** of the plastic part.
- Leave a little bit of extra length on the main cable outside the dwarf cover connector.
- Carefully push the two halves of the Dwarf cover connector together.
⚠ **Pay close attention not to pinch any cables between the plastic parts before you tighten the screw!**
- Secure the parts together by tightening the M3x10 screw.

PASSO 41 Rimuovere la vecchia cable-clip-click




- Pull the PTFE tube out of the cable-clip-click
- Open the clip by pushing on each side of the clip in opposite directions
- Stacca il cavo principale dal fermaglio cable-clip-click
- Togli la vecchia cable-clip-click

PASSO 42 Installare la nuova cable-clip-click




- 🟠 Attach the new cable-clip-click onto the flexible plate.
- 🟡 Inserisci il cavo principale nel fermaglio cable-clip-click.
- 🟢 Close the clip by pressing both sides together until they snap into place.
- 🟣 Push the PTFE tube into the designated groove on the cable-clip-click.
- 🔴 Repeat the entire removal and installation procedure for the four remaining clips. Always replace them one at a time.
- 🟦 Always install the cable-clip-click inside the notches on the flexible plate.

PASSO 43 Collegare lo strumento



- ⬛ Place the Nextruder assembly back onto the printer box.
- 🔴 Collega il cavo principale al Nextruder.
- 🟢 Secure the connector with two M3x10 screws.
- 🟢 Fully insert the PTFE tube into the fitting as far as it will go.
- 🟠 Hook the flexible plate onto the pre-installed screws on the tool changer.
- ⚠️ **Make sure the flexible plate is not twisted.**
- 🟡 Gently pull the flexible plate to properly hook it onto the screws.
- 🟣 Stringi completamente le viti.

PASSO 44 Scoprire il retro




- Remove the six M3x8bT screws from the back metal plate.
- Carefully unplug the PE faston connector from the inside of the back metal plate.
- Slide the corners of the back metal plate out from under the side metal plates to remove it completely.

PASSO 45 Rimozione del gruppo dock degli strumenti I.



- Carefully** cut the zip ties on the dock-cable-router.
 **Pay close attention not to cut any cables!**
- Push the black collet on the filament sensor **in** to unlock the PTFE tube.
- Pull off the PTFE tube from the black collet.
- Pull the PTFE tube completely out of the dock-cable-router.

PASSO 46 Rimozione del gruppo dock degli strumenti II.



- Remove the two M3x14 screws from the dock-cable-router to free the flexible plate.
 - Using the 2.5mm allen key, fully loosen the M3xbT screw from the middle hole.
 - Carefully remove the Tool dock assembly from the rest of the printer.
- ⚠ Make sure to **avoid causing any harm** to the printer's frame.

PASSO 47 Smontaggio del gruppo del dock degli strumenti



- Using the TX8 torx key, fully loosen the two M3x12bT screws inside the holes.
 - Pull the dock plate away from the rest of the assembly.
 - Fully loosen the M3x30 screw and remove the entire nozzle seal assembly.
- ⚠ Make sure you are loosening the right screw (as shown in the picture).
- 📌 We recommend keeping the nozzle seal assembly together for easier assembly afterwards.

PASSO 48 Smontaggio della piastra del dock



- Remove the M3x12bT screw from the dock-plate assembly.
- Remove the old nozzle parking-tool-finger-guide. from the dock plate.

PASSO 49 Nuovo gruppo Dock strumenti: preparazione dei componenti



- Per i seguenti passi prepara:
- Nuovo dock-cable-router (1x)
 - Nuovo parking-tool-finger-guide (1x)
 - Vite M3x12bT (3x)
 - Vite M3x14 (1x)
 - Viti M3x8rT (2x)
 - Dado M3nS (1x)
 - Dado M3nN (2x)

PASSO 50 Montaggio della nuova piastra del dock



- Align the dock plate with the slot on the new parking-tool-finger-guide.
- Secure the two parts together using an M3x12bT screw.

PASSO 51 Montaggio del nuovo dock-cable-router



- Insert the M3nS nut into the slot on the dock-cable-router.
- Insert two M3nN nuts into the two slots.
⚠ Ti consigliamo di usare la tecnica di tiro della vite dal lato opposto.
- Push two M3x12bT screws through the front of the new dock-cable-router:
 - Insert the upper screw through the hole on the top.
 - Insert the lower screw through the hole on the side.

PASSO 52 Montaggio del nuovo gruppo Tool Dock




- Insert the entire parking-plate assembly into the dock-cable-router. Pay close attention to the correct orientation!
- **Stringi leggermente** la vite M3x30.
- Push the M3x14 through the middle hole in the bottom of the tool-changer.
- Press the tool-changer firmly against the dock-cable-router.
- Fully tighten the two M3x12bT screws using the **TX8 torx key**.

PASSO 53 Installazione del gruppo tool dock I.



- Slide the Tool dock assembly under the belts.
- Align the M3x14 screw with the hole on the metal plate.
- Fully tighten the M3x14 screw using the 2.5mm allen key.

PASSO 54 Installing the new tool dock assembly II.



- Place the flexible plate into the groove of the dock-cable-router.
- Secure the flexible plate with two M3x8rT screws.
- Insert the PTFE tube through the opening on the dock-cable-router.
- Push the PTFE into the black collet fitting in the filament sensor as far as possible.
- Route the main cable through the groove on the dock-cable-router.
- Secure the main cable with two zip ties.

⚠ Pay attention to the correct orientation of the zip tie!

PASSO 55 Come montare lo strumento



- Place the tool from the left onto the first dock. Align the two pins with the dock holes, then insert them to park the tool.

i This will snap the tool into place, allowing you to release it.

PASSO 56 È fatta




- Ripeti questi passaggi per tutte le testine.
- Compare the final look of the assembly with the picture.
- Let's continue to the next chapter: **Heatbed upgrade.**

3. Aggiornamento piano riscaldato




PASSO 1 Scoperciare il controller del piano riscaldato



- 🟢 Locate the plastic electronics box on the underside of the heatbed.
- 🟡 Using the T10 screwdriver, unscrew four M3x20rT screws and remove the cover.
- 🟣 Rimuovi la copertura dei componenti elettronici.
- ⚠️ **Fai attenzione a non danneggiare i componenti elettronici.**

PASSO 2 Rimuovere la scheda del piano modulare




- 🟢 Using the T10 screwdriver, unscrew four M3x10rT screws securing the modular bed board.
- 🟣 Carefully release the modular bed board and let it hang freely on the cables of the individual heatbed tiles.
- 🟡 Remove the XL-bed-controller-mount-front from either the underside of the heatbed or the electronics board.
- 🔴 Remove the Modular Bed PCB shield from either the underside of the heatbed or the electronics board. **Keep it aside, as you will reuse it later.**





Note: The Modular Bed PCB shield may not be present on all printers, as it was added in a later hardware update. If you do not have it, please contact our Tech Support.

PASSO 3 Rimuovere il supporto bed-controller-mount-rear




- Remove the XL-bed-controller-mount-rear (printed part) from the top of the board.

PASSO 4 Sganciare i cavi



- On the underside of the board, pull the lower part of the power cable guide.
- From the top side, remove the upper part of the cable guide.


PASSO 5 Nuovi supporti per il controller del piano: preparazione dei componenti



Per i seguenti passi prepara:

- Nuovo bed-controller-mount-rear (1x)
- Nuovo bed-controller-mount-front (1x)
- Dado M3nN (4x)
- Dado M3nS (2x)
- Viti M3x8rT (2x)
- Vite M3x12rT (4x)
- Scheda XL-CAN (1x)
- XL+ Modular bed CAN cable (1x)

PASSO 6 Assemblare i supporti bed-controller-mount I.



- Insert two M3nS nuts into the bed-controller-mount rear from the inner sides.
- Turn the bed-controller-mount-rear over and insert two M3nN nuts.
- Insert two M3nN nuts into the bed-controller-mount-front.



Ensure the M3nS nuts are fully inserted so their threads align with the holes in the printed part.


PASSO 7 Assemblare i supporti bed-controller-mount II.



The Modular Bed PCB shield is reused from the printer.


- Insert the Modular Bed PCB shield into the slots in the bed-controller-mount-rear.
- Insert it so far that the holes align.

PASSO 8 Come fissare il bed-controller-mount-rear




- Slide the bed-controller-mount-rear onto the Modular Bed Controller Board using the grooves, and push it in fully until seated.
- Slide the bed-controller-mount-front onto the front side of the Modular bed controller board.
- Position the Modular Bed Controller assembly at the center of the underside of the heatbed and secure it with four M3x12rT screws.

PASSO 9 Montaggio della scheda XL-CAN



- Disconnect the Modular bed controller cable.
- ⚠ Be careful: the connector has a **safety latch** that must be pressed while disconnecting.
- Position the XL-CAN board onto the bed-controller-mount-rear and align it.
- Secure it with two M3x8rT screws.

PASSO 10 Collegamento dei cavi XL-CAN



- Connect the Modular Bed Controller cable to the **right slot**.
- Connect the Modular Bed Controller board to the XL-CAN board using the XL+-ModularBed-CAN cable and the marked connectors.

PASSO 11 Modular bed controller fan: parts preparation



Per i seguenti passi prepara:



- Nuovo bed-controller-case (1x)
- Ventola del controller del piano (1x)
- Vite M4x10r (2x)
- Vite M3x30 (4x)

PASSO 12 Installazione della ventola del controller del piano



- Position the fan on the inner side of the XL+-bed-modular-case.
- Ensure correct orientation:**
 - L'adesivo è rivolto verso l'alto.
 - The fan cable is routed to the left toward the rear (lower) side.
- Hold the fan in place, flip the assembly over, and fasten it with two M4x10r screws.

PASSO 13 Copertura del controller del piano modulare



- ◆ Connect the fan to the right connector on the XL-CAN board.
- ◆ Cover the Modular bed controller with the new bed-controller-case and secure it with four M3x30 screws.

PASSO 14 Gruppo raschietto ugello: preparazione dei componenti




- ◆ **For the following steps, please prepare:**
- ◆ Bed-wiper-top (1x)
- ◆ Bed-wiper-bottom (1x)
- ◆ Spazzola in silicone per ugello (1x)
- ◆ Giunto di espansione (1x)
- ◆ Dado M3nS (2x)
- ◆ Vite M3x6 (2x)
- ◆ Vite M3x6r (1x)

PASSO 15 Assemblare il raschietto dell'ugello




- Insert the M3x6r screw into the expansion joint with the screw head first.
- Insert a 2.0 mm Allen key through the threaded hole to reach the screw.
- Attach the expansion joint to the Bed-wiper-top and tighten the screw. Do not overtighten it.
- Insert the two M3nS nuts into the designated holes.

PASSO 16 Montaggio del gruppo del raschietto



- Insert the bed-wiper-bottom into the designated space of the bed frame.
- Make sure it is aligned correctly matching the frame's shape.
- Place the bed-wiper-top in the designated space on top of the frame.
- Secure the two bed wiper parts together with two M3x6 screws.

PASSO 17 Come montare il raschietto in silicone




- ◆ Peel off the protective layer from the nozzle wiper pad.
- ① The pad is adhesive underneath the protective layer. **Avoid touching the adhesive surface.**
- ◆ Insert the nozzle wiper pad into the matching recess in the nozzle wiper assembly.
- ◆ Run your finger over the entire surface of the nozzle wiper pad several times to ensure it is evenly adhered and fully seated.

PASSO 18 Offset sensor: parts preparation



- ◆ **For the following steps, please prepare:**
- ◆ Offset sensor (1x)
- ◆ Offset sensor cable (1x)

PASSO 19 Collegamento del cavo del sensore di offset




- Plug the offset sensor cable to the left connector on the XL-CAN board.
- Leave the other end of the cable hanging freely.

PASSO 20 Frame-holder-cnc: preparazione dei componenti




- Per i seguenti passi prepara:
- Frame-holder-cnc (1x)
- Vite M3x12rT (2x)

PASSO 21 Rimozione delle viti




- From the underside of the heatbed frame, use a 2 mm Allen key to remove the front-left screw.
- From the top side, remove the front screws on the left side of the heatbed frame.
- 📌 **Keep the screws.** They will be reused later.

PASSO 22 Montaggio del supporto frame-holder-cnc




- Position the Frame-holder-cnc on the left side of the heatbed frame.
- 📌 Note the correct orientation of the part.
- Secure it using the M3x12rT screw removed earlier.
- From the underside, secure the part with the second M3x12rT screw removed earlier.

PASSO 23 Montaggio del sensore di offset



- ✦ Route the offset sensor cable from the underside of the heatbed through the opening next to the Frame-holder-cnc.
- ✦ Plug the offset sensor cable to the Offset sensor.
- ✦ Attach the offset sensor to the Frame-holder-cnc using the magnets.
 - Make sure it is correctly seated, following the edge of the heatbed frame **without touching it**.

PASSO 24 È fatto




- Confronta l'aspetto finale del tutto con l'immagine.
- Let's continue to the next chapter: **Printed parts and back cover upgrade**.

4. Printed parts and back cover upgrade



PASSO 1 Preparazione stampante





- Move the x-carriage into the center of the printer frame.

PASSO 2 Rilascio delle cinghie



- On the front side of the printer:
- Using a 2.5mm Allen key, release the M3 screw holding the right CoreXY tensioner. Do not remove the screw completely.
- Using a 2.5mm Allen key, release the M3 screw holding the left CoreXY tensioner. Do not remove the screw completely.
- Gently tension the belt with your finger. If the belt has a similar degree of looseness as shown in the picture, proceed to the next step.


PASSO 3 ATTENZIONE: Manipolazione del lubrificante



⚠ CAUTION: Avoid direct skin contact with the lubricant used for the linear rails in this printer. If a contact occurs, wash your hands immediately. Especially before eating, drinking, or touching your face.

● Lubricant accumulates mainly in the linear rail channels on the linear sides.


PASSO 4 Rimozione copertura X-carriage



● Rimuovi la copertura X-carriage.

ⓘ Puoi buttare via questa parte.

PASSO 5 Rimozione del morsetto delle cinghie



- Using the T10 Torx screwdriver, remove four M3x12rT screws holding the belt-clamps.


📌 Metti da parte le viti

- Togli i morsetti della cinghia.

📄 Puoi buttarli via.

- With the belt-clamps removed, proceed to the next step.


PASSO 6 Rimozione cinghie



- Grasp the **bottom belt** on the **left side** of the CoreXY and pull the belt out of the printer.


- Afferra la **cinghia superiore** sul **lato destro** del CoreXY ed estrai la cinghia dalla stampante.

PASSO 7 Rimozione delle lamiere laterali



- ✚ Using the T10 Torx screwdriver, remove four M3x8bT screws from the right side metal plate.
- ✚ Carefully slide the right side metal plate out of the printer's frame.
- Spostati sull'altro lato.
- ✚ Using the T10 Torx screwdriver, remove four M3x8bT screws from the left side metal plate.
- ✚ Carefully slide the left side metal plate out of the printer's frame.

PASSO 8 Rimozione delle parti anteriori del CoreXY




- ✚ Using a 4.0mm Allen key, release the M8x16 screw holding the CoreXY front right .
- ✚ Rimuovi la parte anteriore destra del CoreXY.
- ✚ Using a 4.0mm Allen key, release the M8x16 screw holding the CoreXY front left.
- ✚ Rimuovi la parte anteriore sinistra del CoreXY.

PASSO 9 Smontaggio del gruppo anteriore sinistro del CoreXY




- Remove the M3x22 screw from the CoreXY front left.
- Remove the CoreXY tensioner assembly by pulling it up.
- Remove the pin with pulley and washers from the CoreXY tensioner by sliding it up.

PASSO 10 Smontaggio del gruppo anteriore destro del CoreXY




- Remove the M3x22 screw from the CoreXY front right.
- Remove the CoreXY tensioner assembly by pulling it up.
- Remove the pin with pulley and washers from the CoreXY tensioner by sliding it up.

PASSO 11 Nuovo gruppo tenditore CoreXY: preparazione dei componenti



- **Per i seguenti passi prepara:**
- Nuovo Tensionatore CoreXY (2x)
 - Perno H8 2.9x20 (2x)
 - Puleggia GT2-20 (2x)
 - Rondella 3x7x1 (4x)
 - Dado M3nN (2x)

PASSO 12 Montaggio del nuovo tenditore CoreXY



- Slide the pulley onto the pin.
- Slide two washer on each side of the pulley.
- Push the whole assembly into the slots on the new CoreXY tensioner.
- Insert the M3nN nut into the designated hexagonal slot.
- Repeat this for the other CoreXY tensioner.

PASSO 13 Nuovo CoreXY anteriore sinistro: preparazione dei componenti



- Per i seguenti passi prepara:
- Nuovo CoreXY anteriore sinistro (1x)
 - Vite M8x16 (1x)
 - Vite M3x22 (1x)
 - Dado M3nS (2x)

PASSO 14 Montaggio della nuova parte anteriore sinistra del CoreXY




- Insert two M3nS nuts into the slots on the CoreXY front left **as far as possible**.
- Insert the CoreXY tensioner into the designated space in the CoreXY front left.
⚠ Watch out for the **correct orientation** of the CoreXY tensioner - it has to fully slide into the CoreXY front left.
- Turn the part around and insert the M3x22 screw. **Do not tighten it fully**, just few turns are enough.

PASSO 15 Installazione del CoreXY anteriore sinistro



- Place the CoreXY front left over the frame so the notches on the printed part align with the slots on the metal frame.
- Insert the end of the light bar into the notch on the CoreXY front left.
- Secure the parts together using an M8x16 screw and the 4.0mm Allen key.

PASSO 16 Nuovo CoreXY anteriore destro: preparazione dei componenti



- For the following steps, please prepare:**
- Nuovo CoreXY anteriore destro (1x)
- Vite M8x16 (1x)
- Vite M3x22 (1x)
- Dado M3nS (2x)

PASSO 17 Montaggio della nuova parte anteriore destra del CoreXY




- ✚ Insert two M3nS nuts into the slots on the CoreXY front right as far as possible.
- ✚ Insert the other CoreXY tensioner into the designated space in the CoreXY front right.
 - ⚠ Watch out for the **correct orientation** of the CoreXY tensioner. It has to fully slide into the CoreXY front right.
- ✚ Turn the part around and insert the M3x22 screw. Do not tighten it fully, just few turns are enough.

PASSO 18 Installazione del CoreXY anteriore destro




- ✚ Place the CoreXY front right over the frame so the notches on the printed part align with the slots on the metal frame.
- ✚ Insert the end of the light bar into the notch on the CoreXY front left.
- ✚ Secure the parts together using an M8x16 screw and the 4.0mm Allen key.

PASSO 19 Scoprire l'elettronica I.




- Release, but do not remove four screws securing the cover.
- Slide the cover up and remove it.
- Disconnect the Wi-Fi cable from the Wi-Fi connector if needed.
- Locate the ejectors on both sides of the electronics box. From these, locate the upper pair.
- Fai scivolare fuori lo XLSplitter. Spingi gli estrattori in modo che la scheda si scollegi dalla scheda Sandwich e scivoli fuori utilizzando le guide laterali.
- ⚠ **Touch any electronic board by its edges. Avoid damaging the board components.**
- 📌 Place it on safe anti-static surface, such as the anti-static bubble wrap from the XL-CAN board packaging.

PASSO 20 Smontare la copertura




- Release and remove two screw from the electronics cover.
- From the opposite side of the cover, remove two electronics-case-holders.
- 📌 Each part contains an embedded M3nS nut. Make sure the nut does not fall out, as the part will be reused later.
- Discard the electronics cover. It will no longer be needed.

PASSO 21 Scoprire l'elettronica II.



- Remove two M3x8rT screws from the left side on the back of the printer.
- Slide the cable cover cap left out of the metal electronics cover.
- ⚠ **Be careful not to damage any cables!**
- Remove two M3x5rT located at the bottom of the metal electronics cover.

PASSO 22 Scoprire l'elettronica III.




- Remove the other two M3x8rT screws from the right side on the back of the printer.
- Slide the cable cover cap right out of the metal electronics cover.
- ⚠ **Be careful not to damage any cables!**
- Remove two M3x5rT located at the bottom of the metal electronics cover.

PASSO 23 Scoprire l'elettronica IV.




- 🔴 Move the whole back metal plate back and down the printer.
- 🔵 Quanto basta per vedere i componenti elettronici.

PASSO 24 Liberare i cavi: lato sinistro




- 🟢 Cut all four zipties on the left side to free the cables.
 - 🟡 Scollega il cavo del motore XY.
 - 🟠 Scollega il cavo della barra LED.
- ⚠️ **Be careful:** the connectors have a **safety latch** that **must be pressed while disconnecting**.

PASSO 25 Rimozione della barra LED




- Remove the textile sleeve from the LED bar cable.
- Remove the LED bar by lifting it up and carefully pulling the cable through the CoreXY back right assembly.

PASSO 26 Rimozione del gruppo posteriore destro del CoreXY




- Using the 2.5mm Allen key, remove four M3x10 screws.
- Rimuovi il motore XY.
- Insert the 4mm Allen key through the hole and remove the M8x16 screw.
- Rimuovi la parte CoreXY-back-right dalla stampante.

PASSO 27 Smontare il CoreXY sul retro a destra



- Using a 2.5mm Allen key, remove two M3x35 screws.
- Remove the CoreXY-back-right-top from the CoreXY-back-right. Don't throw the parts away, we'll need some distance nuts.
- Remove the double pulley and the single pulley. Don't throw the parts away!

PASSO 28 Rimozione dei distanziatori




- Remove the M3x10 spacers from the CoreXY back right printed parts for the next steps.

i Hint: You can use an M3x35 to remove the M3x10 spacer nut.

📌 Puoi buttare via le parti stampate.


PASSO 29 New CoreXY back right bottom: parts preparation



For the next steps, please prepare:


- Nuovo CoreXY posteriore destro inferiore (1x)
- GT2-20 pulley (3x) *removed in previous steps*
- Rondella 3x7x1 (5x)
- Pin H8 2.9x20 (1x) *removed in previous steps*
- Pin H8 2.9x30 (1x) *removed in previous steps*
- Dado M3nS (1x)
- Hex spacer M3x10 (1x) *removed in previous steps*

PASSO 30 Assemblare il CoreXY posteriore inferiore destro



- Insert one M3nS nut into the CoreXY back right bottom as far as possible.
- Insert one M3x10 spacer nut into the CoreXY back right bottom as far as possible.
- i Ti consigliamo di usare la tecnica di tiro della vite dal lato opposto.
- Attach three washers and two pulleys on the longer pin in the order seen in the picture.
- Insert one pulley onto the shorter pin and attach two washer on both sides of the pulley.
- Push the washers and the pulleys together in the centre.
- Insert the prepared single pulley into the CoreXY back right bottom.
- Insert the prepared double pulley into the CoreXY back right bottom.


PASSO 31 Nuovo CoreXY posteriore destro superiore: preparazione dei componenti



For the next steps, please prepare:

- CoreXY, parte posteriore destra in alto (1x)
- Hex spacer M3x10 (1x) *removed in previous steps*
- Dado M3nS (2x)
- Dado M3nN (2x)
- M3x35 screw (2x) *removed in previous steps*
- M8x16 screw (1x) *removed in previous steps*

PASSO 32 Assemblare il CoreXY posteriore superiore destro




- Insert two M3nS nuts into CoreXY back right top as far as possible.
- Push the M3x10 hex spacer into the CoreXY back right top as far as possible.
- Insert two M3nS nuts into the CoreXY back right top.

PASSO 33 Assemblare il CoreXY posteriore destro



- Attach the CoreXY back left top onto the pulleys and the CoreXY back right bottom.
- Make sure the pins align with the holes on the CoreXY back left top.
- Fissalo con due viti M3x35.

PASSO 34 Installazione CoreXY sul retro a destra




- Attach the CoreXY back right to the printer.
- Secure the CoreXY back right with an M8x16 screw using a 4.0 mm Allen key.

PASSO 35 Smontaggio della puleggia del motore XY




- Using the 2.0mm Allen key, loosen 2x set screws from the pulley 20t attached to the motor shaft.
- Slide out the pulley 20t from the motor shaft.

PASSO 36 Nuova puleggia del motore: preparazione dei componenti




- Per i seguenti passi prepara:
- XY motor (1x) *removed in previous steps*
- M3x8 screw (4x) *removed in previous steps*
- Fascetta (4x)
- Nuova puleggia T21-1.5GT (1x)

PASSO 37 Assemblare la nuova puleggia del motore




- ◆ Install the pulley flush with the top edge of the motor shaft.
- ⚠ Install the pulley so that one set screw is **aligned with the flat part of the motor shaft**.
- ◆ Tighten both set screws using the 2.0mm Allen key.

PASSO 38 Installazione del nuovo motore




- ◆ Insert the cable through the CoreXY back right.
- ◆ Insert the motor into the CoreXY back right.
- ◆ Secure the motor with four M3x8 screws.
- ◆ Connect the XY motor cable to the XL sandwich board.

PASSO 39 Installazione della barra LED




- Pass the end of the LED bar cable through the hole in the CoreXY back right.
 - ⚠ **Be very careful not to damage any part of the cable!**
- Place the other end into the notch on the CoreXY front right.
- Install the textile sleeve onto the LED bar cable and move it up as far as possible.
- Connect the LED bar cable to the XL sandwich board.

PASSO 40 Fissare i cavi



- Route two zip ties through the holes in the CoreXY back right.
- Secure the LED bar cable by tightening the zip ties. **Do not overtighten the zip tie!**
- Push two zip ties through the perforations in the back plate and guide them under all the cables.
- Secure all the cables by tying the zip ties. **Do not overtighten the zip tie!**
- 📌 Don't forget to cut the loose ends of the zip ties.

PASSO 41 Liberare i cavi: lato destro




- Move to the other side of the printer.
 - Cut all four zip ties on the right side to free the cables.
 - Scollega il cavo del motore XY.
 - Scollega il cavo della barra LED.
- ⚠ **Be careful: the connectors have a safety latch that must be pressed while disconnecting.**

PASSO 42 Rimozione della barra LED



- Remove the textile sleeve from the LED bar cable.
- Remove the LED bar by lifting it up and carefully pulling the cable through the CoreXY back right assembly.

PASSO 43 Rimozione del gruppo posteriore sinistro del CoreXY



- Using the 2.5mm Allen key, remove four M3x10 screws.
- Rimuovi il motore XY.
- Insert the 4mm Allen key through the hole and remove the M8x16 screw.
- Remove the CoreXY-back-right from the printer.

PASSO 44 Smontaggio del CoreXY posteriore sinistro




- Using a 2.5mm Allen key, remove two M3x35 screws.
- Separa la parte CoreXY-back-right-top dalla parte CoreXY-back-right.
- Remove the double pulley and the single pulley.



Don't throw any of the parts away!

PASSO 45 Rimozione dei distanziatori




- Remove the M3x10 spacers from the CoreXY back left printed parts for the next steps.

i Hint: You can use an M3x35 to remove the M3x10 spacer nut.

📌 You can throw the printed parts away.


PASSO 46 New CoreXY back left bottom: parts preparation



For the next steps, please prepare:


- Nuovo CoreXY posteriore sinistro inferiore (1x)
- Pin H8 2.9x20 (1x) *removed in previous steps*
- Pin H8 2.9x30 (1x) *removed in previous steps*
- GT2-20 pulley (3x) *removed in previous steps*
- Rondella 3x7x1 (5x)
- Hex spacer M3x10 (1x) *removed in previous steps*
- Dado M3nS (1x)

PASSO 47 Montaggio della parte posteriore sinistra in basso del CoreXY



- ✦ Insert one M3nS nut into the CoreXY back left bottom as far as possible.
- ✦ Insert one M3x10 spacer nut into the CoreXY back left bottom as far as possible.
- ① Ti consigliamo di usare la tecnica di tiro della vite dal lato opposto.
- ✦ Attach three washers and two pulleys on the longer pin in the order seen in the picture.
- ✦ Insert one pulley onto the shorter pin and attach two washer on both sides of the pulley.
- ✦ Push the washers and the pulleys together in the centre.
- ✦ Insert the prepared single pulley into the CoreXY back left bottom.
- ✦ Insert the prepared double pulley into the CoreXY back left bottom.
- ⚠ **Ensure the correct position of the pins!**


PASSO 48 New CoreXY back left top: parts preparation



For the next steps, please prepare:

- ✦ CoreXY back left top (1x)
- ✦ M3x35 screw (2x) *removed in previous steps*
- ✦ M8x16 screw (1x) *removed in previous steps*
- ✦ Hex spacer M3x10 (1x) *removed in previous steps*
- ✦ Dado M3nS (2x)
- ✦ Dado M3nN (2x)

PASSO 49 Montaggio della parte posteriore sinistra in alto del CoreXY




- Insert two M3nS nuts into CoreXY back left top as far as possible.
- Push the M3x10 hex spacer into the CoreXY back left top as far as possible.
- Insert two M3nS nuts into the CoreXY back right top.

PASSO 50 Montaggio della parte posteriore sinistra del CoreXY



- Attach the CoreXY back left top onto the pulleys and the CoreXY back right bottom.
- Make sure the pins align with the holes on the CoreXY back left top.
- Fissalo con due viti M3x35.

PASSO 51 Installazione del CoreXY posteriore sinistro



- ◆ Attach the CoreXY back left to the printer.
- ◆ Secure the CoreXY back left with an M8x16 screw using a 4.0 mm Allen key.

PASSO 52 Smontaggio della puleggia del motore XY



- ◆ Using the 2.0mm Allen key, loosen 2x set screws from the pulley 20t attached to the motor shaft.
- ◆ Slide out the pulley 20t from the motor shaft.

PASSO 53 Nuova puleggia del motore: preparazione dei componenti



● **Per i seguenti passi prepara:**


- XY motor (1x) *removed in previous steps*
- M3x8 screw (4x) *removed in previous steps*
- Fascetta (4x)
- **New T27-1.5GT pulley (1x)**

PASSO 54 Assemblare la nuova puleggia del motore



- Install the pulley 2.5mm higher than the start of the flat part of the motor shaft. Use the 2.5mm Allen key for reference.
- Alternatively, measure the distance between the beginning of the motor shaft and the pulley, 3.6mm.
- 📌 Nota l'orientamento della puleggia. I denti si trovano sotto le viti di fissaggio.
- ⚠️ **Install the pulley so that one set screw is aligned with the flat part of the motor shaft.**
- Tighten both set screws using the 2.0mm Allen key.

PASSO 55 Installazione del nuovo motore




- Insert the cable through the CoreXY back left.
- Insert the motor into the CoreXY back left.
- Secure the motor with four M3x8 screws.
- Connect the XY motor cable to the XL sandwich board.

PASSO 56 Installazione della barra LED




- Pass the end of the LED bar cable through the hole in the CoreXY back right.
- ⚠ **Be very careful not to damage any part of the cable!**
- Place the other end into the notch on the CoreXY front right.
- Install the textile sleeve onto the LED bar cable and move it up as far as possible.
- Connect the LED bar cable to the XL sandwich board.

PASSO 57 Fissare i cavi




- 🟠 Route two zip ties through the holes in the CoreXY back left.
- 🟡 Secure the LED bar cable by tightening the zip ties. Do not use excessive force and do not overtighten the zip tie!
- 🟢 Push two zip ties through the perforations in the back plate and guide them under all the cables.
- 🟠 Secure all the cables by tying the zip ties. Do not use excessive force and do not overtighten the zip tie!

PASSO 58 Side metal covers: parts preparation




- 🟠 **For the next steps, please prepare:**
- 🟢 CoreXY cover right (1x) *removed in previous steps*
- 🟠 CoreXY cover left (1x) *removed in previous steps*
- 🟡 M3x6bT screw (8x) *removed in previous steps*

PASSO 59 Installing the side metal covers



- Attach the right side metal cover back onto the right side of the CoreXY frame.
- Secure the right side metal cover with four M3x6bT screws.
- Attach the left side metal cover back onto the left side of the CoreXY frame.
- Secure the left side metal cover with four M3x6bT screws.

PASSO 60 Rimozione delle clip della copertura posteriore superiore



- Remove the M3x8rT screw from the back of the printer.
- ❗ The cover clip is inside the printer.
- Turn the cover clip 90° in any direction.
- Remove the cover clip from the frame.
- Ripeti per le altre due clip.


PASSO 61 New upper back cover clips: parts preparation



● For the following steps, please prepare:

- Nuove clip per copertura (3x)
- M3x8rT screw (3x) *removed in previous step*

PASSO 62 Installing the new upper back cover clips



- Insert the new cover clip into the frame.
- Turn it 90° degrees to lock it in.
- Align the holes of the cover clip and the back plate.
- Fissalo con una vite M3x8rT.
- ⚠ **Do not overtighten the screw! You could destroy the printed part.**
- Repeat for the other two cover clips.


PASSO 63 Copertura posteriore: preparazione dei componenti



For the next steps, please prepare:

- Cable cover cap left (1x) *removed in previous steps*
- Cable cover cap right (1x) *removed in previous steps*
- M3x8rT screw (4x) *removed in previous steps*
- M3x4rT screws (4x) *removed in the previous steps*

PASSO 64 Fissaggio della copertura posteriore I.




- Carefully attach the back electronics cover to the printer.

⚠ **Avoid pinching or damaging any of the cables!**


- Fissalo con quattro viti M3x4rT.

PASSO 65 Fissaggio della copertura posteriore II.




- Gently insert the cable cover cap left.
- Secure it with two M3x8rT screws using a T10 Torx screwdriver.
- On the other side, gently insert the cable cover cap right.
- Secure it with two M3x8rT screws using a T10 Torx screwdriver.

PASSO 66 Nuova copertura dell'elettronica: preparazione dei componenti




- **Per i seguenti passi prepara:**
- New XL-buddy-box-cover (1x) *electronics cover*
- Electronics-case-holder (2x) *you removed earlier*
- 📌 **Make sure both parts contain an M3nS nut.**
- M3x8rT screw (2x) *you removed earlier*

PASSO 67 Montare la nuova copertura




- ◆ Attach both electronics-case-holder parts to the inside of the new electronics cover.
- ◆ Make sure the tab on each part is properly seated in the cutout in the cover.
- ◆ Then secure both parts with two M3x8rT screws.
- ◆ If you have a five-toolhead XL, bend the cut-out section of the sheet metal part inward.

PASSO 68 Ventilatore XL Buddy: preparazione dei componenti




- ◆ Per i seguenti passi prepara:
- ◆ Ventola (1x)
- ◆ Rivetto lungo in nylon (4 pezzi)

PASSO 69 Installazione del ventilatore XL Buddy



- From the inside of the cover, attach the XL Buddy fan.
- L'adesivo deve essere rivolto verso l'alto.
- Route the fan cable downward as shown in the image.
- Keep the fan in position and secure it from the opposite side of the cover using four rivets. Press them in completely.

PASSO 70 Dissipatore XL Buddy: preparazione dei componenti




- Per i seguenti passi prepara:
- XL buddy board (1x) *you removed earlier*
- ⚠ **Touch any electronic board by its edges. Avoid damaging the board components.**
- Dissipatore (1x)
- Viti M3x8rT (2x)

PASSO 71 Installazione del dissipatore




- Clean the heatsink area on the XL Buddy board using Isopropyl alcohol.
📌 **Make sure the part is in the correct orientation** and compare it with the image.
- Peel off the blue protective layer from the heatsink.
① Please note that the heatsink will become sticky after removing the protective layer.
- Place the heatsink adhesive side down on the cleaned XL Buddy board area and align it with the screw holes.
- Fissalo con due viti M3x8rT.

PASSO 72 Collegamento del ventilatore XL Buddy




- Connect the XL Buddy fan cable to the connector below the upper slot/board.
📌 Keep the board supported at all times so the electronics cover does not hang from the fan cable.

PASSO 73 Come collegare la scheda XL Buddy




- ◆ Hold the attached electronics cover in your hand and support it so it does not hang from the cable.
- ◆ Install the XL Buddy board into the lower rails (bottom socket).
- ◆ Carefully slide the XL Buddy board into the rails and fully press it in. The microprocessor must face upward.
- ◆ Locate and connect the Wi-Fi cable to the Wi-Fi connector.

PASSO 74 Coprire l'elettronica



- ◆ Install the electronics cover onto the XL Buddy box.
- ⚠ **Make sure no cables are pinched.**
- ◆ **If you have a five-tool XL, make sure the cables from the three toolheads are routed through the cut-out in the cover.**
- ◆ Slide the cover down until it properly seats on the pre-installed screws.
- ◆ Secure it by tightening the four pre-installed screws.


PASSO 75 Nuove coperture dei cavi dell'alimentatore: preparazione dei componenti



● For the next steps, please prepare:

◆ Nuova copertura dei cavi dell'alimentatore (6x)

PASSO 76 Sostituzione delle coperture dei cavi dell'alimentatore



● Allenta le due viti M3x8.

⚠ Non toglierli del tutto.

● Remove the old PSU cable cover by sliding it down.


● Insert the new PSU cable cover by sliding it up under the screws.

● Gently secure it by tightening the two M3x8 screws.

⚠ **Do not overtighten, you might snap the printed part!**

● Repeat the same procedure for all the PSU cable covers.

PASSO 77 Removing the old bed energy chain mount




- ◆ Open one segment of the energy chain using pliers.
- ⚠ **Be very careful not to damage the energy chain or the cables!**
- ◆ Using pliers, grab the end of the energy chain by its sides **as close to the energy chain mount as possible**.
- ◆ Tiralo con decisione verso il basso per rimuoverlo.
- ◆ Togli le due viti M3x20rT.
- ◆ Remove the old bed energy chain mount.

PASSO 78 New bed energy chain mount: parts preparation



- ◆ **Per i seguenti passi prepara:**
- ◆ Nuovo supporto catena piano (1x)
- ◆ M3x20rT (2x) *removed in previous steps*

PASSO 79 Installing the new bed energy chain mount




- Place the new bed energy chain mount into the designated space under the heatbed.
- Fissalo con due viti M3x20rT.
- Close the segment you opened in the previous step by pushing it against the side of the energy chain mount.
- Firmly push the end of the energy chain into the bed energy chain mount until it clicks.

PASSO 80 Rimozione della copertura anteriore del telaio



- Remove the M8x16 screw using a 4.0mm Allen key.
- Togli la copertura anteriore del telaio.
- Repeat the same procedure on the other side.

PASSO 81 Nuova copertura anteriore del telaio: preparazione dei componenti



- Per i prossimi passaggi, per favore prepara:
- Nuova copertura anteriore del telaio (2x)
- M8x16 screw (2x) *removed in previous step*

PASSO 82 Installing the new right frame front cover




- Attach the new frame front cover to the exposed end of the frame on the right side.
- Secure the new frame front cover with an M8x16 screw using a 4.0 mm Allen key.

PASSO 83 Installing the new left frame front cover



- ◆ Attach the new frame front cover to the exposed end of the frame on the left side.
- ◆ Secure the new frame front cover with an M8x16 screw using a 4.0 mm Allen key.

PASSO 84 Nuova Clip della copertura: preparazione dei componenti




- ◆ For the following steps, please prepare:
- ◆ Nuove clip per copertura (28x)

PASSO 85 Rimuovere la clip della copertura




- Locate the old cover clip on the inside of the printer.
- Remove the M3x8rT screw from the other side of the metal plate.
- Rotate the cover clip 90° degrees to free the cover clip.
- Remove the cover clip from the frame.

PASSO 86 Installazione della nuova clip di fissaggio della copertura




- Insert the new cover clip into the frame.
- Turn it 90° degrees to lock it in.
- Align the holes of the cover clip and the metal plate.
- Fissalo con una vite M3x8rT.
- ⚠ **Do not overtighten the screw! You could destroy the printed part.**

PASSO 87 Sostituzione delle clip della copertura I.




- Repeat the same procedure for the rest of the cover clips.
- These clips have been replaced in previous steps.

PASSO 88 Sostituzione delle clip della copertura II.




- Appoggia con cura la stampante sul retro.
- Use any type of support material to not damage the printer.**
- Repeat the same procedure for the cover clips as in the previous steps.
- Carefully lift the printer and set it on it's base.

PASSO 89 Regolazione del piano riscaldato




- ✦ From the rear side of the printer, plug in the PSU cable.
- ✦ Turn the power switch ON (symbol "I").
- ✦ Inserisci qui il tuo testo
- ✦ Go to the menu, press **Control** -> **Move Axis** -> **Move Z** and set the heatbed all the way down.
- ✦ Turn off and unplug the printer.

PASSO 90 Sostituzione delle clip della copertura III.



- ✦ Replace the last four cover clips using the procedure from the previous steps.

PASSO 91 Rimozione dell'alloggiamento del cuscinetto dell'asse Z



- Remove the two M3x10 screws from the Z axis bearing housing.
- Remove the Z axis bearing housing by pulling it up.
- Repeat the same procedure on the other side.
- Pull the Z axis bearing out of it's printed housing
- i** You can throw out the printed housing, but **keep the Z axis bearing** for the next steps.

PASSO 92 Nuovo alloggiamento del cuscinetto dell'asse Z: preparazione dei componenti



- For the next steps, please prepare:**
- Nuovo alloggiamento per cuscinetti dell'asse Z (2x)
 - Z axis bearing (2x) *removed in previous steps*
 - M3x10 screw (4x) *removed in previous steps*

PASSO 93 Installing the new Z axis bearing housing I.




- Install the Z axis bearing into it's printed housing by pushing it firmly.
- Attach the Z axis bearing housing onto the Z axis rod and frame.
- Fissalo con due viti M3x10.

PASSO 94 Installing the new Z axis bearing housing II.



- Spostati sull'altro lato.
- Attach the Z axis bearing housing onto the Z axis rod and frame.
- Fissalo con due viti M3x10.

PASSO 95 Rimozione del supporto della catena portacavi dal telaio




- Remove the two M3x16 screws from the frame energy chain mount.
- Pull the frame energy chain mount towards yourself.
- Completely remove the top energy chain segment lock by pulling it away from the chain using pliers.
- Push the sides of the energy chain together with pliers as close to the frame energy chain mount as possible.
- Pull the frame energy chain mount out to remove it.

PASSO 96 Nuovo supporto per catena portacavi: preparazione dei componenti




- **Per i seguenti passi prepara:**
- Nuovo supporto catena telaio (1x)
- Energy chain segment lock (1x) *removed in previous step*
- M3x16 screw (2x) *removed in previous step*

PASSO 97 Installazione del nuovo supporto per la catena portacavi



- Install the energy chain segment lock onto the energy chain.
 - First push the single end onto the right side.
 - Then guide it behind the cables and lock it on the other side.
- Firmly push the new energy chain mount onto the chain mount.
- Secure it to the back plate with two M3x16 screws.

PASSO 98 È fatta



- Compare the final look of the assembly with the picture.
- Let's continue to the next chapter:
Belts and spool holder upgrade.

5. Aggiornamento delle cinghie e del porta bobina





PASSO 1 Fissaggio della cinghia: informazioni importanti



- ⚠ È importante fissare correttamente le cinghie alla stampante. Non avere fretta.
- ⬢ Confronta sempre le immagini con la tua stampante.
- ⚠ Assicurati che nessuna cinghia sia attorcigliata.

PASSO 2 Fissaggio della cinghia: preparazione dei componenti



- ⬢ Per i seguenti passi prepara:
- 🟠 Nuova Cinghia XY 1.5GT (2x)
- 🟢 Nuovi morsetti per la cinghia (2x)
- 🟡 Viti M3x12rT (4x) *che hai rimosso nei passi precedenti*

PASSO 3 Fissaggio della cinghia inferiore: lato anteriore destro





- Dal lato frontale della stampante:
- Prendi una delle cinghie.
- Inserisci un'estremità della cinghia nella parte anteriore inferiore del pezzo Y-carriage-right-base.
- La cinghia deve essere rivolta verso la stampante con i denti in vista (non il lato liscio della cinghia).
- ❗ Controlla che il lato con i denti sia rivolto verso la macchina.
- Sul lato interno della parte Y-carriage-right-base tira la cinghia.
- ⚠ Non tirare troppo la cinghia, potrebbe sfilarsi dal supporto Y-carriage-right-base e l'intero processo di aggancio della cinghia dovrà ricominciare dall'inizio.

PASSO 4 Fissaggio della cinghia inferiore: lato posteriore destro





- Tira la cinghia un altro po' e inseriscila dietro la puleggia inferiore.
- Tira la cinghia, che ora è inserita nella puleggia inferiore.

PASSO 5 Fissaggio della cinghia inferiore: lato posteriore sinistro




- Tira ancora un po' la cinghia e inseriscila dietro le pulegge inferiori.
- Tira la cinghia, che ora è inserita attraverso le pulegge inferiori.

PASSO 6 Fissaggio della cinghia inferiore: preparazione puleggia motore



- Dal lato posteriore della stampante:
- Inserisci la chiave a brugola da 2,5 mm attraverso il foro per creare un occhiello sulla cinghia.
- Una volta creato un occhiello, puoi rimuovere la chiave a brugola. **Non tirare la cinghia!**

PASSO 7 Fissaggio della cinghia inferiore: fissaggio puleggia motore




- Dal lato frontale della stampante:
- Utilizzando il lato più corto della chiave a brugola da 2,5 mm, tira delicatamente la cinghia per creare un occhiello più grande.
- Attacca l'occhiello sulla puleggia del motore.
- Tira la cinghia per fissare la sua posizione sulla puleggia.

PASSO 8 Fissaggio della cinghia inferiore: lato sinistro




- ① Quando tiri la cinghia sentirai una maggiore resistenza da parte del motore XY, questo è perfettamente normale.
- Tira la cinghia un altro po' e guidala dietro la parte Y-carriage-left-base.
- Tira la cinghia intorno alla puleggia sul lato anteriore sinistro.
- Fai passare la cinghia intorno alla puleggia nella parte Y-carriage-left-base.

PASSO 9 Fissaggio della cinghia inferiore: morsetto della cinghia



- ① Il colore dei morsetti della cinghia potrebbe essere diverso a seconda che tu abbia un Original Prusa Enclosure XL o meno. La procedura è la stessa, continua.
- ① Questa immagine è stata scattata fuori dalla stampante su uno sfondo bianco per una migliore visibilità e definizione. Segui questo passaggio sulla tua stampante.
- Prepara un morsetto per cinghia con i fori per le viti rivolti verso l'alto.
- Attacca l'estremità sinistra al morsetto della cinghia. L'estremità della cinghia deve trovarsi a metà del morsetto.
- Attacca l'estremità destra al morsetto della cinghia. L'estremità della cinghia deve trovarsi a metà del morsetto.
- ① Il morsetto con le cinghie sarà ruotato di 180° e fissato al carrello X.

PASSO 10 Fissaggio della cinghia inferiore: fissaggio del morsetto della cinghia



- Ruota di 180° il morsetto con le cinghie e fissalo sul carrello X.
- Controlla che le cinghie siano in posizione. In caso contrario, sistemale in posizione come indicato nel passaggio precedente.
- Inserisci due viti M3x12rT e fissale con un cacciavite Torx T10.
- Ben fatto! Una delle cinghie è stata fissata. Proviamo la seconda.

PASSO 11 Fissaggio della cinghia superiore: lato anteriore sinistro




- Dal lato frontale della stampante:
- Prendi la seconda cinghia.
- Inserisci un'estremità della cinghia nella parte anteriore superiore del pezzo Y-carriage-left-base.
- La cinghia deve essere rivolta verso la stampante con i denti in vista (non il lato liscio della cinghia).
- ⓘ Controlla che il lato con i denti sia rivolto verso la macchina.
- Sul lato interno della parte Y-carriage-left-base tira la cinghia.
- ⓘ Non tirare troppo la cinghia, potrebbe cadere dal supporto Y-carriage-left-base e l'intero processo di aggancio della cinghia dovrà ricominciare dall'inizio.

PASSO 12 Fissaggio della cinghia superiore: lato posteriore sinistro



- Tira di più la cinghia e inseriscila dietro la puleggia superiore.
- Tira la cinghia, che ora è inserita attraverso la puleggia superiore.


PASSO 13 Fissaggio della cinghia superiore: lato posteriore destro



i *Suggerimento: per un assemblaggio più semplice possibile, rimuovi il quinto Nextruder (solo per gli utenti con stampante a cinque testine) e posizionalo sopra la scatola sul piano riscaldato.*

- Tira di più la cinghia e inseriscila dietro le pulegge superiori.
- Tira la cinghia, che ora è inserita attraverso le pulegge superiori.
- Dal lato posteriore della stampante:
- Inserisci la chiave a brugola da 2,5 mm attraverso il foro per creare un occhiello sulla cinghia.
- Una volta creato un occhiello, puoi rimuovere la chiave a brugola. Non tirare la cinghia!
- Procedi al passo successivo.

PASSO 14 Fissaggio della cinghia superiore: fissaggio puleggia motore




- Dal lato frontale della stampante:
- Utilizzando il lato più corto della chiave a brugola da 2,5 mm, tira delicatamente la cinghia per creare un occhiello più grande.
- Attacca l'occhiello sulla puleggia del motore.
- Tira la cinghia per fissare la sua posizione sulla puleggia.

PASSO 15 Fissaggio della cinghia superiore: lato destro




- ❗ Quando tiri la cinghia sentirai una maggiore resistenza da parte del motore XY, questo è perfettamente normale.
- ➡ Tira di più la cinghia e allungala dietro la parte Y-carriage-right-base.
- ➡ Tira la cinghia intorno alla puleggia sul lato anteriore destro.
- ➡ Fai passare la cinghia intorno alla puleggia nella parte Y-carriage-right-base.

PASSO 16 Fissaggio della cinghia superiore: morsetto della cinghia



- ❗ Questa immagine è stata scattata fuori dalla stampante su uno sfondo bianco per una migliore visibilità e definizione. Segui questo passaggio sulla tua stampante.
- ➡ Prepara un morsetto per cinghia con i fori per le viti rivolti verso il basso.
- ➡ Attacca l'estremità destra al morsetto della cinghia. L'estremità della cinghia deve trovarsi a metà del morsetto.
- ➡ Attacca l'estremità sinistra al morsetto della cinghia. L'estremità della cinghia deve trovarsi a metà del morsetto.
- ❗ Il morsetto con le cinghie sarà ruotato di 180° e fissato al carrello X.

PASSO 17 Fissaggio della cinghia inferiore: fissaggio del morsetto della cinghia



- Ruota di 180° il morsetto con le cinghie e fissalo sul carrello X.
- Controlla che le cinghie siano in posizione. In caso contrario, sistemale in posizione come indicato nel passaggio precedente.
- Inserisci due viti M3x12rT e fissale con un cacciavite Torx T10.
- Ben fatto! Entrambe le cinghie sono agganciate.

PASSO 18 Tensionamento della cinghia



- Sul lato frontale della stampante:
- Utilizzando una chiave a brugola da 2,5 mm, stringi leggermente la vite M3 che tiene il tensionatore CoreXY sinistro.
- Utilizzando una chiave a brugola da 2,5 mm, stringi leggermente la vite M3 che tiene il tensionatore CoreXY destro.
- Non tendere completamente la cinghia, ma passa alla fase successiva, dove troverai un video sulla regolazione della tensione della cinghia.

PASSO 19 Tensione della cinghia: video


- Su Original Prusa XL, regolare la cinghia alla tensione ottimale è fondamentale per ottenere una buona qualità di stampa. Una cinghia poco tesa può causare lo spostamento del layer, il ghosting o altre anomalie di stampa, come l'ottenimento di una forma irregolare invece di un cerchio perfetto. Una cinghia eccessivamente tesa può causare un movimento irregolare sugli assi X e Y.
- Abbiamo il nostro accordatore di cinghie. L'applicazione determina la tensione della cinghia misurando la frequenza della vibrazione generata dal suo suono. Per regolare la cinghia, seguire le istruzioni riportate nel video sottostante.

PASSO 20 Copertura del carrello X: preparazione dei componenti



- **Per i seguenti passi prepara:**
- Nuova copertura X-carriage-cover (1x)

PASSO 21 Attaccare la copertura carrello X



- Monta la nuova copertura del carrello X.

PASSO 22 Copertura Core XY: preparazione dei componenti




- Per il prossimo passo, per favore prepara:
- Copertura CoreXY (1x)
 - Viti M3x6bT (6x) *che hai rimosso nei passi precedenti*

PASSO 23 Attaccare la copertura CoreXY



- Attacca delicatamente la copertura sul retro del CoreXY.
- Sul lato interno della copertura del CoreXY, collega il connettore PE.
- Insert six M3x6bT screws and tighten them using a T10 Torx screwdriver.

PASSO 24 Fissaggio della copertura CoreXY



- Insert six M3x6bT screws and tighten them using a T10 Torx screwdriver.

PASSO 25 Rimuovere il porta bobina



- Using the **long** 3.0mm Allen key, unscrew the M4x12 screw holding the spool holder assembly.

- Rimuovi il gruppo porta bobina.



If your printer uses a printed spool holder, it is equipped with an M5 screw and an M5nEs nut in the profile.

Replace both with the supplied M4 screw and M4nEs nut before proceeding.

PASSO 26 Nuovo porta bobina: preparazione dei componenti



- Per i seguenti passi prepara:
- Spoolholder-static (1x)
 - Puck-universal (1x)
 - O-ring (1x)
 - M4x12 screw (1x) *you removed earlier*

PASSO 27 Installare il disco del supporto bobina



- Insert the M4x12 screw into the universal puck.
- Align the screw in the puck with the M3nEs nut in the profile.
- Make sure both tabs on the puck are inserted into the profile.
- Stringi bene la vite M4x12.

PASSO 28 Assemblare il porta bobina



- Install the O-ring onto the spool holder.
- Insert the spool holder into the puck.
- Insert the spool holder into the puck.
- Repeat the same for the remaining spool holders.

PASSO 29 È fatta



- Confronta l'aspetto finale del tutto con l'immagine.
- Let's continue to the last chapter: **Finishing up.**

6. Completamento




PASSO 1 Prima di iniziare con il Multi-Tool




- ❗ Questo capitolo mostra una breve descrizione della Configurazione guidata. Tieni presente che le schermate sono illustrative e potrebbero differire da quelle del firmware.
- ❗ Assicurati di utilizzare il **Firmware 6.10.1 o più recente**.
- ❗ Alcune parti della procedura guidata devono essere eseguite più volte, a seconda del numero di testine degli strumenti. Ad esempio:
 - Calibrazione Dock
 - Calibrazione cella di carico
 - Calibrazione sensore filamento

PASSO 2 Calibrazione dell'altezza della guarnizione dell'ugello



- Nei passi relativi alla regolazione delle guarnizioni degli ugelli, per maggiore visibilità e chiarezza abbiamo usato dei Nextruder parcheggiati nel dock senza stampante. **Non smontare i dock sulla tua stampante.**
- Nella fase successiva, regoleremo l'altezza della guarnizione dell'ugello.
- Utilizzando la chiave a brugola da 2,5 mm, stringi o svita la vite M3x30 per regolare l'altezza della guarnizione dell'ugello.

PASSO 3 Calibrazione dell'altezza della guarnizione dell'ugello




- Se la guarnizione dell'ugello è troppo bassa o troppo alta, dobbiamo modificare la sua altezza.
- Con una chiave a brugola da 2,5 mm, ruota la vite M3x30 in senso orario per abbassare la guarnizione dell'ugello.
 - ⓘ Se non riesci a raggiungere la vite, puoi staccare la testina di stampa vicina per avere più spazio.
- Se la guarnizione dell'ugello tocca l'ugello e non è piegata, è nella posizione corretta.
 - ⓘ Prova a spingere delicatamente con il dito sulla parte inferiore della guarnizione dell'ugello per verificare che la guarnizione sia a contatto con l'ugello.

PASSO 4 Preparare la stampante



- ⚠ Assicurati di posizionare la stampante in un luogo stabile in cui non vengano trasmesse vibrazioni ambientali (ad esempio, dove altre stampanti stanno stampando).
- Inserisci il cavo di alimentazione nella parte posteriore della stampante.
- Accendi l'interruttore di alimentazione (simbolo "I").

PASSO 5 Aggiornamento Firmware




- ❗ Ti consigliamo di controllare e, se necessario, aggiornare la versione del firmware.
- 🛠️ Visita la pagina help.prusa3d.com.
- 🔵 Vai alla pagina di Prusa XL+.
- 🟢 Salva il file del firmware (.bbf) sulla chiavetta USB in dotazione.
- ❗ Suggerimento: per accedere alla homepage di Prusa XL+ puoi utilizzare il link: <https://help.prusa3d.com/product/xl-plus>

PASSO 6 Configurazione guidata: Configurazione della rete e di Prusa Connect



- ❗ Dopo l'avvio della stampante, la schermata invita a eseguire i test e il Wizard (configurazione guidata) della stampante.
- 🛠️ La configurazione iniziale inizia con la configurazione di rete opzionale, che include anche la configurazione di Prusa Connect. Segui le istruzioni sullo schermo se vuoi che la stampante sia connessa al Wi-Fi e a Prusa Connect.

PASSO 7 Configurazione guidata: Test di calibrazione



i La Configurazione guidata (o Wizard) verifica tutti i componenti importanti della stampante. Alcune parti del wizard richiedono l'interazione diretta dell'utente. Segui le istruzioni che appaiono sullo schermo.

⚠ ATTENZIONE: Non toccare la stampante durante il wizard, a meno che non venga richiesto! Alcune parti della stampante potrebbero essere calde e spostarsi ad alta velocità.


📌 La configurazione guidata inizia con questi test:

- Test ventola
- Test degli assi X e Y
- Calibrazione dell'allineamento Asse Z

● Durante la prima calibrazione, questi primi test sono completamente automatici.

⚠ Durante il test degli assi, accertarsi che nella stampante non vi sia nulla che ostacoli il loro movimento.

PASSO 8 Configurazione guidata: Calibrazione della posizione del Dock



❗ Questo test richiede l'intervento dell'utente. La stampante fornirà le istruzioni per calibrare correttamente la posizione delle singole testine degli strumenti sulla stampante.

● Ti servirà:

● Chiave universale (1x)

● Chiave mini (1x)

⚠ È necessario seguire correttamente tutti i passaggi della calibrazione del dock! **Non avere fretta. Leggi ogni passaggio attentamente e poi procedi seguendo le istruzioni.**

PASSO 9 Configurazione guidata: Rimuovere i perni del dock



● Segui le istruzioni della Configurazione guidata sullo schermo.


● Utilizzando una chiave Mini, svita e rimuovi entrambi i perni del Dock 1. Mettili da parte, ci serviranno ancora tra poco.

PASSO 10 Configurazione guidata: Allenta le viti




- Segui le istruzioni della Configurazione guidata sullo schermo.
- Utilizzando una chiave Uni, allenta due viti. **Sono sufficienti pochi giri; non rimuovere del tutto le viti.**

PASSO 11 Configurazione guidata: Blocca lo strumento



- Segui le istruzioni della Configurazione guidata sullo schermo.
- Muovi lentamente e con attenzione il meccanismo di cambio strumento con la mano verso il primo strumento (quello più a sinistra).
- Blocca manualmente le barre metalliche come indicato nell'immagine.
- ⚠ **Lo strumento deve essere bloccato nel Tool changer.**

PASSO 12 Configurazione guidata: Stringi la vite superiore




- Segui le istruzioni della Configurazione guidata sullo schermo.
- Utilizzando una chiave Universale, stringi la vite superiore sul lato del dock.
- ⚠ Dopo aver confermato con il pulsante *Continua* sul display LCD, l'asse XY lascerà il dock con lo strumento. **Assicurarsi che non ci siano ostacoli.**

PASSO 13 Configurazione guidata: Stringi la vite inferiore




- Segui le istruzioni della Configurazione guidata sullo schermo.
- Utilizzando una chiave Universale, stringi la vite inferiore sul lato del dock.

PASSO 14 Configurazione guidata: Installa i perni del dock



- Segui le istruzioni della Configurazione guidata sullo schermo.
- Inserisci i due perni metallici e stringili con una chiave Mini.
- Dopo aver cliccato sul pulsante *continua* sul display LCD, la stampante riporterà lo Strumento nel dock1 ed eseguirà alcuni movimenti di calibrazione.

PASSO 15 Configurazione guidata: Dock calibrato correttamente



- Ottimo lavoro! Il Dock 1 è calibrato.
- Ripetere il processo di calibrazione per tutte le testine di stampa.

PASSO 16 Configurazione guidata: Test della cella di carico




- ◆ Il passo successivo della Configurazione guidata richiede di toccare l'ugello per testare e calibrare la Cella di carico. Le parti della stampante non sono riscaldate durante questo test; è possibile toccare le parti della stampante. Fai clic su **Continua**.
- ◆ **Non toccare ancora l'ugello.** Attendi che il conto alla rovescia finisca e che la stampante ti avvisi con un suono e un messaggio sul display.
- ◆ Tocca delicatamente l'ugello ma con decisione. Non usare troppa forza. Se la cella di carico non sente il tuo tocco, ti verrà chiesto di ripetere il passaggio.
- ❗ Ripeti il test della cella di carico in base al numero di testine di stampa.
- 📌 Dopo questo passaggio, passa al **test dell'asse Z** e al **test del riscaldatore dell'ugello**. Questi due test sono automatici e richiedono pochissimi interventi.

PASSO 17 Wizard - Calibrazione dei sensori del filamento



- ◆ La stampante ti chiederà se vuoi rimappare il sensore del filamento sul terzo lato. Scegli **Sinistra**. Cambia il lato solo se non hai abbastanza spazio intorno alla stampante per il terzo porta bobina sul lato sinistro.
- ◆ Durante la calibrazione dei sensori di filamento, verrà richiesto di utilizzare almeno 130 cm di filamento. Utilizza il Prusament in dotazione con la stampante e montalo sul supporto della bobina.
- ◆ Quando hai preparato il filamento, fai clic su **Sì**.
- ◆ Attendi che la stampante ti chieda di inserire il filamento nel sensore di filamento laterale.

PASSO 18 Wizard - Calibrazione dei sensori del filamento



- Inserisci il filamento nel sensore di filamento laterale attraverso il tubo in PTFE. Spingilo dentro fino a raggiungere il sensore di filamento nell'estrusore (sentirai una leggera resistenza).
- È possibile controllare lo stato del sensore del filamento laterale (a sinistra) e del sensore del filamento dell'estrusore (a destra) sulla barra inferiore dello schermo.
- Alla fine del test, ti verrà chiesto di **rimuovere il filamento dal sensore**.
- i In base al numero di testine di stampa, ripeti il processo di calibrazione del sensore di filamento.
- Una volta calibrati e testati correttamente tutti e cinque i sensori di filamento, la stampante passerà alla calibrazione dell'offset dello strumento. Questo passaggio richiederà il tuo intervento. Vai al passo successivo →

PASSO 19 Configurazione guidata: Phase stepping



- **L'ultimo passo è la calibrazione del Phase Stepping.** Questa funzione è stata introdotta nella versione firmware 6.0.0. La calibrazione è automatica. Segui le istruzioni sullo schermo.
- ① Puoi trovare più informazioni sul Phase Stepping nei link qui sotto:
 - 📌 **GUIDA AL PHASE STEPPING:** Informazioni necessarie sulla calibrazione del Phase Stepping.
 - 📌 **ARTICOLO DEL BLOG SULLA PHASE STEPPING:** Uno sguardo più approfondito alla funzione Phase Stepping.
- ① La stampante sposterà la prima testina di stampa al centro del piano riscaldato e muoverà lo strumento in diagonale per gli assi X e Y a velocità diverse.
- Quando la stampante ha finito il test, lo schermo ti dirà di quanto sono diminuite le vibrazioni del motore.

PASSO 20 È fatta




- **Questo è tutto, la stampante è pronta a stampare.** In ogni caso, segui le istruzioni di questo manuale fino in fondo.

PASSO 21 Calzino Nextruder Prusa (Opzionale)



- i** Il calzino Nextruder aiuta a mantenere stabile la temperatura nel blocco riscaldante. Inoltre, tiene pulito l'hotend dai residui di filamento e lo protegge nel caso in cui la stampa si stacchi dalla superficie di stampa.
- Con ogni confezione di Nextruder viene fornito un calzino in silicone.
- Se vuoi installare il calzino, ti consigliamo di farlo dopo la calibrazione.
- i** Come installare il calzino - controlla l'articolo.

PASSO 22 Manutenzione regolare della stampante



- i** Per far sì che la stampante continui a funzionare correttamente nel tempo, è consigliabile effettuare una manutenzione regolare.
- Per la manutenzione regolare della stampante, segui l'articolo Manutenzione regolare della stampante (XL) per informazioni e istruzioni.
- P** Nelle stampanti multitool, è necessario concentrarsi sulla lubrificazione dei perni di accoppiamento delle testine degli strumenti.
- i** La lubrificazione dei perni dell'accoppiatore può essere effettuata insieme al resto della manutenzione, oppure può essere eseguita se noti che le stampe presentano problemi di banding o ringing.
- Per lubrificare i perni dell'accoppiatore usa la nostra guida online dedicata Come lubrificare i perni dell'accoppiatore su Original Prusa XL.
- i** È necessario stampare un applicatore per lubrificare i perni. Per maggiori informazioni, consulta la guida dedicata.

PASSO 23 Una veloce guida per le prime stampe




Ora leggi il Manuale di stampa 3D, creato su misura per la tua stampante, e segui le istruzioni per configurarla correttamente. La versione più recente è sempre disponibile a **questo link**.



Leggi i capitoli *Disclaimer* e *Istruzioni di Sicurezza*

PASSO 24 Modelli 3D stampabili




Congratulazioni! Ora dovresti essere pronto a stampare ;-)




Puoi iniziare stampando alcuni dei nostri oggetti di prova contenuti nella chiavetta USB in dotazione: dagli un'occhiata in questa raccolta.

PASSO 25 Dacci il tuo feedback




- Sappiamo che non vedi l'ora di iniziare a stampare, ma ti saremmo davvero grati se potessi dedicare 3-4 minuti per **condividere con noi le tue opinioni** su questo manuale: quanto è stato chiaro, quanto è stato facile da seguire e qualsiasi idea per migliorarlo.
- i Questo feedback è un po' diverso dai soliti commenti che puoi lasciare sui singoli passi.
- Condividi il tuo feedback qui.**
- Grazie per averci aiutato a rendere i nostri manuali ancora migliori!

PASSO 26 Nozioni base Prusa



- Se incontri qualunque tipo di problema, non dimenticare che puoi dare un'occhiata alle nostre nozioni base su help.prusa3d.com
- Aggiungiamo nuovi argomenti ogni giorno!

PASSO 27 Unisciti a Printables!




- ◆ **Non dimenticare di unirti alla community Prusa più numerosa! Scarica gli ultimi modelli in STL o i G-code fatti su misura per la tua stampante. Registrati su [Printables.com](https://www.printables.com)**
- ◆ **Cerchi ispirazione per nuovi progetti? Controlla il nostro blog per gli aggiornamenti settimanali.**
- ◆ **Se hai bisogno di aiuto nel montaggio, dai un'occhiata al nostro forum con una splendida community :-)**
- i **Tutti i servizi condividono lo stesso account.**

Registro modifiche del manuale



PASSO 1 Storico versioni



- **Version history of the Prusa XL+ upgrade manual:**

- 08/2026 - Versione iniziale 1.00

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across the entire width of the page, providing a guide for handwriting or typing. The background is a clean, solid white color.

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across the entire width of the page, typical of standard notebook or school paper. There are no margins, text, or other markings present.

This image shows a full page of blank, lined paper. It features approximately 20 evenly spaced horizontal grey lines across the entire width of the page, providing a guide for writing. The background is a clean, solid white color. There are no margins, text, or other markings present on the sheet.

[illegible]